

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

User's Manual

RENESAS

Phase-out/Discontinued

PG-1500

PROM PROGRAMMER

Document No. U11940EJ4V0UM00 (4th edition)
(O.D.No. EEU-651B)
Date Published May 1997 N

© NEC Corporation 1990
Printed in Japan

[MEMO]

V25/35 and V30 are trademarks of NEC Corporation.

INTELLEC is a trademark of Intel Corporation.

MS-DOS is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

The export of this product from Japan is regulated by the Japanese government. To export this product may be prohibited without governmental license, the need for which must be judged by the customer. The export or re-export of this product from a country other than Japan may also be prohibited without a license from that country. Please call an NEC sales representative.

The information in this document is subject to change without notice.

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Corporation. NEC Corporation assumes no responsibility for any errors which may appear in this document.

NEC Corporation does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from use of a device described herein or any other liability arising from use of such device. No license, either express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Corporation or of others.

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC product in your application, please contact the NEC office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

NEC Electronics Inc. (U.S.)

Santa Clara, California
Tel: 800-366-9782
Fax: 800-729-9288

NEC Electronics (Germany) GmbH

Duesseldorf, Germany
Tel: 0211-65 03 02
Fax: 0211-65 03 490

NEC Electronics (UK) Ltd.

Milton Keynes, UK
Tel: 01908-691-133
Fax: 01908-670-290

NEC Electronics Italiana s.r.l.

Milano, Italy
Tel: 02-66 75 41
Fax: 02-66 75 42 99

NEC Electronics (Germany) GmbH

Benelux Office
Eindhoven, The Netherlands
Tel: 040-2445845
Fax: 040-2444580

NEC Electronics (France) S.A.

Velizy-Villacoublay, France
Tel: 01-30-67 58 00
Fax: 01-30-67 58 99

NEC Electronics (France) S.A.

Spain Office
Madrid, Spain
Tel: 01-504-2787
Fax: 01-504-2860

NEC Electronics (Germany) GmbH

Scandinavia Office
Taeby, Sweden
Tel: 08-63 80 820
Fax: 08-63 80 388

NEC Electronics Hong Kong Ltd.

Hong Kong
Tel: 2886-9318
Fax: 2886-9022/9044

NEC Electronics Hong Kong Ltd.

Seoul Branch
Seoul, Korea
Tel: 02-528-0303
Fax: 02-528-4411

NEC Electronics Singapore Pte. Ltd.

United Square, Singapore 1130
Tel: 253-8311
Fax: 250-3583

NEC Electronics Taiwan Ltd.

Taipei, Taiwan
Tel: 02-719-2377
Fax: 02-719-5951

NEC do Brasil S.A.

Sao Paulo-SP, Brasil
Tel: 011-889-1680
Fax: 011-889-1689

Major Revisions in This Version

Section	Description
Throughout	Target PROM devices for programming are added (75XL Series, 16- and/or 32-bit single chip microcontrollers, V851™, and V852™).
p.4	Part I , Description is added to the note of Section 1.3 Operating Mode .
p.7	Part I , Devices are added and changed in Table 1-1 List of PROM Adapters .
p.18	Part I , Devices are added to Table 2-1 Adapter Board Selection . (V851, V852, and 75XL Series)
p.25	Part II , Figure 2-1 Instruction System is changed.
p.28	Part II , Description on Section 2.4 ROM control (DEVICE Mode) is changed.
p.37	Part II , Devices (V851, V852, and 75XL Series) are added to Table 2-4 Device Selecting Silicon Signature Compatibility .
p.37	Part II , Devices are deleted or added in Table 2-5 78K Series Silicon Signature Compatible Products .
p.36	Part II , Description on Section 2.4.2 Device selection (SELECT) (2) Use of different selection methods is changed.
p.61	Part II , Description on Section 2.5 Memory Edit (EDIT MODE) is changed.
p.73	Part II , Description on Section 2.6 Interface Setting (FUNCTION MODE) is changed.
p.85	Part II , Description and Command list of Section 3.1 Outline of Operation are changed.
p.88	Part II , <Execution example> of Section 3.4.1 RS (ROM select) command is changed.
p.92	Part II , <Execution example> in Section 3.4.2 RZ (ROM zero check) command is changed.
p.95	Part II , Input format is added to Section 3.4.3 RR/RW/RV command input format .
p.97	Part II , <Execution example> in Section 3.4.4 RR (ROM read) command is changed.
p.103	Part II , <Execution example> and <Error control> in Section 3.4.5 RW (ROM write) command is changed.
p.109	Part II , <Execution example> in Section 3.4.6 RV (ROM verify) command is changed.
p.125	Part II , Description in Section 3.4.13 LI (Load Intel) command is changed.
p.126	Part II , Description and caution in Section 3.4.14 LM (Load Motorola) command are added.
p.127	Part II , Description and caution in Section 3.4.15 LI (Load TEK) command are added.
p.128	Part II , Description is added and <Execution example> is changed in Section 3.4.16 SI (Serial Intel) .
p.130	Part II , Description and caution in Section 3.4.17 SM (Serial Motorola) are added.
p.132	Part II , Description and caution in Section 3.4.18 ST (Serial TEK) are added.
p.157	Part II , Transfer procedure is added to Section 4.1.7 Data transfer from PG-1500 to external machine .
p.177	APPENDIX A , Description on Error Message List is changed.

The mark ★ shows major revised points.

[MEMO]

INTRODUCTION

The PROM programmer PG-1500 has the following features:

- (1) Typical PROMs having a capacity of 256 Kbits to 4 Mbits can be programmed.
- (2) Programming such as a single-chip microcontroller can be used as a separately available PROM programmer adapter.
- (3) ROM-type automatic identification and setting can be carried out using the silicon signature read function.
- (4) Memory edit such as data update and check can be carried out.
- (5) The device is protected by the device reverse load and incorrect insert check functions.
- (6) The internal power supply and internal memory are checked by the self-diagnostic function upon power-on.
- (7) All keyboard operations can be remote controlled via an RS-232-C interface.
- (8) Since this programmer is equipped with a typical data format according to standard specifications, it can be easily connected to a personal computer and development support tools.
- (9) The power supply is an AC wide-range type of 90 V to 250 V for use throughout the world.

Read this manual carefully before operation and follow its contents to ensure maximum performance.

[MEMO]

TABLE OF CONTENTS

PART I. INTRODUCTION	1
CHAPTER 1 PRODUCT OVERVIEW	3
1.1 PG-1500 Hardware Specifications	3
1.2 Operating Environment.....	3
1.3 Operating Modes	4
1.4 Cautions	4
1.5 Block Diagram	6
1.6 Product Configuration.....	8
CHAPTER 2. DESCRIPTION OF APPEARANCE	9
2.1 Front Panel	10
2.1.1 Adapter board connection unit	10
2.1.2 LCD Display unit	10
2.1.3 Key switch unit	11
2.2 Rear Panel	15
2.3 Sides	16
2.3.1 Right side	16
2.3.2 Left side	16
2.4 Adapter Board	17
2.4.1 General-purpose PROM socket board (27A board)	17
2.4.2 4-bit single-chip microcomputer interface board (04A board)	17
2.5 Adapter Board Connection	18
2.6 Device Insertion	20
2.6.1 When writing to a general-purpose PROM	20
2.6.2 When writing to a 78K Series device, DSP, etc.	20
2.6.3 When writing to a 75K Series device (except the μ PD75P402) or a μ PD7500 Series device	20
PART II. OPERATION	21
CHAPTER 1. OUTLINE OF OPERATION	23
1.1 Description of Terms	23
CHAPTER 2. STANDALONE MODE	25
2.1 Operation Overview	25
2.2 Setting	26
2.3 Start and Initial Test	26
2.4 ROM Control (DEVICE mode)	28
2.4.1 Parameter setting	29

2.4.2	Device selection (SELECT)	36
2.4.3	Blank check (BLANK)	53
2.4.4	Read (COPY)	55
2.4.5	Write (PROG)	56
2.4.6	Verify check (VERIFY)	58
2.4.7	Continuous operation (CONT)	60
2.5	Memory Edit (EDIT MODE)	61
2.5.1	Data change (CHANGE)	62
2.5.2	Initialize (INIT)	65
2.5.3	Block transfer (MOVE)	67
2.5.4	Data search (SEARCH)	69
2.5.5	Check sum (C-SUM)	72
2.6	Interface Setting (FUNCTION MODE)	73
2.6.1	Parallel input (P-IN)	74
2.6.2	Serial input (S-IN)	76
2.6.3	Serial output (S-OUT)	79
2.6.4	Serial interface setting (MODE)	81
2.6.5	Remote control mode setting (REMOTE)	84

CHAPTER 3. REMOTE CONTROL MODE 85

3.1	Outline of Operation	85
3.2	Setting	86
3.3	START, INITIAL TEST AND MODE SETTING	86
3.4	COMMANDS	87
3.4.1	RS (ROM Select) command	88
3.4.2	RZ (ROM Zero check) command	92
★ 3.4.3	RR/RW/RV Command input format	95
3.4.4	RR (ROM Read) command	97
3.4.5	RW (ROM Write) command	103
3.4.6	RV (ROM Verify) command	109
3.4.7	MC (Memory change) command	115
3.4.8	MD (Memory dump) command	117
3.4.9	MF (Memory fill) command	120
3.4.10	PI (Parallel Intel) command	122
3.4.11	PM (Parallel Motorola) command	123
3.4.12	PT (Parallel TEK) command	124
3.4.13	LI (Load Intel) command	125
3.4.14	LM (Load Motorola) command	126
3.4.15	LT (Load TEK) command	127
3.4.16	SI (Serial Intel) command	128
3.4.17	SM (Serial Motorola) command	130
3.4.18	ST (Serial TEK) command	132
3.4.19	?? (Help) command	134

CHAPTER 4. SIMPLE OPERATION EXAMPLES	135
4.1 Standalone Mode	136
4.1.1 Data read from master ROM to PG-1500 internal memory	136
4.1.2 Data write from PG-1500 internal memory to blank ROM	142
4.1.3 Changing PG-1500 internal memory data	149
4.1.4 Verify check	151
4.1.5 Split write to two PROMs of PG-1500 internal memory data	152
4.1.6 Data transfer from external machine to PG-1500	155
4.1.7 Data transfer from PG-1500 to external machine	157
4.2 Remote Control Mode	159
4.2.1 Outline of operations using NEC in-circuit emulator	159
4.2.2 Data write from in-circuit emulator to blank PROM	168
4.2.3 Data read from master ROM to in-circuit emulator	170
4.2.4 Data transfer from external machine to PG-1500 via parallel interface	172
APPENDIX A. ERROR MESSAGE LIST	177
A.1 Standalone Mode Error List	177
A.2 Remote Control Mode Error List	185
APPENDIX B. OBJECT FORMATS	189
B.1 INTELLEC HEX	189
B.2 MOTOROLA EXORCISER	191
B.3 EXTENDED TEKHEX	194
APPENDIX C. EXTERNAL INTERFACE	197
C.1 Serial Interface	197
C.1.1 Pin configuration	197
C.1.2 Interface circuit	199
C.1.3 Resetting	200
C.1.4 Handshake method	201
C.1.5 Connection example	206
C.2 Paralle Interface	207
C.2.1 Pin configuration	207
C.2.2 Interface circuit	209
C.2.3 Handshake method	210
C.2.4 Connection example	211

[MEMO]

LIST OF FIGURES

Figure No.	Title	Page
PART I. INTRODUCTION		
1-1	Block Diagram	6
2-1	External View	9
2-2	Front Panel	10
2-3	Key Switch Unit	11
2-4	Rear Panel	15
2-5	Right Side	16
2-6	Left Side	16
2-7	27A Board	17
2-8	04A Board	17
2-9	Connection of Main Unit and Adapter Board	19
PART II. OPERATION		
2-1	Instruction System	25
2-2	Normal Program Mode Flowchart	50
2-3	Fast Program Mode Flowchart	51
2-4	Page Program Mode Flowchart	52
4-1	IE-75000-R Channel 2 Setting	160
APPENDIX C. EXTERNAL INTERFACE		
C-1	Serial Interface Connector	197
C-2	Serial Interface Pin Configuration	197
C-3	RS-232-C Interface Circuit	199
C-4	Hardware Handshake	201
C-5	Software Handshake	202
C-6	Hardware Handshake	203
C-7	Schematic Circuit Diagram of Serial Input Unit	204
C-8	Software Handshake	205
C-9	Parallel Interface Connector	207
C-10	Parallel Interface Pin Configuration	207
C-11	Parallel Interface Circuit	209
C-12	Parallel Interface Timings	210

LIST OF TABLES

Table No.	Title	Page
PART I. INTRODUCTION		
1-1	List of PROM Programmer Adapters	7
2-1	Adapter Board Selection	18
PART II. OPERATION		
2-1	Initial Values	27
2-2	Numeric Keys Specified in Address Divide Mode	30
2-3	Specifiable Address Divide Modes	31
2-4	Device Selection by Silicon Signature Compatibility	37
2-5	78K Series Silicon Signature Compatible Products	37
2-6	List of Code Numbers	44
2-7	Items to be Set by MODE Command	81
4-1	IE-75000-R Channel 2 Setting	160
4-2	Channel 2 Settings By MOD Command	161
4-3	Sample of PG-1500 Serial Interface Settings	162
APPENDIX C. EXTERNAL INTERFACE		
C-1	Serial Interface Connector Signal Table	198
C-2	Connection Cable and Signal Relations	206
C-3	Parallel Interface Connector Signal Table	208
C-4	Connection Cable and Signal Relations	211

PART I. INTRODUCTION

[MEMO]

CHAPTER 1 PRODUCT OVERVIEW

The PG-1500 is a PROM programmer which performs PROM writing as a standalone unit or connected to a host machine.

The PG-1500 can write to the following devices.

- General-purpose NEC PROMs (256 K to 4 Mbits)
- The following devices with on-chip PROM^{Note 1}
 - NEC 4-bit single-chip microcontrollers
 - 75X Series, 75XL Series, μ PD7500 Series
 - NEC 8, 16 and 16/32-bit single-chip microcontrollers
 - 78K Series, 87AD Series, V25/35TM, V851, V852
 - NEC Turbo Access Manager
 - NEC DSP (digital signal processor)^{Note 2}
 - NEC speech synthesis LSI

Notes 1. PROM programmer adapter is required (sold separately).

2. Except μ PD77P20

1.1 PG-1500 Hardware Specifications

The PG-1500 hardware consists of the following:

CPU	μ PD70208 (8 MHz)
Data RAM	512 Kbytes
Monitor ROM	128 Kbytes
Work RAM	32 Kbytes
Serial interface	RS-232-C
Parallel interface	Conforming to Centronics

1.2 Operating Environment

Power voltage	90 VAC to 250 VAC
Power frequency	50 to 60 Hz
Temperature range	10 to 35°C
Humidity range	20 to 80%RH

1.3 Operating Modes

The following operating modes are available for the PG-1500.

Standalone mode	PG-1500 is used independently.
Remote control mode	PG-1500 is connected to and controlled by a host machine ^{Note} .

Note When directly connected to the host machine, use the PG-1500 controller (separately available).

Connection to an NEC in-circuit emulator is possible. For details, refer to Part II, Section 4.2 Remote Control Mode.

★

1.4 Cautions

(1) Power supply

Power voltage	90 VAC to 250 VAC
Power frequency	50 to 60 Hz

- Strictly follow the above power specifications.
- Before connecting the power cable, check that the power switch on the side panel is set to OFF.

(2) Power cable

- The maximum input voltage of the standard accessory power cable is 125 V.
- The power cable is a 3-pin flag type and a round pin in the center serves as a ground. Thus, use the power supply with a 3-pin socket having a ground.
- If the power supply is used with a 2 pin socket, use an accessory power adapter. In this case, be sure to connect the grounding terminal of the adapter to an external ground.

(3) Operating environment

Temperature range	10 to 35°C
Humidity range	20 to 80%RH

- Strictly follow the above ambient conditions.
- Do not use the PG-1500 where it might be exposed to a lot of dirt or dust, corrosive gases and direct sunlight.
- Avoid condensation.

(4) Cooling and ventilation

- Cooling and ventilation of this unit is carried out by means of natural convection through a vent hole made in the upper panel. Thus, do not place anything on the upper panel of this unit.

(5) Vibrations

- An LCD is used for the display unit. Thus, do not use the unit where it might be exposed to mechanical shocks or vibrations.

(6) Noise

- Avoid device programming near noise sources.
- Do not connect noise producing equipment on the same AC line as with this unit.

Example: PROM eraser, fluorescent lamp, motor-driven equipment, equipment with high current switching functions, etc.


(7) Others

- Do not turn on/off the power supply if a device is mounted on a socket.
- Do not turn the calibration volumes.

1.5 Block Diagram

The PG-1500 block diagram is shown below.

★ Figure 1-1 Block Diagram



Note PROM programmer Socket adapters

★

Table 1-1. List of PROM Programmer Adapters

	PROM Programmer Adapter			
Adapters connected to 27A board	PA-70P322L	PA-78P018KK-S	PA-78P214GJ	PA-78P328GF
	PA-71P301GF	PA-78P024CW	PA-78P214GQ	PA-78P334GJ
	PA-71P301GQ	PA-78P024GF	PA-78P214L	PA-78P334KW (KE)
	PA-71P301KA	PA-78P048GF	PA-78P224GJ	PA-78P334LQ
	PA-71P301KB	PA-78P048KL-S	PA-78P224L	PA-78P334KM
	PA-71P301L	PA-78P054GC	PA-78P238GC	PA-78P352G
	PA-75P402CT	PA-78P054GK	PA-78P238GJ	PA-78P352KK
	PA-75P402GB	PA-78P054KK-T	PA-78P238KF	PA-78P356GC
	PA-77P230R	PA-78P064GC	PA-78P238LQ	PA-78P356GD
	PA-77P25C	PA-78P064GF	PA-78P312CW	PA-78P356KP
	PA-77P25GW	PA-78P064KL-T	PA-78P312GF	PA-78P364CW
	PA-77P25L	PA-78P078GC	PA-78P312GQ	PA-78P368GF
	PA-78CP14CW	PA-78P078GF	PA-78P312L	PA-78P368KL
	PA-78CP14GF	PA-78P078KL-T	PA-78P322GF	PA-78P372GC
	PA-78CP14GQ	PA-78P083CU	PA-78P322GJ	PA-78P372GF
	PA-78CP14KB	PA-78P083GB	PA-78P322K	PA-78P372KL
	PA-78CP14L	PA-78P0208GF	PA-78P322KC	PA-78P4026GC
	PA-78P014CW	PA-78P0208KL-T	PA-78P322KD	PA-78P4026KK
	PA-78P014GC	PA-78P138GF	PA-78P322L	PA-78P4038GK ^{Note}
	PA-78P044GF	PA-78P138K	PA-78P324GJ	PA-78P4916GF
	PA-78P044KL-S	PA-78P148GF	PA-78P324KC	PA-70P3000KP ^{Note}
	PA-78P018CW	PA-78P148K	PA-78P324KD	PA-70P3000GC ^{Note}
	PA-78P018GC	PA-78P214CW	PA-78P324LP	
	PP-78P018GK	PA-78P214GC	PA-78P328CW	
Adapters connected to 04A board	PA-75P54CS	PA-75P117GF	PA-75P308GF	PA-75P516K
	PA-75P56CS	PA-75P117GK	PA-75P308K	PA-77P56
	PA-75P008CU	PA-75P117KG	PA-75P316BGC	PA-75P0076CU
	PA-75P036CW	PA-75P216ACW	PA-75P316BGK	PA-75P3116GC ^{Note}
	PA-75P036GC	PA-75P218GF	PA-75P316BKK-T	PA-75P3116GK ^{Note}
	PA-75P036KG	PA-75P218KB	PA-75P328GC	PA-75P3216GT ^{Note}
	PA-75P108CW	PA-75P238GJ	PA-75P336GK	PA-75P4308GS ^{Note}
	PA-75P116GF	PA-75P238KF	PA-75P516GF	PA-17KCZ

(As of July '96)

Note Under development

1.6 Product Configuration

The PG-1500 consists of the following items. Items (2) through (8) are accessories and related documents.

(1) PG-1500

Main unit. Used connected to accessory adapter board.

(2) Adapter boards (2 types)

a. General-purpose PROM socket board (27A board)

The PG-1500 operates as a PROM programmer for general-purpose PROM by connecting it to the 27A board. It is also used for the 78K Series, DSPs, etc. When a device other than a general-purpose PROM is used, the PROM programmer adapter (separately available) for that device is required.

b. 4-bit single-chip microcontroller interface board (04A board)

The PG-1500 operates as a PROM programmer for the 75X Series and μ PD7500 Series by connecting it to the 04 board. The program adapter (separately available) corresponding to the device used is required.

(3) Warranty

This document specifies a warranty for the PG-1500.

(4) PG-1500 User's manual

Read this manual to protect the unit from damage due to misoperation.

(5) Power cable

Power cable for the PG-1500. Strictly follow the operating voltage specifications marked on the rear panel.

(6) Power adapter

Adapter for the power cable for use with 2-pin socket.

(7) Spare fuse

Spare fuse for the PG-1500. The specification is 800 mA. Do not use any fuses other than 800-mA fuse.

(8) Attached documents


These are documents that list PG-1500 accessories and general-purpose PROMs for which the PG-1500 can be used.

Remark RS-232-C serial interface cable is not provided.

CHAPTER 2. DESCRIPTION OF APPEARANCE

This chapter describes the appearance of PG-1500 components and outlines PG-1500 functions. Figure 2-1 shows an external view of the main unit and the adapter board.


Figure 2-1. External View




Left Side

Front Panel


Right Side



Rear Panel



27A Board




04A Board

2.1 Front Panel

Figure 2-2 shows the front panel.

Figure 2-2. Front Panel



- < 1 > Adapter board connection unit
- < 2 > LCD display unit
- < 3 > Key switch unit

2.1.1 Adapter board connection unit

An adapter board of the PG-1500 accessories is connected to the adapter board connection unit.

The following two types of adapter boards are used:

- 27A board
- 04A board

For details of the adapter board, refer to **2.4 Adapter Boards** in **Part I**.


2.1.2 LCD Display unit

Data which is input and set using command and numeric keys are displayed on the LCD display unit.

For details of display in each mode, refer to **Part II. Operation**.

2.1.3 Key switch unit

Figure 2-3 shows the key switch unit.

Figure 2-3. Key Switch Unit

DEVICE mode..... Performs device access.

EDIT mode Performs PG-1500 internal memory editing.

FUNCTION mode Performs option function settings.

The key switch functions are as follows:

1. SET/START key

Switch to start each command or set data. Used to execute or re-execute each command.

2. △ key

Used to move the cursor to the right, and to change data.

3. ▽ key

Used to move the cursor to the left, and to change data. Also used as a cancel key after numeric value input.

4.

RESET

 key

Switch to reset in the idle state.

★ Used to suspend each instruction or release in the event of an error.

5.

DEVI
CE

 key

ROM control (DEVICE mode) select switch.

6.

EDIT

 key

Memory edit (EDIT mode) select switch.

7.

FUNC
TION

 key

Interface set (FUNCTION mode) select switch.

CHANGE

8.

0

 key

EDIT mode DATA CHANGE command select switch.

Used to change data in the PG-1500 internal memory.

Also used as a numeric value [0] input switch.

INIT

9.

1

 key

EDIT mode INITIALIZE command select switch.

Used to initialize the contents of the PG-1500 internal memory. Also used as a numeric value [1] input switch.

MOVE

10.

2

 key

EDIT mode BLOCK TRANSFER command select switch.

Used to move data in the specified range to different addresses in the PG-1500 internal memory.

Also used as a numeric value [2] input switch.

SEARCH

11.


3

 key

EDIT mode DATA SEARCH command select switch.

Used to retrieve the specified data from the data in the PG-1500 internal memory.


Also used as a numeric value [3] input switch.

C-SUM12.  key

EDIT mode CHECK SUM command select switch.

Used to calculate the checksum.

Also used as a numeric value [4] input switch.

S-IN13.  key

FUNCTION mode SERIAL INPUT command select switch.

Used to input data from the serial interface.

Also used as a numeric value [5] input switch.

S-OUT14.  key

FUNCTION mode SERIAL OUTPUT command select switch.

Used to output data from the serial interface.

Also used as a numeric value [6] input switch.

REMOTE15.  key

FUNCTION mode REMOTE CONTROL command select switch.

Used to set the remote control mode.

Also used as a numeric value [7] input switch.

P-IN16.  key

FUNCTION mode PARALLEL INPUT command select switch.

Used to input data from the parallel interface.

Also used as a numeric value [8] input switch.


MODE17.  key

FUNCTION mode SERIAL INTERFACE SET command select switch.

Used to set the serial interface parameter.

Also used as a numeric value [9] input switch.

CONT

18.  key

DEVICE mode CONTINUOUS OPERATION command select switch.

Used to perform device blank check, write, and verify operations automatically.

Also used as a numeric value [A] input switch.

SELECT

19.  key

DEVICE mode DEVICE SELECT command select switch.

Used to set the device write conditions.

Also used as a numeric value [B] input switch.

COPY

20.  key

DEVICE and READ command select switch.

Used to copy data in the device to the PG-1500 internal memory.

Also used as a numeric value [C] input switch.

BLANK

21.  key

DEVICE mode BLANK CHECK command select switch.

Used to check whether the device is blank.

Also used as a numeric value [D] input switch.

PROG

22.  key

DEVICE mode WRITE command select switch.

Used to write data in the PG-1500 internal memory to the device.

Also used as a numeric value [E] input switch.

VERIFY

23.  key

DEVICE mode VERIFY CHECK command select switch.


Used to check whether the data written to the device matches the contents of the PG-1500 internal memory.

Also used as a numeric value [F] input switch.

2.2 Rear Panel

Figure 2-4 shows the rear panel.

Figure 2-4. Rear Panel




- <1> AC input connector
Input voltage range from 90 to 250 V (50 to 60 Hz).
- <2> Fuse holder
800-mA power line fuse holder
- <3> Parallel interface connector
Connector for parallel interfaces. Conforming to Centronics.
- <4> Serial interface connector
Connector for serial interface (RS-232-C).

2.3 Sides

2.3.1 Right side

Figure 2-5 shows the right side viewed from the front.

Figure 2-5. Right Side




<1> Power switch

Seesaw switch. Setting this switch to the left position (toward the front side of the main unit) turns on the power supply. Setting this switch to the right position (toward the opposite side of the main unit) turns off the power supply.

2.3.2 Left side

Figure 2-6 shows the left side viewed from the front.

Figure 2-6. Left Side



<1> Calibration volume cover

Cover for the internal calibration volume for use by NEC.

Do not turn the internal calibration volume.

2.4 Adapter Board


Two adapter boards are provided with the PG-1500, as described below.

2.4.1 General-purpose PROM socket board (27A board)

The general-purpose socket board (27A board) is the adapter board for general-purpose PROM. It is also used for the 78K Series, DSPs, etc. When a device other than a general-purpose PROM is used, the PROM programmer adapter (sold separately) for that device is required.

Figure 2-7 shows the 27A board.

Figure 2-7. 27A Board




These sockets are equipped with an LED which lights up during use.

2.4.2 4-bit single-chip microcomputer interface board (04A board)

The 4-bit single-chip microcomputer interface board (04A board) is the adapter board for the μ PD7500 Series. The PROM programmer adapter (sold separately) for the device used is required.

Figure 2-8 shows the 04A board.

Figure 2-8. 04A Board



2.5 Adapter Board Connection

When using the PG-1500, the adapter board for the device to be used is first mounted on the adapter board connection area. Select the adapter board in accordance with Table 2-1.

★

Table 2-1. Adapter Board Selection

Device Used	Adapter Board
General-purpose PROM	27A board
78K Series	
87AD Series	
V25/35 (μ PD70P322)	
V851 (μ PD70P3000)	
V852 (μ PD70P3002)	
Turbo Access Manager (μ PD71P301)	
DSP	
μ PD75P402	
75X Series (except μ PD75P402)	04A board
75XL Series	
μ PD7500 Series	
Speech Processing Device (μ PD77P56)	

The procedure of connecting the adapter board is described below.


<Connecting Procedure>

- <1> Insert the two guide pins of the adapter board into the guide pin holes of the main unit.
- <2> Push the adapter board so that the two connectors are securely connected in parallel to the obliquely mounted main unit.
- <3> Connection of the adapter board is completed after checking that there is no gap between the adapter board and the main unit.
- <4> After the 04A board has been connected, connect a PROM programmer adapter (sold separately) onto the 04A board.

When the 27A board is used, a PROM programmer adapter (sold separately) should also be connected when using a device other than a general-purpose PROM.

Figure 2-9 shows an adapter board connection example.

Figure 2-9. Connection of Main Unit and Adapter Board



2.6 Device Insertion

2.6.1 When writing to a general-purpose PROM

Insert the device directly into the 27A board. The procedure is shown below.

- (1) From the three sockets on the 27A board, select the one with the same number of pins as the device used, and raise the lever vertically.
- (2) Insert the device into the socket, with pin 1 at the top left.
- (3) Lower the lever.

Caution Do not turn the power on/off with the device inserted in the socket, as this may damage it.

2.6.2 When writing to a 78K Series device, DSP, etc.

Connect the PROM programmer adapter to the 27A board, and insert the device into the PROM programmer adapter. The procedure is shown below.

- (1) From the three sockets on the 27A board, select the one with the same number of pins as the number of connection pins on the PROM programmer adapter used, and raise the lever vertically.
- (2) Turn the PROM programmer adapter so that the words "NEC MADE IN JAPAN" on its base (the part to which the socket is not attached) can be seen, and insert it into the socket.
- (3) Lower the lever.
- (4) Insert the device into the PROM programmer adapter as shown in the relevant instruction manual.

The shape of the PROM programmer adapter varies according to the shape of the device package. If the PROM programmer adapter has a pin 1 indication, insert the device in accordance with that indication. If there is no indication, follow the directions given in the relevant instruction manual. Lower the lever if one is provided, and if there is a closing cover, check that this is locked securely. This completes device insertion.

Note Do not turn the power on/off with the device inserted in the socket, as this may damage it.

2.6.3 When writing to a 75K Series device (except the μ PD75P402) or a μ PD7500 Series device

Connect the PROM programmer adapter to the 04A board, and insert the device into the PROM programmer adapter. The procedure is shown below.

- (1) Connect the connectors of the PROM programmer adapter used to the five sockets on the 04A board so that it is correctly aligned.
- (2) Insert the device into the PROM programmer adapter as shown in the relevant instruction manual.

The shape of the PROM programmer adapter varies according to the shape of the device package. If the PROM programmer adapter has a pin 1 indication, insert the device in accordance with that indication. If there is no indication, follow the directions given in the relevant instruction manual. Lower the lever if one is provided, and if there is a closing cover, check that it is locked securely. This completes device insertion.

Caution Do not turn the power on/off with the device inserted in the socket, as this may damage it.

PART II. OPERATION

[MEMO]

CHAPTER 1. OUTLINE OF OPERATION

As described in Part I, the following operating modes are available for the PG-1500:

- Standalone mode
- Remote control mode

(1) Standalone mode

This mode is a PG-1500 single unit which is used for device copy and program patch operations. Since the serial and parallel interfaces are supported, input/output to/from an external device is possible (input only via the parallel interface).

(2) Remote control mode

This mode is the PG-1500 which can be controlled from a host machine (PC-9800 series, etc.) connected to the PG-1500.

1.1 Description of Terms

The terms used in this user's manual are outlined below.

(1) PROM start address

Start address to determine the address range of a device inserted into the socket.

(2) PROM end address

End address to determine the address range of a device inserted into the socket.

(3) PG-1500 internal memory

Memory in the PG-1500. This is for storage of data which is read from a device.

(4) Address divide

Only even or odd addresses of the PG-1500 internal memory are used.

(5) Initial test

PG-1500 internal circuit check operation to be automatically carried out upon power-ON.

(6) Silicon signature data

Product code which each device internally possesses.

This shows the device write conditions.

(7) Idle state

Mode set state to be generated upon power-ON or when the RESET key is pressed.

(8) Check sum width

This is the total resulting from data addition used to check whether the data is correct.

(9) Precheck

Function for checking incorrect device insertion or inverted device insertion. This function can only be used with an NEC general-purpose PROM.


CHAPTER 2. STANDALONE MODE

2.1 Operation Overview

The standalone mode is the state in which the PG-1500 is used as a single unit and is not connected to other devices.

Figure 2-1 shows a STANDALONE mode instruction system.

Figure 2-1. Instruction System



Turning on the PG-1500 power supply automatically sets the mode to the STANDALONE mode.

2.2 Setting

An adapter board corresponding to the device used for the PG-1500 is connected. When using a device other than a general-purpose PROM, a PROM programmer adapter is connected to the adapter board.

Turn the power on, then insert the device in the socket.

See **Part I. 2.5 Adapter Board Connection** and **Part I. 2.6 Device Insertion** for details.

Caution Do not turn on/off the power supply with the device inserted into the socket. The device may be damaged.

2.3 Startup and Initial Test

When the PG-1500 is powered on, the following message is displayed, indicating that a test (initial test) is performed to check if the PG-1500 functions operate normally.

```
PG-1500
*Initial Test Busy
```

↑

Blinks during initial test execution.

When the initial test terminates normally, the following message is displayed and the system waits for key input.

```
DEVICE EDIT FUNCTION
IDLE          V♦.♦
```

Idle status

□

PG-1500 Monitor ROM Version is displayed.

This status is called "idle status" in this manual.

If an error occurs during initial test, the following message is displayed on the LCD.

```
PG-1500
ERRXX
```

XX: Error number

Remark For details of error numbers, refer to **Appendix A. Error Message List**.

In this case, turn on the power supply again a few seconds after turning it off.

If the error is generated again the PG-1500 may be damaged, and you should therefore contact NEC or an authorized NEC dealer.

Table 2-1 lists the initial parameter values in each mode upon power-ON.

Table 2-1. Initial Values

Mode Parameter	Initial Value
PROM product name code	μ PD27256
Code Number	1004
Device selection method	READ
PROM start address	00000H
PROM end address	07FFFH
Internal memory start address	00000H
Address divide mode	NORMAL
Internal memory data	FFH
Precheck	OFF
Data format	INTELLEC TM


Note

Note [7FFFF] is displayed.

DEVICE

★ 2.4 ROM Control (DEVICE mode)

The DEVICE mode is a mode in which a device is directly controlled.




Note The SELECT command specifies write conditions specific to the device, and must be executed before executing a DEVICE mode command other than SELECT.

2.4.1 Parameter setting

The following parameters can be set for the execution of the COPY, PROG, VERIFY and CONT commands in the DEVICE mode.


- PROM start address
- PROM end address
- PG-1500 internal memory start address
- Address divide mode

These parameters are displayed as follows:



The parameters are described below.

- (1) [PROM start address
PRM end address
PG-1500 internal memory start address]



As shown in the figure above, the range in which device writing, reading, etc., is to be performed is set with the PROM start address and PROM end address. Also, the address in the internal memory from which the memory is to be used is set with the PG-1500 internal memory start address.

Caution An error will be caused by any of the following settings.

1. PROM start address > PROM end address
2. PROM size < PROM start address
3. PG-1500 internal memory start address > 7FFFFH

If an error occurs, see Appendix A.1 "List of Standalone Mode Errors".

DEVICE**(2) What is the address divide mode?**

Address divide is used to divide data into a ROM for a 16-bit or 32-bit CPU.

Address divide mode specification is performed by means of the specified numeric keys shown in Table 2-2 when the parameters are set.

Table 2-2. Numeric Keys Specified in Address Divide Mode

Numeric Key	Description	Display
0	Normal (without address divide)	NORMAL
4	16-bit data divided into 2, applicable to even addresses	16EVN
7	16-bit data divided into 2, applicable to odd addresses	16ODD
C	32-bit data divided into 2, applicable to even addresses	32/2E
F	32-bit data divided into 2, applicable to odd addresses	32/2O
8	32-bit data divided into 4, applicable to the 1st even address	32/4E1
9	32-bit data divided into 4, applicable to the 1st odd address	32/4O1
A	32-bit data divided into 4, applicable to the 2nd even address	32/4E2
B	32-bit data divided into 4, applicable to the 2nd odd address	32/4O2

The address divide modes that can be specified depend on the device. The address divide modes that can be specified for each device are shown in Table 2-3.

Table 2-3. Specifiable Address Divide Modes

Product Name	Normal (No Division)	16 Bits, 2 Divisions	32 Bits, 4 Divisions	32 Bits, 2 Divisions
μ PD27256	○	○	○	×
μ PD27256A	○	○	○	×
μ PD27C256	○	○	○	×
μ PD27C256A	○	○	○	×
μ PD27C512	○	○	○	×
μ PD27C1000	○	○	○	×
μ PD27C1000A	○	○	○	×
μ PD27C1001	○	○	○	×
μ PD27C1001A	○	○	○	×
μ PD27C1024	○	×	×	○
μ PD27C1024A	○	×	×	○
μ PD27C2001	○	○	×	×
μ PD27C4001	○	×	×	×
μ PD27C4096	○	×	×	×
Devices other than general-purpose PROMs	○	×	×	×

Remark ○: Specifiable, ×: Not specifiable


Caution Do not specify a non-specifiable address division mode. If a device other than a general-purpose PROM is used, be sure to specify normal mode (no address division).

If a non-specifiable address division mode is specified, an error will result. See **Appendix A.1 List of Standalone Mode Errors**.


If an address division mode is not used, the correspondence between the device ROM and PG-1500 internal memory data is as follows (normal mode (no address division) is omitted).

DEVICE

4 16EVN (16-Bit Even Address)




7 16ODD (16-Bit, Odd Address)




DEVICE


8 32/4E1 (32-Bit, 4-Divide Even Address-1)




9 32/4O1 (32-Bit, 4-Divide Odd Address-1)



A 32/4E2 (32-Bit, 4-Divide Even Address-2)




B 32/4O2 (32-Bit, 4-Divide Odd Address-2)




The parameter setting methods are described from the next page.

DEVICE

<Operating procedure>



DEVICE




Note Refer to Table 2-2 for the specified numeric keys.

DEVICE**SELECT****2.4.2 Device selection (SELECT)**


The SELECT command is intended to select the device to be used and set the device write conditions (including the write voltage). This command should be carried out at the start of the DEVICE mode.

There are three modes for device selection: READ mode, AUTO mode, and CODE mode. There may be restrictions on the methods that can be used depending on the device; therefore, one method should be selected in accordance with the following description.



The mode set by the SELECT command is displayed while a DEVICE mode command (BLANK, COPY, PROG, VERIFY and CONT) is executed.

Example Display for PROG command execution

**(1) Silicon signature compatible and non-compatible products**

Each device has its own specific write conditions.

The write conditions are recorded in the device as a silicon signature. With the PG-1500, the write conditions for a particular device are set by reading the silicon signature data from the device or inputting a code number corresponding to the write conditions to the PG-1500.

Depending on the device, the silicon signature may or may not be compatible with the PG-1500.

Device selection by silicon signature compatibility is detailed in Tables 2-4 and 2-5.

DEVICE**SELECT****Table 2-4. Device Selection by Silicon Signature Compatibility**

		READ Mode	AUTO Mode	CODE Mode
Silicon signature compatible products	General-purpose PROM	○	○	○
	μPD75P402	○	○	○
	78K Series products shown in Table 2-5	○	○	○
	V851/V852	○	○	○
	87AD series	○	○	○
	Turbo Access Manager	○	○	○
	75X Series (except μPD75P402)	○	○	×
	75XL Series	○	○	×
	μPD7500 Series	○	○	×
	Speech Synthesis LSI	○	○	×
Silicon nature non-compatible products	78K Series products not shown in Table 2-6	×	×	○
	V25/V35	×	×	○
	DSP	×	×	○

Remark ○: Usable, ×: Not usable

(As of July '96)

Table 2-5. 78K Series Silicon Signature Compatible Products

	8-Bit Single-Chip Microcontrollers		16-Bit Single-Chip Microcontrollers	
Silicon signature compatible products	μPD78P014	μPD78P078	μPD78P322	μPD78P372 ^{Note}
	μPD78P044	μPD78P083	μPD78P324	μPD78P4026
	μPD78P018F ^{Note}	μPD78P0208	μPD78P328	μPD78P4038 ^{Note}
	μPD78P024 ^{Note}	μPD78P138	μPD78P334	μPD78P4916
	μPD78P048A ^{Note}	μDP78P148	μPD78P352	
	μPD78P054	μPD78P218A	μPD78P356	
	μPD78P058	μPD78P224	μPD78P364	
	μPD78P064 ^{Note}		μPD78P368A	

Note Under development

(As of July '96)

DEVICE**SELECT**

(2) Use of different selection methods

The appropriate selection method – READ mode, AUTO mode, or CODE mode – for the device used should be selected in accordance with the description given below.

Caution On no account set a mode which cannot be used, as this may damage the device.

★

(a) READ mode: manual reading of silicon signature data

This method sets the device-specific write conditions by reading silicon signature data from the device inserted into the socket when SELECT command is executed.


After setting, the read silicon signature data is compared with previously set silicon signature data at the execution of BLACK, COPY, PROG, VERIFY, and CONT in the ROM control instruction.

This is useful when a number of devices of the same type are used one after another.

When the device type is changed, select the device type by executing another SELECT command.

Caution READ mode can only be used to set the write conditions for silicon signature compatible products.

Refer to Table 2-4 in 2.4.2 Device Selection (SELECT).

DEVICE**SELECT**

Note See the operating method on the next page.


Cautions 1. If READ mode is used with a device without silicon signature compatibility, the device may be damaged.

In this case, CODE mode should be used.

★ 2. When setting the μ PD75P402, set the ROM end address to 77FH while executing COPY, PROG, VERIFY, and CONT.

DEVICE**SELECT**

<Operating procedure>



DEVICE**SELECT**

★


(b) AUTO mode: automatic reading of silicon signature data

With this method, the silicon signature data which indicates the device-specific write conditions is automatically read from the device each time a DEVICE mode command, BLANK, COPY, PROG, VERIFY, or CONT is executed, and the write conditions are then set. The write address range should be set to the entire address range of the device.

This is useful when a number of devices of different types are used one after another.

Caution AUTO mode can only be used to set the write conditions for silicon signature compatible products.

Refer to Table 2-4 in 2.4.2 Device Selection (SELECT)


DEVICE**SELECT**

Note See the operating method on the next page.

Caution If AUTO mode is used with a device without silicon signature compatibility, the device may be damaged. In this case, CODE mode should be used.

DEVICE**SELECT**

<Operating procedure>




DEVICE**SELECT**★ (c) **CODE mode: manual input of code number**

With this method, a code number which indicates the device-specific write conditions is input at the SELECT command execution, and the write conditions are then set. When using a device other than general-purpose PROM (including silicon signature noncompatibles), the end address of the general-purpose PROM corresponding to the device may differ. The write address range should be set at the time of ROM control instruction (DEVICE) input such as COPY, PROG, VERIFY, or CONT.

- Cautions**
1. When the μ PD75P402 is used, the write conditions are set by inputting the code number for the μ PD27C256A (1064) and changing the ROM end address to 77FH when executing each command.
 2. CODE mode cannot be used to set the write conditions for 75X Series devices (except the μ PD75P402), μ PD7500 Series devices, or speech synthesis LSIs.

Table 2-6. List of Code Numbers

General-Purpose PROM	Code Number
μ PD27256	1004
μ PD27256A	10C4
μ PD27C256	10A4
μ PD27C256A	1064
μ PD27C512	1025
μ PD27C1000	1086
μ PD27C1000A	1016
μ PD27C1001	1046
μ PD27C1001A	10D6
μ PD27C1024	1026
μ PD27C1024A	10B6
μ PD27C2001	10C7
μ PD27C4001	10C8
μ PD27C4096	10A8


**DEVICE
SELECT**

Note See operating procedure on the next page.

Caution If a different code number device is used after CODE mode setting, no errors result.

SELECT

<1>

DEVICE**SELECT**

DEVICE SELECT

(3) Program mode

The program mode designates the write method according to differences in the length of the program pulses, the number of bytes written at one time, etc.

If READ mode or AUTO mode is used as the device selection method, the program mode is changed automatically according to the device being written to, so that the fastest write method is selected.

If CODE mode is used as the device selection method, the program mode should be selected after the code number is input. Any of three program modes can be selected: NORMAL, FAST and PAGE.

(a) Normal program mode (NORMAL)

Target devices: All devices^{Note}

The program can be performed by applying a 1-ms initial program pulse (active low) to the \overline{CE} pin for the initial address, then executing the program verify with \overline{OE} ^{Note} set to 0. If the program cannot be performed only by the first initial program pulse, programs and program verifies are repeated X times ($X \leq 25$) to verify a 1-byte program, then an additional program pulse (3X ms) is added to complete the 1-byte program. After completing the 1-byte program, the address is incremented by one. The same sequence as above is repeated up to the last address.

After completing whole byte programs, the whole byte verify is carried out.

Figure 2-2 shows the program mode flowchart.

Note The normal program mode for the μ PD27C1000A, μ PD27C1001A and μ PD27C1024A, 27C2001, 27C4001, 27C4096 is the same as the fast program mode.

(b) Fast program mode (FAST)

Target devices: μ PD27256A, μ PD27C256A and μ PD27C512

The program can be performed by applying a 0.1-ms initial program pulse (active low) to the \overline{CE} (\overline{PGM}) pin for the initial address, then executing the program verify with \overline{OE} set to 0. If the program cannot be performed only by the first initial program pulse, programs and program verifies are repeated X times ($X \leq 10$) to verify the 1-byte program. This completes the 1-byte program. After completing the 1-byte program, the address is incremented by one. The same sequence as above is repeated up to the last address. After completing whole byte programs, the whole program verify is carried out.

Figure 2-3 shows the program mode flowchart.

DEVICE

SELECT

(c) Page program mode (PAGE)

Target devices: μ PD27C1000A, μ PD27C1001A and μ PD27C1024A, 27C2001

The program can be performed by latching the initial 4-byte, 1-page address and data in the page data latch mode, and by applying 0.1-ms program pulse (active low) to the $\overline{\text{PGM}}$ pin with $\overline{\text{CE}}$ and $\overline{\text{OE}}$ set to 1, then immediately changing $\overline{\text{CE}}$ and $\overline{\text{OE}}$ to 0. This completes the program verify. If the program cannot be performed only by the first program pulse, programs and program verifies are repeated X times ($X \leq 10$). After confirming the 1-page program, the address is incremented by one. The same sequence as above is repeated up to the last address.


After completing whole byte programs, the whole byte verify is carried out.

Figure 2-4 shows the program mode flowchart.

The program mode cannot be selected for a device for which CODE mode cannot be used (75X Series, μ PD7500 Series, or speech synthesis LSI). When READ mode or AUTO mode is used, the program mode is set automatically. With a general-purpose PROM, the program modes that can be selected vary from device to device. If there is more than one selectable program mode, one of these should be selected.

With other devices, as a general rule the NORMAL program mode should be selected.

Please refer to the data sheet for the device concerned for details of program modes.


DEVICE**SELECT****Figure 2-2. Normal Program Mode Flowchart**

G = Start Address
N = Program End Address

DEVICE

SELECT


Figure 2-3. Fast Program Mode Flowchart



G = Start Address
N = Program End Address

DEVICE **SELECT**

Figure 2-4. Page Program Mode Flowchart




DEVICE**BLANK****2.4.3 Blank check (BLANK)**

The BLANK command performs a check to determine whether the device inserted in the socket is blank (blank check).

The entire address range is checked regardless of the operation address range set by other commands.

<Operating procedure>




Note There is no code display when the device selection mode is READ mode or CODE mode.

DEVICE**BLANK**

In the event of an error, take the following countermeasure.

If [ERR28] is displayed



A blank error has occurred.

This error occurs if the device inserted into the socket is not unwritten.

Countermeasure 1

To stop command execution, press the **RESET** key.

This generates the idle status.

Countermeasure 2

To execute a blank check, press the **SET/START** key.

Blank check starts at an address following the error address.


Caution When operation becomes normal at the address following the error address by taking countermeasure 2, [OK] is displayed.

If any other error occurs, take the necessary measure in accordance with **Appendix A.1 Standalone Mode Error List**.

DEVICE**COPY****2.4.4 Read (COPY)**

The COPY command is intended to copy the data written into the ROM to the PG-1500 internal memory. After all the addresses have been read, verification is performed on all the addresses automatically.

<Operating procedure>




DEVICE**PROG****2.4.5 Write (PROG)**

The PROG (PROGRAM) command is intended to write PG-1500 internal memory data into the unwritten device inserted into the socket.

Writing (including verification) is performed in accordance with the program mode specified when the SELECT command is executed.

<Operating procedure>



DEVICE

PROG

In the event of an error, take the following countermeasure.

If [ERR2C] is displayed

Internal Memory Data		Error Address Data
33:	22	
PROG	ERR2C	11111
Error Number		Error Address

A write error has occurred.

This error occurs if data cannot be written to the device.

Countermeasure 1

To stop command execution, press the **[RESET]** key.

This generates the idle status.

Countermeasure 2

To continue write operation, press the **[SET/START]** key.

Write to ROM starts at an address following the error address.

★ **Caution** Even if operation becomes normal at the address following the error address by taking countermeasure 2, a verify error (ERR20) still occurs in a verify check to be executed after termination of write operation.


If any other error occurs, take the necessary measure in accordance with **Appendix A.1 Standalone Mode Error List**.

DEVICE**VERIFY****2.4.6 Verify check (VERIFY)**

The VERIFY command is intended to check if the data which is written into the device matches the PG-1500 internal memory content.

When data has been written to the device, or when data has been read from the device, a verify check should be performed directly afterward. If power is cut or the device is replaced before a verify check is performed, the data write must be repeated from the start, followed immediately by a verify check.

<Operating procedure>



DEVICE

VERIFY

In the event of an error, take the following countermeasure.

★

If [ERR21, 22] is displayed

Internal Memory Data		Error Address Data
33 :	22	
VERI	ERR21	11111
Error Number		Error Address

A verify error has occurred.

This error occurs if device data does not match the PG-1500 internal memory data content.

Countermeasure 1

To stop command execution, press the **RESET** key.

This generates the idle status.

Countermeasure 2

To execute a verify check, press the **SET/START** key.

Compare starts at an address following the error address.


Caution When operation becomes normal at the address following the error address by taking countermeasure 2, [OK] is displayed.

If any other error occurs, take the necessary measure in accordance with **Appendix A.1 Standalone Mode Error List**.

DEVICE**CONT****2.4.7 Continuous operation (CONT)**

The CONT (CONTINUOUS) command is intended to carry out a continuous operation concerning a program which executes blank check, ROM write, and verify check in order.

<Operating procedure>



EDIT

★ **2.5 Memory Edit (EDIT MODE)**

The EDIT mode is intended to edit or change data in the PG-1500 internal memory.


EDIT

CHANGE	: Internal memory data check and change
INT	: Internal memory initialize
MOVE	: Internal memory block transfer
SEARCH	: Internal memory data search
C-SUM (CHECKSUM)	: Internal memory checksum

EDIT**CHANGE****2.5.1 Data change (CHANGE)**

The CHANGE command is intended to check or change PG-1500 internal memory data.


Because this command enables any address in the PG-1500 internal memory to be set, data at any address can be readily checked or changed.



EDIT

CHANGE

<Operating procedure>



EDIT**CHANGE****(1) Check**

To check data, change the address value using the Δ or ∇ key.

Δ : Address value increases.

∇ : Address value decreases.



```
12341:DD EE FF 00 11
12346:22 33 44 55 66
```

Address value increases and data shifts.



```
1233F:BB CC DD EE FF
12344:00 11 22 33 44
```

Address value decreases and data shifts.

Upon termination of check operation, exit from this mode using the **DEVICE**, **EDIT**, **FUNCTION** or **RESET** key.

(2) Change

To change the data for the specified address, press the **0** to **F** numeric keys. The displayed data (at locations where the cursor is blinking) is erased and the input numeric value is displayed from the right.

0 to **F**
(Numeric Key)

```
12340:CC DD EE FF 00
12345:7B 22 33 44 55
```

Input data.

Use the ∇ key to cancel the input numeric value.

(Setting Example)

Changing [12345] address data to [7B]

SET/START

```
12341:DD EE FF 00 7B
12346:22 33 44 55 66
```


Data is changed and the address proceeds to the next value

Upon termination of change operation, exit from this mode using the **DEVICE**, **EDIT**, **FUNCTION** or **RESET** key.

Caution If a numeric value is input, the preset data cannot be changed unless the **SET/START** key is pressed.

EDIT**INIT****2.5.2 Initialize (INIT)**

The INIT (INITIAL) command is intended to initialize the data in the range specified by the PG-1500 internal memory using the specified data.




Remark It takes about 1 second to initialize 512K bytes (all data of the PG-1500 internal memory).


<Operating procedure>

Key Operation

Display

Description




EDIT**INIT**


Upon termination of initialize, exit from this mode using the **DEVICE**, **EDIT**, **FUNCTION** or **RESET** key.


EDIT**MOVE****2.5.3 Block transfer (MOVE)**

The MOVE command is intended for block transfer of data between any start address of the PG-1500 internal memory and the end address to any different address.




<Operating procedure>



EDIT**MOVE**

Caution If the transfer address range overflow the destination address range, [ERR12] occurs.
(Example)



In this case, change the transfer destination start address or decrease the transfer address range.


EDIT

SEARCH

2.5.4 Data search (SEARCH)

The SEARCH command is intended to search for the PG-1500 internal memory address at which the key input data string is located.


A data string with a maximum of 4 bytes can be searched for and the search range can also be specified.



Caution 1-, 2- or 4-byte data string can be searched. 3-byte data string cannot be searched.


Remark It takes a maximum of about 20 seconds to search for a data string.

Example Search data string : 000000FF
Search range : 00000H to 7FFFFH




EDIT**SEARCH**

<Operating procedure>



EDIT


SEARCH



EDIT**C-SUM****2.5.5 Checksum (C-SUM)**

The C-SUM (CHECKSUM) command is intended to display the PG-1500 internal memory data sum value.

The checksum value is also displayed upon termination of each DEVICE mode command (COPY, PROG, VERIFY and CONT).



<Operating procedure>


Key Operation	Display	Description
EDIT	CHA INI MOV SEA SUM EDIT	EDIT mode is set.
C-SUM	00000:7FFFF CSUM	C-SUM command is selected.
SET/START	00000:7FFFF *CSUM ↑ Blinks while internal memory is being accessed.	Checksum is calculated.
End	Checksum Value 00000:7FFFF 0000 CSUM	Upon normal termination, the checksum value is displayed.

Caution The address range cannot be specified by this command.

FUNCTION

★ 2.6 Interface Setting (FUNCTION MODE)

The FUNCTION mode is intended to input/output data to/from the external device or to set the interface.



- Cautions**
1. For details of these transfer formats, refer to Appendix B Object Formats.
 2. In baud rate and character format setting, ON/OFF can be set for the precheck function to check whether the device is inserted correctly only for general-purpose PROMs.

FUNCTION

P-IN

2.6.1 Parallel input (P-IN)

The P-IN (PARALLEL INPUT) command is intended to input data from an external device connected to the PG-1500 parallel interface.

When executing the P-IN command, the PG-1500 should be connected to the external machine by a serial interface cable.

The P-IN command enables the following transfer data formats to be set.


- INTELLEC HEX (INTELLEC)
- MOTOROLA EXORCISER (MOTOROLA)
- EXTENDED TEKHEX (EX-TEK)

<Transfer method>

(1) Transferred data is masked in a 512K-byte unit.


(Transfer example)

(a) When data transferred from an external device is 00000H to 0FFFFFFH



Unless data is transferred in two transfers, only [80000H to 0FFFFFFH] data is transferred to the PG-1500 internal memory.

(b) When external transfer data is 0E0000H to 0F0000H in INTELLEC format



As shown above, data is transferred to the 60000H to 7FFFFH range.


FUNCTION

P-IN

(2) The end of data input is an end record in each transfer format (INTELLEC, MOTOROLA and EX-TEK).

Caution When using this mode, be sure to start external device data output after setting the PG-1500 to the RECEIVE mode. If the procedure is carried out in reverse order, the first data is not loaded correctly.

<Operating procedure>



Remark When the PC-9801VX (V30: 10 MHz) MS-DOS V3.1 is connected, it takes approx. 2 minutes to transfer (receive) 512K bits.

FUNCTION**S-IN****2.6.2 Serial input (S-IN)**

The S-IN (SERIAL INPUT) command is intended to input data from an external device connected to the PG-1500 serial interface.

When executing the S-IN command, the PG-1500 should be connected to the external machine by a serial interface cable.

The following data formats can be set by the S-IN command.


- INTELLEC HEX (INTELLEC)
- MOTOROLA EXORCISER (MOTOROLA)
- EXTENDED TEKHEX (EX-TEK)

<Transfer method>

(1) The location of the transferred data is masked in a 512K-byte unit.

(Transfer example)

(a) When data transferred from an external device is 00000H to 0FFFFFFH.




Unless data is transferred in two transfers, only [80000H to 0FFFFFFH] data is transferred to the PG-1500 internal memory.

FUNCTION

S-IN

- (b) When external transfer data is 0E0000H to 0F0000H in INTELLEC format.




As shown above, data is transferred to the 60000H to 7FFFFH range.

- (2) Data input terminates with an end record in each transfer format (INTELLEC, MOTOROLA and EX-TEX).

Caution When using this mode, be sure to start external device data output after setting the PG-1500 to the **RECEIVE** mode. If the procedure is carried out in reverse order, the first data is not loaded correctly.

FUNCTION**S-IN**

<Operating procedure>



Caution If no external devices are connected, pressing the **SET/START** key causes [ERR40] as follows.

ERR40 Not ready

Remark When the PC-9801VX (V30™: 10 MHz) MS-DOS™ V3.1 is connected, it takes approx. 3 minutes to transfer (receive) 512K bits at the baud rate of 9600 bps.

FUNCTION

S-OUT

2.6.3 Serial output (S-OUT)

The S-OUT (SERIAL OUTPUT) command is intended to output data from the PG-1500 with an external device connected to the PG-1500 serial interface.

When executing the S-OUT command, the PG-1500 should be connected to the external machine by a serial interface cable.

The S-OUT command enables the following transfer data formats to be set.

- INTELLEC HEX (INTELLEC)
- MOTOROLA EXORCISER (MOTOROLA)
- EXTENDED TEKHEX (EX-TEK)

It also enables the PG-1500 internal memory start address, end address and EOF code specifying the transfer range to be set.

EOF code


The EOF code is used for an external device connected to the PG-1500 to close a file.

Data output terminates with each format end record and the EOF code following the record.

(EOF code example) When OS is MS-DOS


↑ Z (control Z) → 1AH

<Operating procedure>



FUNCTION

S-OUT



Remark When the PC-9801VX (V30: 10 MHz) MS-DOS V3.1 is connected, it takes approx. 3 minutes to transfer 512K bits at the baud rate of 9600 bps.

FUNCTION

MODE

2.6.4 Serial interface setting (MODE)

The MODE command is intended to execute serial interface setting and set the precheck function.

This setting is saved in the NV-RAM (nonvolatile RAM) of the PG-1500 and remains unchanged after power-OFF.

The following items are set. Change by setting in accordance with the external machine to be connected.

Table 2-7. Items to be Set by MODE Command

Item	Setting	Display Symbol
Baud rate	1200 2400 4800 <u>9600</u> 19200 [bps]	BR
Parity	<u>NON</u> (none) EVN (even number) ODD (odd number)	P
XON/OFF control ^{Note 1}	<u>ON</u> (yes) OFF (none)	XN
Character length	7 <u>8</u>	B
Stop bit	1 <u>2</u>	SB
Precheck ^{Note 2}	ON (yes) <u>OE</u> (none)	PC

Notes 1. When connecting the unit to an in-circuit emulator, XON/XOFF control should be set to "none" (LCD display: OF).

2. This function checks whether the device has been inserted correctly. It can only be used with an NEC general-purpose PROM.

Remark The default settings at shipment are underlined in the Setting column.

FUNCTION**MODE**

<Operating procedure>

Key Operation

Display

Description

FUNCTION

```

SIN PIN SOUT MOD REM
FUNCTION

```

FUNCTION mode is set.

MODE

```

      Baud Rate      Parity      XON/XOFF
BR:  9600 P:NON XN:OF
MODE B:8 SB:2 PC:OF
      Character      Stop      Precheck
      Length        Bit

```

Various setting modes are selected.

Caution The parameter cannot be changed using numeric keys.

△ : Parameter Select

▽ : Parameter Setting Change

▽

```

BR:  1200 P:NON XN:OF
MODE B:8 SB:2 PC:OF

```

The parameter is changed to a desired value.
(Setting Example) 1200 bps

The parameter changes as follows with the ▽ key.

```

→ [19200] → [1200] → [2400] → [8400] → [9600] →

```

△

```

BR:  1200 P:NON XN:OF
MODE B:8 SB:2 PC:OF

```

The cursor is moved.

▽

```

BR:  1200 P:EVN XN:OF
MODE B:8 SB:2 PC:OF

```

The parameter is changed to a desired value.
(Setting Example) EVN [Even Parity]

The parameter changes as follows with the ▽ key.

```

→ [NON] → [EVN] → [ODD] →

```

△

```

BR:  1200 P:EVN XN:OF
MODE B:8 SB:2 PC:OF

```

The cursor is moved.

▽

```

BR:  1200 P:EVN XN:ON
MODE B:8 SB:2 PC:OF

```

The parameter is changed to a desired value
(Set to external equipment to be connected).
(Setting Example) ON

The parameter changes as follows with the ▽ key.


```

[OF] ↔ [ON]

```

<1>

FUNCTION MODE



- Cautions**
1. This setting is not changed unless the **SET/START** key is pressed.
 2. Pressing the **SET/START** key executes data write to the NV-RAM in the PG-1500.

FUNCTION**REMOTE****2.6.5 Remote control mode setting (REMOTE)**

The REMOTE command is intended for control the PG-1500 with an external device.

When executing the REMOTE command, connect the PG-1500 to the external device with a serial interface cable.

<Operating procedure>

Key Operation	Display	Description
FUNCTION	SIN PIN SOUT MOD REM FUNCTION	FUNCTION mode is set.
REMOTE	REMOTE MODE	REMOTE command is selected.
SET/START	REMOTE MODE OK	If the PG-1500 is connected to the external device normally, [OK] is displayed.

To terminate control by the external machine, press the **RESET** key.

For details of the REMOTE command, refer to **Chapter 3 Remote Control Mode** in **Part II**.

CHAPTER 3. REMOTE CONTROL MODE

3.1 Outline of Operation


When the PG-1500 is connected to a host machine (PC-9800 series, etc.), the remote control mode is used to control the PG-1500 from the host machine.

When the remote control mode is used, the PG-1500 controller (control software, separately available), or an in-circuit emulator (IE-75001-R, etc.) is required.

To connect the PG-1500 to an external machine, the serial interface alone, or the serial interface and the parallel interface, are used. Please refer to the relevant User's Manual for the connection and start-up procedure. An example of connection to an in-circuit emulator is given in **4.2.1 Outline of Operations Using NEC In-Circuit Emulator**.

For the operation method for the PG-1500 controller, refer to the **PG-1500 Controller User's Manual** (EEU-1291C MS-DOS based, U10540EJ PC DOS based).

Remote control mode commands are shown below.



Note These command set the below parameters at execution.

- <1> PROM start address
- <2> PROM end address
- <3> PG-1500 internal memory start address
- <4> Address division mode

3.2 Setting

An adapter board for the device used is connected to the PG-1500. When a device other than a general-purpose PROM is used, a PROM programmer adapter is connected to the adapter board.

Check the interface of the external machine used before connecting. To connect the PG-1500 to an external machine, the serial interface alone, or the serial interface and the parallel interface, are used.


After the external machine and the PG-1500 have been powered on and the initial test has been performed, perform the PG-1500 and external machine settings and start the control software, etc., then insert the device into the socket.

See the sections of **2.5 Adapter Board Connection** and **2.6 Device Insertion** in **Part I** and **Appendix C External Interfaces** in **Appendix**, and the User's Manual for the external machine, etc., for details.

3.3 START, INITIAL TEST AND MODE SETTING

When connection of the PG-1500 to the host machine is completed, power on the host machine.

When the PG-1500 power supply is turned on, the following message is displayed on the LCD and an initial test is performed (as in the standalone mode).



Caution Do not turn the power on/off with the device inserted in the socket, as this may damage it.

Use the PG-1500 keys to set to the remote control mode.

<Operating procedure>

Key Operation	Display	Description
FUNCTION	SIN PIN SOUT MOD REM FUNCTION	FUNCTION mode is set.
REMOTE	REMOTE MODE	REMOTE command is selected.
SET/START	REMOTE MODE OK	If the PG-1500 is connected to the external device correctly, [OK] is displayed.

Caution If no external devices are connected, an error results.
If the DSR and DTR external devices are set to [OFF], an error results.

To release the remote control mode, press the **RESET** key on the PG-1500.

3.4 COMMANDS

The commands for the remote control mode are described below.

RS**(ROM Select)****3.4.1 RS (ROM Select) command**

The RS command is used to select the device.

The device selection method is set by the subcommands C, R, and A.

There are three device selection methods: CODE mode (subcommand: C), READ mode (subcommand: R), and AUTO mode (subcommand: A).

In CODE mode, the code number and program mode are input when the RS command is executed, and the device write conditions are set accordingly.

In READ mode, the silicon signature data is read from the device inserted in the socket when the RS command is executed, and the device write conditions are set in accordance with this data.

In AUTO mode, the silicon signature data is read automatically each time RR, RW, RV or RZ is executed, and the device write conditions are set in accordance with this data.

See **Section 2.4.2 Device Selection (SELECT)** in **Part II** for details of the device selection methods.

<Input format>

PG > RS C 

PG > RS R 

PG > RS A 

↑
Subcommand

Subcommand	Function
C	Manual input of code number (CODE mode)
R	Manual read of silicon signature data (READ mode)
A	Automatic read of silicon signature data (AUTO mode)

An error message will be displayed if a character other than C, R, or A is input, or if subcommand input is omitted.

RS


(ROM Select)

<Execution example>

(1) Code Mode



When 27A board is used

(a) Normal execution

PG>RS C 

ROM SELECT

1004 = μ PD27256 (VPP = 21V) (N) 10A4 = μ PD27C256 (VPP = 21V) (N)
 10C4 = μ PD27256A (VPP = 12.5V) (F/N) 1064 = μ PD27C256A (VPP = 12.5V) (F/N)
 1025 = μ PD27C512 (VPP = 12.5V) (F/N) 1086 = μ PD27C1000 (VPP = 12.5V) (N)
 1016 = μ PD27C1000A (VPP = 12.5V) (P/N) 1046 = μ PD27C1001 (VPP = 12.5V) (N)
 10D6 = μ PD27C1001A (VPP = 12.5V) (P/N) 1026 = μ PD27C1024 (VPP = 12.5V) (N)
 10B6 = μ PD27C1024A (VPP = 12.5V) (P/N) 10C7 = μ PD27C2001 (VPP = 12.5V) (P/N)
 10C8 = μ PD27C4001 (VPP = 12.5V) (N) 10A8 = μ PD27C4096 (VPP = 12.5V) (N)

Please input code No. = 10C4 Please input program mode (Page/Fast/Normal) = F 

PG>


RS**(ROM Select)**

(b) Error (when an item other than code numbers is input)

PG>RS C 


ROM SELECT

1004 = μ PD27256 (VPP = 21V) (N) 10A4 = μ PD27C256 (VPP = 21V) (N)
 10C4 = μ PD27256A (VPP = 12.5V) (F/N) 1064 = μ PD27C256A (VPP = 12.5V) (F/N)
 1025 = μ PD27C512 (VPP = 12.5V) (F/N) 1086 = μ PD27C1000 (VPP = 12.5V) (N)
 1016 = μ PD27C1000A (VPP = 12.5V) (P/N) 1046 = μ PD27C1001 (VPP = 12.5V) (N)
 10D6 = μ PD27C1001A (VPP = 12.5V) (P/N) 1026 = μ PD27C1024 (VPP = 12.5V) (N)
 10B6 = μ PD27C1024A (VPP = 12.5V) (P/N) 10C7 = μ PD27C2001 (VPP = 12.5V) (P/N)
 10C8 = μ PD27C4001 (VPP = 12.5V) (N) 10A8 = μ PD27C4096 (VPP = 12.5V) (N)

Please input code No. = 5555 

ROM SELECT

1004 = μ PD27256 (VPP = 21V) (N) 10A4 = μ PD27C256 (VPP = 21V) (N)
 10C4 = μ PD27256A (VPP = 12.5V) (F/N) 1064 = μ PD27C256A (VPP = 12.5V) (F/N)
 1025 = μ PD27C512 (VPP = 12.5V) (F/N) 1086 = μ PD27C1000 (VPP = 12.5V) (N)
 1016 = μ PD27C1000A (VPP = 12.5V) (P/N) 1046 = μ PD27C1001 (VPP = 12.5V) (N)
 10D6 = μ PD27C1001A (VPP = 12.5V) (P/N) 1026 = μ PD27C1024 (VPP = 12.5V) (N)
 10B6 = μ PD27C1024A (VPP = 12.5V) (P/N) 10C7 = μ PD27C2001 (VPP = 12.5V) (P/N)
 10C8 = μ PD27C4001 (VPP = 12.5V) (N) 10A8 = μ PD27C4096 (VPP = 12.5V) (N)

Please input code No. = 


PG>

If a number not displayed is input, the message is displayed again.

Press the RETURN key to exit from the CODE mode.

When 04A board is used

CODE mode cannot be used. The following error message is displayed.

PG>RS C 

ERR39(Board not connected)

PG> 


RS

(ROM Select)

(2) READ mode

(a) Normal execution (μ PD75P108)PG>RS R Your setting ROM is μ PD75P108PG> 


(b) Error

PG>RS R 

ERR30 (Signature read error)


PG> 

(3) AUTO mode (only for SELECT mode setting)

PG>RS A PG> 

<Error control>

<1> When a command other than the specified subcommand is input

PG>RS F 

ERR16 (Command syntax error)

PG>  When the preset device silicon signature data cannot be read.PG>RS R 

ERR30 (Signature read error)

PG> 

RS**(ROM Zero check)****3.4.2 RZ (ROM Zero check) command**



The RZ command is intended to check if the device inserted into the socket is unwritten.

<Input format>

PG > RZ 


<Execution example>

(1) Upon normal termination

PG>RZ 
 ROM erase OK!
 PG> 

★

(2) When device has not been written

PG>RZ 
 ERR28 ROM not erased !!
 Adr ROM data
 00000 FE
 Continue(Y:Yes/N:No)?

↑

"Continue (Y:Yes/N:No)?" message is displayed.

If "Continue (Y:Yes/N:No)?" message is displayed during execution, input Y or N.

If Y is input, blank check is done again at the address following the displayed address.

If N is input, blank check is stopped.

If a character other than Y or N is input, message is displayed again.

RS

(ROM Zero check)

<1> Y input

- (a) When device is unwritten in check after re-execution

```
Continue(Y:Yes/N:No)?Y
ROM erase OK!

PG> █
```

Caution "OK" is displayed, but this is not a normal termination.

- (b) When device is not unwritten in erase status check after re-execution

```
Continue(Y:Yes/N:No)?Y
ERR28 ROM not erased !!

  Adr      ROM data
00001      FD

Continue(Y:Yes/N:No)?
```

The message is displayed again.

<2> N Input

```
Continue(Y:Yes/N:No)?N

PG> █
```

The instruction is stopped.

<3> Input other than Y and N

```
Continue(Y:Yes/N:No)?G
Continue(Y:Yes/N:No)?
```


The message is displayed again.

RS

(ROM Zero check)

<Error control>


<1> When symbol is input after RZ

PG>RZ 0,1FFF 

ERR16(Command syntax error)

PG> 


<2> When silicon signature data cannot be read

PG>RZ 

ERR30(Signature read error)

PG> 


<3> When the read silicon signature data differs from the preset data

PG>RZ 

ERR31(Unexpected Signature)

PG> 


<4> When undefined data is read in silicon signature data read

PG>RZ 

ERR32(Undefined Signature)

PG> 

<5> When the device insert direction is inverted (this occurs only when general-purpose PROM precheck is ON)

PG>RZ 

ERR38(Device insert error)

PG> 

RS

RW

RV

(ROM Read) (ROM Write) (ROM Verify)

★

3.4.3 RR/RW/RV Command input format

<Input format>

PG>Rx ROM_S_ADR, ROM_E_ADR, PG_S_ADR, CONV

<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>
Command	PROM start address	PROM end address	PG-1500 internal memory start address	Address divide mode

Remark x: R/W/V

<Input example>

In the case of any PR command of the following addresses:

PROM start address : 0000H


PROM end address : FFFFH

PG start address : 0000H

↓

PG>RR 0, FFFF, 0, BE

The symbols used for command description have the following meanings.

Symbol	Meaning	Remark
ROM_S_ADR	PROM start address	Input 5-digit hexadecimal number. If 4 digits or less are input, 0 is set to the highest digit. If 6 digits or more, an error results.
ROM_E_ADR	PROM end address	
PG_S_ADR	PG-1500 internal start address	
PG_E_ADR	PG-1500 internal end address	
CONV	Address division mode ^{Note} . The following modes are available: N Normal (No address divide) BE 16-bit data 2-divide even address specification BO 16-bit data 2-divide odd address specification WE 32-bit data 2-divide even address specification WO 32-bit data 2-divide odd address specification 0 32-bit data 4-divide 0-block specification 1 32-bit data 4-divide 1-block specification 2 32-bit data 4-divide 2-block specification 3 32-bit data 4-divide 3-block specification	Inputs other than those listed on the left result in an error.
	RETURN Key Input	
<u> </u> (Underlined portion)	Indicates input from keyboard	

Note For device types and specifiable address division modes, see **Table 2-3 Specifiable Address Divide Mode** in **Part II**.

RS**RW****RV****(ROM Read) (ROM Write) (ROM Verify)**

<Abbreviation format>

After inputting commands, the format can be abbreviated for the following parameter conditions. The abbreviated format is described below.

Abbreviated format	Setting condition			
	PROM start address	PROM end address	PG start address	Divide mode
Rx ROM_S_ADR, ROM_E_ADR, PG_S_ADR, CONV	Address input	Address input	Address input	Input
Rx ROM_S_ADR, ROM_E_ADR, PG_S_ADR,	Address input	Address input	Address input	N
Rx ROM_S_ADR, ROM_E_ADR, PG_S_ADR	Address input	Address input	Address input	N
Rx ROM_S_ADR, ROM_E_ADR,, CONV	Address input	Address input	0	Input
Rx ROM_S_ADR, ROM_E_ADR,,	Address input	Address input	0	N
Rx ROM_S_ADR, ROM_E_ADR	Address input	Address input	0	N
Rx ROM_S_ADR,, PG_S_ADR, CONV	Address input	0	Address input	Input
Rx ROM_S_ADR,, PG_S_ADR,	Address input	0	Address input	N
Rx ROM_S_ADR,, PG_S_ADR	Address input	0	Address input	N
Rx ROM_S_ADR,,, CONV	Address input	0	0	Input
Rx ROM_S_ADR,,,	Address input	0	0	N
Rx ROM_S_ADR,,	Address input	0	0	N
Rx ROM_S_ADR,	Address input	0	0	N
Rx ROM-S_ADR	Address input	0	0	N
Rx ROM_E_ADR, PG_S_ADR, CONV	0	Address input	Address input	Input
Rx , ROM_E_ADR, PG_S_ADR,	0	Address input	Address input	N
Rx , ROM_E_ADR, PG_S_ADR	0	Address input	Address input	N
Rx , ROM_E_ADR,, CONV	0	Address input	0	Input
Rx , ROM_E_ADR,,	0	Address input	0	N
Rx , ROM_E_ADR	0	Address input	0	N
Rx ,, PG_S_ADR, CONV	0	0	Address input	Input
Rx ,, PG_S_ADR,	0	0	Address input	N
Rx ,, PG_S_ADR	0	0	Address input	N
Rx,,, CONV	0	0	0	Input
Rx,,,	0	0	0	N
Rx,,	0	0	0	N
Rx,	0	0	0	N
Rx	0	Preset ROM_E_ADR ^{Note2}	0	N

Note 1

Note 1

Note 1

Note 1

Note 1

Note 1

Note 1

Note 1

Note 1

Notes 1. Because of ROM_S_ADR > ROM_E_ADR, error results.

2. Preselected ROM end address in the CODE mode.

3. ROM end address set by the silicon signature data that was read previously in the READ mode.

4. ROM end address set by the silicon signature data that is read in the AUTO mode.

Remark x: R/W/V

RR**(ROM Read)**

3.4.4 RR (ROM Read) command


The RR command is used to read the specified range of data from the device inserted in the socket into PG-1500 internal memory, allocating the data at the specified start address. After the addresses have been read, verification is performed on all the addresses automatically.

<Execution example>

When

ROM_S_ADR = 00H
ROM_E_ADR = FFFFH
PG_S_ADR = 00H

(1) Upon normal termination (CONV: BE)

```
PG>RR 0,FFFF,0,BE 
```

```
Now , data reading !
```

```
Data complete
```


```
Check sum : 2BC8
```

```
PG> 
```

RR**(ROM Read)**

(2) If an error occurs in verify operation, the display is made as follows.

(a) When using 8-bits data length ROM


```
PG>RR 0,FFFF,0,W0 

Now , data reading !
ERR20 Data not completed !!

  Adr          ROM data    RAM data
00000          FFFF       FF00

Continue(Y:Yes/N:No)?
```

(b) When using 16-bits data length ROM

```
PG>RR 0,FFFF,0,N 

Now , data reading !
ERR20 Data not completed !!

  Adr          ROM data    RAM data
00000          FF         00

Continue(Y:Yes/N:No)?
```

↑

"Continue(Y:Yes/N:No)?" message is displayed.

- (3) If [Continue (Y:Yes/N:No)?] message is displayed during execution, input Y or N.
 If Y is input, verify is done again at the address following the displayed address.
 If N is input, verify is stopped.
 If a character other than Y or N is input, message is displayed again.

RR

(ROM Read)

<1> Y input

(a) When compare data is the same after re-execution

```
Continue(Y:Yes/N:No)?Y
Data complete
Check sum : 7D6F

PG> ■
```

(b) When compare data differs after re-execution

```
Continue(Y:Yes/N:No)?Y
ERR20 Data not completed !!

  Adr          ROM data      RAM data
00010          FF           00

Continue(Y:Yes/N:No)?
```

The message is displayed again.

<2> N input

```
Continue(Y:Yes/N:No)?N

PG> ■
```

The instruction is stopped.

<3> Input other than Y and N



```
Continue(Y:Yes/N:No)?G
Continue(Y:Yes/N:No)?
```

The message is displayed again.

RR**(ROM Read)**



<Error control>

<1> When PROM start address is larger than PROM end address
(ROM_S_ADR>ROM_E_ADR)

```
PG>RR 100,00,0,BE 
ERR10(START_ADR>END_ADR)
PG> 
```



<2> When PROM end address is larger than PROM size
(ROM_E_ADR>ROM SIZE)

Example: When 75P108 is used (ROM end address = 1FFFH)

```
PG>RR 2000,3FFF,0,N 
Now, data reading!
ERR11(ROM_S_ADR OR ROM_E_ADR > ROM SIZE)
PG> 
```

<3> When the device inserted into the socket cannot be operated by the selected address divide mode



Example When 8-bit specification is made with a data length 16-bits PROM selected

```
PG>RR 0,1FFF,0,BE 
Now, data reading!
ERR13(Conversion error)
PG> 
```



RR

(ROM Read)



<4> When a symbol not in hexadecimal notation is used

```
PG>RR 0,G,0,WE   
  
ERR14(Illegal character)  
  
PG> 
```



<5> When an inappropriate symbol is used for address divide mode specification

```
PG>RR 0,1FFF,0,R   
  
ERR15(Illegal conversion)  
  
PG> 
```

<6> When silicon signature data cannot be read



```
PG>RR 0,FF,0,BE   
  
ERR30(Signature read error)  
  
PG> 
```

<7> When the read silicon signature differs from the preset data



```
PG>RR 0,FF,0,N   
  
Now , data reading !  
  
ERR31(Unexpected Signature)  
  
PG> 
```

RR**(ROM Read)**

<8> When undefined data is read in silicon signature data read

```
PG>RR 0,FF,0,WE   
  
Now , data reading !  
  
ERR32(Undefined Signature)  
  
PG> 
```

<9> When the device insert direction is inverted (this occurs only when general-purpose μ PD27xxx system precheck is ON)

```
PG>RR 0,3FFF,0,N   
  
Now , data reading !  
  
ERR38(Device insert error)  
  
PG> 
```

RW**(ROM Write)****3.4.5 RW (ROM Write) command**

The RW command is intended to write the PG-1500 internal memory data allocated at the specified start address to the unwritten device inserted in the socket, allocating the data to the specified range. Writing (including verification) is performed in accordance with the program mode specified when the RS command is executed.

<Execution example>

When

ROM_S_ADDR=00H ROM_E_ADDR=FFFFH PG_S_ADR=00H
--

(1) Upon normal termination

```
PG>RW 0,FFFF,0,BE 
```


```
Now , data writing !
```

```
Data complete
```

```
Check sum : 2BC8
```

```
PG> 
```

(2) If an error occurs in write operation

```
PG>RW 0,FFFF,0,W0 
```

```
Now , data writing !
```

```
ERR2C Write error !!
```

```
Adr          ROM data
```

```
00010        FE
```

```
Continue(Y:Yes/N:No)?
```

RW**(ROM Write)****(3) If an error occurs in verify operation****(a) When using data length 8-bits ROM**PG>RW 0,FFFF,0,N 

Now , data writing !

ERR22 Data not completed !!

Adr	ROM data	RAM data
00000	FF	00

Continue(Y:Yes/N:No)?

(b) When using data length 16-bits ROMPG>RW 0,FFFF,0,WE 

Now , data writing !

ERR22 Data not completed !!

Adr	ROM data	RAM data
00000	FFFF	FF00

Continue(Y:Yes/N:No)?

↑

"Continue(Y:Yes/N:No)?" message is displayed.

RW

(ROM Write)

If [Continue (Y:Yes/N:No)?] message is displayed during execution, input Y or N.

If Y is input, write is done again at the address following the displayed address.

If N is input, write is stopped.

If a character other than Y or N is input, message is displayed again.

<1> Y input

(a) When compare data is the same after re-execution

Continue(Y:Yes/N:No)?Y

Data complete

Check sum : FFFF

PG> ■

(b) When compare data differs after re-execution

When using data length 8-bits ROM

Continue(Y:Yes/N:No)?Y

ERR20 Data not completed !!

Adr	ROM data	RAM data
00010	FF	00

Continue(Y:Yes/N:No)?

When using data length 16-bits ROM

Continue(Y:Yes/N:No)?Y

ERR20 Data not completed !!

Adr	ROM data	RAM data
00010	FFFF	FF00

Continue(Y:Yes/N:No)?

The message is displayed again.

RW**(ROM Write)**

<2> N input

Continue(Y:Yes/N:No)?N

PG> ■

The instruction is stopped.

<3> Input other than Y and N

Continue(Y:Yes/N:No)?G



Continue(Y:Yes/N:No)?

The message is displayed again.



RW**(ROM Write)**

<Error control>

- <1> When PROM start address is larger than PROM end address
(ROM_S_ADR>ROM_E_ADR)



```
PG>RW 100,0,0,BE   
  
ERR10 (START_ADR>END_ADR)  
  
PG> 
```

- <2> When a symbol not in hexadecimal notation is used



```
PG>RW 0,G,0,WE   
  
ERR14 (Illegal character)  
  
PG> 
```

- <3> When PROM end address is larger than PROM size
(ROM_E_ADR>ROM SIZE)

Example: When μ PD75P108 is used (ROM end address = 1FFFH)


```
PG>RW 0,2000,0,N   
  
Now , data writing !  
  
ERR11 (ROM_S_ADR OR ROM_E_ADR > ROM SIZE)  
  
PG> 
```

- <4> When an inappropriate symbol is used for address divide mode specification

```
PG>RW 0,1FFF,0,R   
  
ERR15 (Illegal conversion)  
  
PG> 
```

RW**(ROM Write)**

<5> When silicon signature data cannot be read

PG>RW 0,FF,0,BE 

ERR30(Signature read error)

PG> 

<6> When the read silicon signature data differs from the preset data


PG>RW 0,FF,0,N 

Now , data writing !

ERR31(Unexpected Signature)

PG> 

<7> When undefined data is read in silicon signature data read


PG>RW 0,FF,0,WE 

Now , data writing !

ERR32(Undefined Signature)

PG> 

<8> When the device insert direction is inverted (this occurs only when general-purpose PROM precheck is ON)

PG>RW 0,3FFF,0,N 

Now , data writing !

ERR38(Device insert error)

PG> 

RV**(ROM Verify)**

3.4.6 RV (ROM Verify) command


The RV command compares the data in the device inserted in the socket with the PG-1500 internal memory data. It should be executed after execution of the RR or RW command.

<Execution example>

When

ROM_S_ADR=00H ROM_E_ADR=1FFFH PG_S_ADR=00H
--

(1) Upon normal termination

```
PG>RV 0,1FFF,0,N 
```

```
Now , data reading !
```

```
Data complete
```

```
Check sum : 2BC8
```

```
PG> 
```

RV**(ROM Verify)****(2) If an error occurs in verify operation****(a) When using data length 8-bits ROM**

```
PG>RV 0,FFFF,0,N
```

```
Now , data reading !
```

```
ERR22 Data not completed !!
```

Adr	ROM data	RAM data
00000	FF	00

```
Continue(Y:Yes/N:No)?
```

(b) When using data length 16-bits ROM

```
PG>RV 0,FFFF,0,N
```

```
Now , data reading !
```

```
ERR22 Data not completed !!
```

Adr	ROM data	RAM data
00000	FFFF	FF00

```
Continue(Y:Yes/N:No)?
```

↑

"Continue(Y:Yes/N:No)?" message is displayed.

If [Continue (Y:Yes/N:No)?] message is displayed during execution, input Y or N.

If Y is input, verify is done again at the address following the displayed address.

If N is input, verify is stopped.

If a character other than Y or N is input, message is displayed again.

RV

(ROM Verify)

<1> Y input

(a) When compare data is the same after re-execution

Continue(Y:Yes/N:No)?Y

Data complete

Check sum : FFFF

PG> ■

(b) When compare data differs after re-execution

When using data length 8-bits ROM

Continue(Y:Yes/N:No)?Y

ERR22 Data not completed !!

Adr	ROM data	RAM data
00010	FF	00

Continue(Y:Yes/N:No)?

When using data length 8-bits ROM

Continue(Y:Yes/N:No)?Y

ERR22 Data not completed !!

Adr	ROM data	RAM data
00010	FFFF	FF00

Continue(Y:Yes/N:No)?

The message is displayed again.

RV**(ROM Verify)**

<2> N input

Continue(Y:Yes/N:No)?N

PG> ■

The instruction is stopped.

<3> Input other than Y and N

Continue(Y:Yes/N:No)?G

Continue(Y:Yes/N:No)?



The message is displayed again.

RV



(ROM Verify)

<Error control>

- <1> When PROM start address is larger than PROM end address
(ROM_S_ADR>ROM_E_ADR)



```
PG>RV 100,0,0,BE 
ERR10(START_ADR>END_ADR)
PG> 
```

- <2> When a symbol not in hexadecimal notation is used



```
PG>RV 0,G,0,WE 
ERR14(Illegal character)
PG> 
```

- <3> When PROM end address is larger than PROM size
(ROM_E_ADR>ROM SIZE)

Example When 75P108 is used (ROM end address = 1FFFFH)



```
PG>RV 0,2000,0,N 
Now , data reading !
ERR11(ROM_S_ADR OR ROM_E_ADR > ROM SIZE)
PG> 
```

- <4> When an inappropriate symbol is used for address divide mode specification



```
PG>RV 0,1FFF,0,R 
ERR15(Illegal conversion)
PG> 
```

RV**(ROM Verify)**



<5> When silicon signature data cannot be read

```
PG>RV 0,FF,0,BE   
  
ERR30(Signature read error)  
  
PG> 
```



<6> When the read silicon signature data differs from the preset data

```
PG>RV 0,FF,0,N   
  
Now , data reading !  
  
ERR31(Unexpected Signature)  
  
PG> 
```

<7> When undefined data is read in silicon signature data read

```
PG>RV 0,FF,0,WE   
  
Now , data reading !  
  
ERR32(Undefined Signature)  
  
PG> 
```

<8> When the device insert direction is inverted (this occurs only when general-purpose PROM precheck is ON)

```
PG>RV 0,3FFF,0,N   
  
Now , data reading !  
  
ERR38(Device insert error)  
  
PG> 
```


MC

(Memory Change)

3.4.7 MC (Memory change) command

The MC command is used to change the PG-1500 internal memory data.


<Input format>

PG>MC PG_S_ADR 

PA_S_ADR: PG-1500 internal memory start address

<Execution example>

[PG_S_ADR=100H]

PG>MC 100 


00100 FF-


The following can be input in this status.

Input	Function
Hexadecimal 2-digit data	Data change
Space key	Display shifts to the next address data without data change
RETURN key	End of data change

<1> When data is changed


(Data at address 100H is changed to 00 and data at address 101H is changed to 01)


PG>MC 100 

00100 FF-00 FF-01 

PG> 

<2> When data is not changed

PG>MC 100 

00100 FF-FF FF-FF FF- 

PG> 

MC**(Memory Change)**



<Abbreviated format>

When a command is used, an abbreviated input format can be used for the following setting.



Input	PG_S_ADR
MC PG_S_ADR	Address input
MC	0

<Error control>

<1> When a symbol not in hexadecimal notation is input

```
PG>MC 000H 
ERR14(Illegal character)
PG> 
```

<2> When the PG-1500 internal memory start address is larger than the PG-1500 internal memory size (PG_S_ADR>PG_BUFF_SIZE)

```
PG>MC FFFFF 
ERR12(PG_BUFF_SIZE over)
PG> 
```

MD**(Memory Dump)**

3.4.8 MD (Memory dump) command

The MD command is used to display data in the range specified within the PG-1500 internal memory.

<Input format>

PG>MD PG_S_ADR, PG_E_ADR 

PG_S_ADR: PG-1500 internal memory start address


PG_E_ADR: PG-1500 internal memory end address

The following key inputs are valid during data display after instruction execution.

Input key	Function
CTRL-S	Display suspend
CTRL-Q	Display resume
Space key	Display stop
CTRL-C	Display stop

MD**(Memory Dump)**

<Execution example>

When $\begin{bmatrix} \text{PG_S_ADR}=00\text{H} \\ \text{PG_E_ADR}=\text{FFH} \end{bmatrix}$ PG>MD 0,FF 

```

PG A +0 +1 +2 +3 +4 +5 +6 +7 +8 +9 +A +B +C +D +E +F
00000 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00010 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00020 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00030 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00050 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00090 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000A0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000B0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000C0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000D0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000E0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000F0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

```

PG> 

<Abbreviated format>

When a command is input, an abbreviated input format can be used for the following setting.

Input Format	PG_S_ADR	PG_E_ADR
MD PG_S_ADR, PG_E_ADR	Address input	Address input
MD, PG_E_ADR	0	Address input
MD PG_S_ADR,	Address input	0
MD PG_S_ADR	Address input	Address input + 0FFH
MD,	0	0
MD	0	0FFH



Note

Note Because PG_S_ADR>PG_E_ADR, an error results.



MD**(Memory Dump)**

<Error control>



<1> When the PG-1500 internal memory start address is larger than the end address
(PG_S_ADR>PG_E_ADR)

```
PG>MD 100,0   
  
ERR10(START_ADR>END_ADR)  
  
PG> 
```

<2> When the PG-1500 internal memory end address is larger than the PG-1500 internal memory size
(PG_E_ADR>PG_BUFF_SIZE)

```
PG>MD 0,FFFFF   
  
ERR12(PG_BUFF_SIZE over)  
  
PG> 
```

<3> When a symbol not in hexadecimal notation is input

```
PG>MD 0,G   
  
ERR14(Illegal character)  
  
PG> 
```

MF**(Memory Fill)****3.4.9 MF (Memory fill) command**

The MF command is used to initialize the PG-1500 internal memory contents with the specified data.

The specified range can be initialized.

<Input format>

```
PG>MF PG_S_ADR, PG_E_ADR, INT_DATA ↵
```

PG_S_ADR: PG-1500 internal memory start address

PG_E_ADR: PG-1500 internal memory end address

INT_DATA : Initialize data

<Execution example>

When $\left[\begin{array}{l} \text{PG_S_ADR}=00\text{H} \\ \text{PG_E_ADR}=\text{FFFFH} \\ \text{INT_DATA}=\text{FFH} \end{array} \right]$

```
PG>MF 0,FFFF,FF ↵
```

```
PG> ■
```

<Abbreviated format>

When a command is input, an abbreviated input format can be used for the following setting.

Input	PG_S_ADR	PG_E_ADR	INT_DATA
MF PG_S_ADR, PG_E_ADR, INT_DATA	Address input	Address input	Data input
MF PG_S_ADR, PG_E_ADR,	Input format error ERROR (Command syntax)		
MF PG_S_ADR,, INT_DATA	Address input	0	Data input
MF PG_S_ADR,,	Input format error ERROR (Command syntax)		
MF PG_S_ADR,	Input format error ERROR (Command syntax)		
MF PG_S_ADR	Input format error ERROR (Command syntax)		
MF , PG_E_ADR, INT_DATA	0	Address input	Data input
MF , PG_E_ADR,	Input format error ERROR (Command syntax)		
MF , PG_E_ADR	Input format error ERROR (Command syntax)		
MF ,, INT_DATA	0	0	Data input
MF ,,	Input format error ERROR (Command syntax)		
MF ,	Input format error ERROR (Command syntax)		
MF	Input format error ERROR (Command syntax)		

Note

Note Because PG_S_ADR>PG_E_ADR, an error results.

MF**(Memory Fill)**

<Error control>

- <1> When the PG-1500 internal memory start address is larger than the end address
(PG_S_ADR>PG_E_ADR)

```
PG>MF 1FFF,1FFE,0
```

```
ERR10 (START_ADR>END ADR)
```

```
PG> 
```

- <2> When the PG-1500 internal memory end address is larger than the PG-1500 internal memory size
(PG_E_ADR>PG_BUFF_SIZE)

```
PG>MF 0,FFFFFF,FF
```

```
ERR12 (PG BUFF SIZE over)
```

```
PG> 
```

- <3> When a symbol not in hexadecimal notation is input

```
PG>MF 0,GG,RR
```

```
ERR14 (Illegal character)
```

```
PG> 
```

PI**(Parallel Intel)****3.4.10 PI (Parallel Intel) command**

The PI command is used to input parallel data in the INTELLEC HEX format.


When executing the PI command, the PG-1500 should be connected to the external machine by a parallel interface cable.

<Input format>

PG>PI 


<Execution example>

Data file name: TEST.HEX

PG>PI 

A>COPY TEST.HEX prn

one file was copied.

A> 

PG>PI is displayed and the PG-1500 is set to the parallel input status.

Exit from the terminal mode is marked by the dotted frame.

The procedure to exit from the terminal mode differs depending on the type of external device.


PM**(Parallel Motorola)**

3.4.11 PM (Parallel Motorola) command

The PM command is used to input parallel data in the MOTOROLA EXORCISER format.


When executing the PM command, the PG-1500 should be connected to the external machine by a parallel interface cable.


<Input format>

PG>PM 


<Execution example>

Data file name: TEST.HEX

PG>PM 



A>COPY TEST.HEX prn
one file was copied.

A> 

PG>PM is displayed and the PG-1500 is set to the parallel input status.

Exit from the terminal mode is marked by the dotted frame.

The procedure to exit from the terminal mode differs depending on the type of external device.

(Parallel TEK)

The PT command is used to input parallel data in the EXTENDED TEKHEX format.

<Input format>

<Execution example>

PG>PT

A> [REDACTED]

Exit from the terminal mode is marked by the dotted frame.

124

LI

(Load Intel)

3.4.13 LI (Load Intel) command

The LI command is used to input serial data in the INTELLEC HEX format.

This command transfers to the PG-1500 internal memory the data inside the memory of the NEC in-circuit emulator.

<Input format>

PG>LI

<Execution example>

When transferring the IE-75000-R contents at addresses 00H to FFH to the PG-1500

brk:0>PGM

PG>LI

partition=0,FF

PG>

<Error control>

<1> When a parameter is attached after LI

PG>LI 0,1FFF

ERR16(Command syntax error)

PG>

<2> When serial is disconnected

PG>LI

ERR40(Serial not ready)

PG>

Caution The LI command uses a simplified protocol as the communication procedure.

Thus, communication with a personal computer cannot be carried out using the LI command.

LM**(Load Motorola)****3.4.14 LM (Load Motorola) command**

The LM command is used to input serial data in the MOTOROLA EXORCISER format.

- ★ This command transfers to the PG-1500 internal memory the data inside the memory of the NEC in-circuit emulator.

<Input format>

```
PG>LM ↵
```

<Error control>

<1> When a parameter is attached after LM

```
PG>LM 0,1FFF ↵
```

```
ERR16(Command syntax error)
```

```
PG> ■
```

<2> When serial is disconnected

```
PG>LM ↵
```

```
ERR40(Serial not ready)
```

```
PG> ■
```

Cautions 1. The LM command uses a simplified protocol as the communication procedure.
Thus, communication with a personal computer cannot be carried out using the LM command.

- ★ 2. The MOTOROLA EXORCISER format is not supported in some in-circuit emulators.

LT

(Load TEK)

3.4.15 LT (Load TEK) command

The LT command is used to input serial data in EXTENDED TEKHEX format.


This command transfers to the PG-1500 internal memory the data inside the memory of the NEC in-circuit emulator.

<Input format>

PG>LT 

<Error control>


<1> When a parameter is attached after LT

PG>LT 0,1FFF 

ERR16(Command syntax error)

PG> 

<2> When serial is disconnected

PG>LT 

ERR40(Serial not ready)

PG> 

- Cautions**
1. The LT command uses a simplified protocol as the communication procedure.
Thus, communication with a personal computer cannot be carried out using the LT command.
 2. The EXTENDED TEKHEX format is not supported in some in-circuit emulators.

SI**(Serial Intel)****3.4.16 SI (Serial Intel) command**

- ★ The SI command is used to serially transfer the data within the specified range of the PG-1500 internal memory to the memory of the NEC in-circuit emulator in the INTELLEC HEX format.

<Input format>

PG>SI PG_S_ADR, PG_E_ADR ↵

PG_S_ADR: PG-1500 internal memory start address

PG_E_ADR: PG-1500 internal memory end address

<Execution example>

When $\left[\begin{array}{l} \text{PG_S_ADR}=00\text{H} \\ \text{PG_E_ADR}=\text{FFH} \end{array} \right]$

PG>SI 0,FF ↵

PG> ■

<Abbreviated format>

When a command is used, an abbreviated input format can be used for the following setting.

Input Format	PG_S_ADR	PG_E_ADR
SI PG_S_ADR, PG_E_ADR	Address input	Address input
SI, PG_E_ADR	0	Address input
SI PG_S_ADR,	Address input	0
SI PG_S_ADR	Address input	Address input + 0FFH
SI,	0	0
SI	0	FFH

Note

Note Because PG_S_ADR>PG_E_ADR, an error results.

SI

(Serial Intel)

<Error control>

- <1> When the PG-1500 internal memory start address is larger than the end address
(PG_S_ADR>PG_E_ADR)

```
PG>SI 100,0  
  
ERR10 (START_ADR>END_ADR)  
  
PG> ■
```

- <2> When the PG-1500 internal memory end address is larger than the PG-1500 internal memory size
(PG_E_ADR>PG_BUFF_SIZE)

```
PG>SI 0,FFFF  
  
ERR12 (PG_BUFF_SIZE over)  
  
PG> ■
```

- <3> When a symbol not in hexadecimal notation is input

```
PG>SI 0,G  
  
ERR14 (Illegal character)  
  
PG> ■
```

Caution The SI command uses a simplified protocol as the communication procedure.
Thus, communication with a personal computer cannot be carried out using the SI command.

SM**(Serial Motorola)****3.4.17 SM (Serial Motorola) command**

- ★ The SM command is intended to serially transfer the data within the specified range of the PG-1500 internal memory to the memory of the NEC in-circuit emulator in the MOTOROLA EXORCISER format.

<Input format>

```
PG>SM PG_S_ADR, PG_E_ADR
```

PG_S_ADR: PG-1500 internal memory start address

PG_E_ADR: PG-1500 internal memory end address

<Execution example>

When $\begin{cases} \text{PG_S_ADR}=00\text{H} \\ \text{PG_E_ADR}=\text{FFH} \end{cases}$

```
PG>SM 0,FF
```

```
PG>
```

<Error control>

- <1> When the PG-1500 internal memory start address is larger than the end address
(PG_S_ADR>PG_E_ADR)

```
PG>SM 100,0
```

```
ERR10 (START_ADR>END_ADR)
```

```
PG>
```

- <2> When the PG-1500 internal memory end address is larger than the PG-1500 internal memory size
(PG_E_ADR>PG_BUFF_SIZE)

```
PG>SM 0,FFFFFF
```

```
ERR12 (PG_BUFF_SIZE over)
```

```
PG>
```

SM

(Serial Motorola)

<3> When a symbol not in hexadecimal notation is input

```
PG>SM 0,G
ERR14(Illegal character)

PG>
```

- Cautions**
1. The SM command uses a simplified protocol as the communication procedure. Thus, communication with a personal computer cannot be carried out using the SM command.
 2. The MOTOROLA EXORCISER format is not supported in some in-circuit emulators.

<Abbreviated format>

When a command is used, an abbreviated input format can be used for the following setting.

Input Format	PG_S_ADR	PG_E_ADR
SM PG_S_ADR, PG_E_ADR	Data input	Data input
SM, PG_E_ADR	0	Data input
SM PG_S_ADR,	Data input	0
SM PG_S_ADR	Data input	Data input + 0FFH
SM,	0	0
SM	0	FFH

Note

Note Because PG_S_ADR > PG_E_ADR, an error results.

ST**(Serial TEK)****3.4.18 ST (Serial TEK) command**

- ★ The ST command is used to serially transfer the data within the specified range of the PG-1500 internal memory to the memory of the NEC in-circuit emulator in the EXTENDED TEKHEX format.

<Input format>

```
PG>ST PG_S_ADR, PG_E_ADR [Enter]
```

PG_S_ADR: PG-1500 internal memory start address

PG_E_ADR: PG-1500 internal memory end address

<Execution example>

When $\begin{bmatrix} \text{PG_S_ADR}=00\text{H} \\ \text{PG_E_ADR}=\text{FFH} \end{bmatrix}$

```
PG>ST 0, FF [Enter]
```

```
PG> [Cursor]
```

<Abbreviated format>

When a command is used, an abbreviated input format can be used for the following setting.

Input Format	PG_S_ADR	PG_E_ADR
ST PG_S_ADR, PG_E_ADR	Address input	Address input
ST, PG_E_ADR	0	Address input
ST PG_S_ADR,	Address input	0
ST PG_S_ADR	Address input	Address input + 0FFH
ST,	0	0
ST	0	FFH

Note

Note Because PG_S_ADR>PG_E_ADR, an error results.

<Error control>

- <1> When the PG-1500 internal memory start address is larger than the end address (PG_S_ADR>PG_E_ADR)

```
PG>ST 100, 0 [Enter]
```



```
ERR10 (START_ADR>END_ADR)
```

```
PG> [Cursor]
```



ST

(Serial TEK)

- <2> When the PG-1500 internal memory end address is larger than the PG-1500 internal memory size (PG_E_ADR>PG_BUFF_SIZE)

```
PG>ST 0,FFFFFF   
  
ERR12 (PG_BUFF_SIZE over)  
  
PG> 
```

- <3> When a symbol not in hexadecimal notation is input

```
PG>ST 0,G   
  
ERR14 (Illegal character)  
  
PG> 
```


- Cautions**
1. The ST command uses a simplified protocol as the communication procedure. Thus, communication with a personal computer cannot be carried out using the ST command.
 2. The EXTENDED TEKHEX format is not supported in some in-circuit emulators.

★


??**(Help)****3.4.19 ?? (Help) command**

The ?? command is intended to display the types of instructions and their input methods in the remote control mode.

<Input format>

PG>?? 

<Execution example>

PG>?? 

1. RR rom_st, rom_end, pg_st, conv
2. RS[C R A]
3. RV rom_st, rom_end, pg_st, conv
4. RW rom_st, rom_end, pg_st, conv
5. RZ
6. MC pg_st
7. MD pg_st, pg_end
8. MF pg_st, pg_end, init_data
9. PI {PM, PT}
10. LI {LM, LT}
11. SI pg_st, pg_end {SM, ST}

```
conv      :N,BE,B0,WE,W0,0,1,2,3
rom_st    :0-7FFFF
rom_end   :0-7FFFF
pg_st     :0-7FFFF
init_data :0-FF
```

CHAPTER 4. SIMPLE OPERATION EXAMPLES

The following operation procedures in standalone mode and remote control mode are shown in this chapter.

4.1 Standalone Mode

4.1.1 Data Read from Master ROM to PG-1500 Internal Memory

- (1) Procedure for data read from general-purpose PROM to PG-1500 internal memory
- (2) Procedure for data read from 75X series on-chip PROM product to PG-1500 internal memory
- (3) Procedure for data read from 78K/II series on-chip PROM product to PG-1500 internal memory

4.1.2 Data Write from PG-1500 Internal Memory to Blank ROM

- (1) Procedure for data write from PG-1500 internal memory to general-purpose PROM
- (2) Procedure for data write from PG-1500 internal memory to 75X series on-chip PROM product
- (3) Procedure for data write from PG-1500 internal memory to 78K/II series on-chip PROM product

4.1.3 Changing PG-1500 Internal Memory Data

4.1.4 Verify Check

4.1.5 Split Write to Two PROMs of PG-1500 Internal Memory Data

4.1.6 Data Transfer from External Machine to PG-1500

4.1.7 Data Transfer from PG-1500 to External Machine

4.2 Remote Control Mode

4.2.1 Outline of Operations Using NEC In-Circuit Emulator

4.2.2 Data Write from In-Circuit Emulator to Blank ROM

4.2.3 Data Read from Master ROM to In-Circuit Emulator

4.2.4 Data Transfer from External Machine to PG-1500 via Parallel Interface

4.1 Standalone Mode


4.1.1 Data read from master ROM to PG-1500 internal memory

(1) Procedure for data read from general-purpose PROM to PG-1500 internal memory

Example	Master ROM	μ PD27C1001A
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	1FFFFH
	Internal memory start address	00000H
	Address division mode	NORMAL

<1> Select the device.

Connect the 27A board to the PG-1500. After power has been turned on and the initial test has been performed, insert the μ PD27C1001A in the 32-pin PROM socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ	μ PD27C1001A
------	------------------

Remark If AUTO mode or CODE mode is used as the device selection method, see Section 2.4.2 **Device Selection (SELECT)**.

⇒ Read the master ROM data into the PG-1500 internal memory.



When the COPY command terminates normally, the following is displayed:

0000Q:1FFFF	00000
COPY OK	■■■■ NORMAL

Checksum Value

The general-purpose PROM data has been read into the PG-1500 internal memory.

(2) Procedure for data read from 75X Series on-chip PROM product to PG-1500 internal memory


Example	Master ROM	μ PD27P308GF
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	01F7FH
	Internal memory start address	00000H
	Address division mode	NORMAL ^{Note}

Note When a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified.

<1> Select the device.

Connect the 04A board to the PG-1500, and connect the PROM programmer adapter (PA-75P308GF) to this board.

After power has been turned on and the initial test has been performed, insert the μ PD75P308GF in the PROM programmer adapter socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ	D75P308
------	---------

Remark If AUTO mode is used as the device selection method, see Section 2.4.2 Device Selection (SELECT).

<2> Read the master ROM data into the PG-1500 internal memory.



When the COPY command terminates normally, the following is displayed:

00000:01F7F	00000
COPY OK	■■■■ NORMAL

Checksum Value

The 75X Series on-chip PROM version data has been read into the PG-1500 internal memory.

(3) Procedure for data read from 78K/II Series on-chip PROM product to PG-1500 internal memory


Example	Master ROM	μ PD78P214CW
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	03FFFFH
	Internal memory start address	00000H
	Address division mode	NORMAL ^{Note}

Note When a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified.

<1> Select the device

Connect the 27A board to the PG-1500, and connect the PROM programmer adapter (PA-78P214CW) to this board.

After power has been turned on and the initial test has been performed, insert the μ PD78P214CW in the PROM programmer adapter socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ	D78P214
------	---------

Remark If AUTO mode or CODE mode is used as the device selection method, see Section 2.4.2 **Device Selection (SELECT)**.

➤ Read the master ROM data into the PG-1500 internal memory.



When the COPY command terminates normally, the following is displayed:

00000:03FFF	00000
COPY OK	■■■■ NORMAL

Checksum Value

The 78K/II Series on-chip PROM version data has been read into the PG-1500 internal memory.

4.1.2 Data write from PG-1500 internal memory to blank ROM

(1) Procedure for data write from PG-1500 internal memory to general-purpose PROM


Example	Blank ROM	μ PD27C1001A
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	1FFFFH
	Internal memory start address	00000H
	Address division mode	NORMAL

It is assumed that data has already been read into the PG-1500 internal memory (see Section 4.1.1 Data Read from Master ROM to PG-1500 Internal Memory).

<1> Select the device.

Connect the 27A board to the PG-1500.

Insert the μ PD27C1001A in the 32-pin PROM socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ μ PD27C1001A

Remark If AUTO mode or CODE mode is used as the device selection method, see Section 2.4.2 Device Selection (SELECT).

⇒ Write the PG-1500 internal memory data to the blank ROM.

The CONT command is used here to perform the following series of operations: blank check → ROM write → verify check.



When this series of operations terminates normally, the following is displayed:

00000:1FFFF	00000
CONT OK	■■■■ NORMAL

Checksum Value

The PG-1500 internal memory data has been written to the general-purpose PROM.

(2) Procedure for data write from PG-1500 internal memory to 75X Series on-chip PROM product


Example	Blank ROM	μ PD75P308GF
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	01F7FH
	Internal memory start address	00000H
	Address division mode	NORMAL ^{Note}

Note When a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified.

It is assumed that data has already been read into the PG-1500 internal memory (see Section 4.1.1 Data Read from Master ROM to PG-1500 Internal Memory).

<1> Select the device.

Connect the 04A board to the PG-1500, and connect the PROM programmer adapter (PA-75P308GF) to this board. Insert the μ PD75P308GF in the PROM programmer adapter socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ	D75P308
------	---------

Remark If AUTO mode is used as the device selection method, see Section 2.4.2 Device Selection (SELECT).

<3> Check whether the device is blank.




When the blank check terminates normally, the following is displayed:

```

BLNK  OK
  
```

If the result is not OK, replace the device with another one, and repeat the blank check.

<3> Write the PG-1500 internal memory data to the blank PROM.



```


00000:01F7F  00000
PROG  READ   NORMAL
  
```

When the write terminates normally, the following is displayed:

```

00000:01F7F  00000
PROG OK ■■■■ NORMAL
              
          Checksum Value
  
```

<4> Compare the written ROM contents with the contents of the PG-1500 internal memory.



When the verify check terminates normally, the following is displayed:

```

00000:01F7F 00000
VERI OK ■■■■ NORMAL
          [ ]
          Checksum Value
  
```

The PG-1500 internal memory data has been written to the 75X Series on-chip PROM version.

Remark The CONT command can also be used, which performs the following series of operations:
blank check, ROM write, verify check.

(3) Procedure for data write from PG-1500 internal memory to 78K/II Series on-chip PROM product


Example	Blank ROM	μ PD78P214CW
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	03FFFH
	Internal memory start address	00000H
	Address division mode	NORMAL ^{Note}

Note When a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified.

It is assumed that data has already been read into the PG-1500 internal memory (see 4.1.1 Data Read from Master ROM to PG-1500 Internal Memory).

<1> Select the device.

Connect the 27A board to the PG-1500, and connect the PROM programmer adapter (PA-78P214CW) to this board. Insert the μ PD78P214CW in the PROM programmer adapter socket.




When the above read and settings terminate normally, the following is displayed for 1 second:

READ D78P214


Remark If AUTO mode or CODE mode is used as the device selection method, see Section 2.4.2 Device Selection (SELECT).

<2> Write the PG-1500 internal memory data to the blank ROM.

The CONT command is used here to perform the following series of operations: blank check → ROM write → verify check.



When this series of operations terminates normally, the following is displayed:





The PG-1500 internal memory data has been written to the 78K/II Series on-chip PROM version.

4.1.3 Changing PG-1500 internal memory data

It is assumed that data has already been read into the PG-1500 internal memory (see 4.1.1 Data Read from Master ROM to PG-1500 Internal Memory).

	Address	Data before Change		Data after Change
Examples 1.	02345	C7	→	56
2.	02347	66	→	57





Input the data to be changed to, using the numeric keys.
(Example 1: 57)

The data is changed, and the following is displayed:

Data in Address 2347

02343:AA	13	56	84	57
02348:D2	FA	9C	BB	DD


Data in Address 2348

When the change is completed, exit the CHANGE command using the DEVICE, EDIT, FUNCTION, or RESET key.
The PG-1500 internal memory data has been changed.


4.1.4 Verify check

The procedure for checking whether the data written in the device matches the contents of the PG-1500 internal memory is shown below.

Example	Programmed ROM	μ PD27C1001A
	ROM code	10D6
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	1FFFFH
	Internal memory start address	00000H
	Address division mode	NORMAL



When the verify check terminates normally, the following is displayed:



The verify check is now terminated.

4.1.5 Split write to two PROMs of PG-1500 internal memory data

The procedure for writing data read into the PG-1500 internal memory to two PROMs, divided between odd addresses and even addresses, is described below.

An example of a split write of 16-bit data is shown below.


Example	Blank ROM	$\mu\text{PD27C1001A} \times 2$
	Device selection method	READ mode
	PROM start address	00000H
	PROM end address	1FFFFH
	Internal memory start address	00000H
	Address division mode	16EVN, 16ODD

It is assumed that data has already been read into the PG-1500 internal memory (see Section 4.1.1 **Data Read from Master ROM to PG-1500 Internal Memory**).

<1> Select the device.

Connect the 27A board to the PG-1500.

Insert a $\mu\text{PD27C1001A}$ in the 32-pin PROM socket.




When the above read and settings terminate normally, the following is displayed for 1 second:


READ	$\mu\text{PD27C1001A}$
------	------------------------

Remark If AUTO mode or CODE mode is used as the device selection method, see Section 2.4.2 **Device Selection (SELECT)**.

- <2> Write only the data corresponding to the even addresses of the PG-1500 internal memory to the blank ROM. The CONT command is used here to perform the following series of operations: blank check → ROM write → verify check.




When this series of operations terminates normally, the following is displayed:



- <3> Remove the written ROM, and insert the blank ROM in the 32-pin PROM socket.

<4> Write only the data corresponding to the odd addresses of the PG-1500 internal memory to the blank ROM.

The CONT command is used here to perform the following series of operations: blank check → ROM write → verify check.



When this series of operations terminates normally, the following is displayed:

00000:1FFFF	00000
CONT OK	■■■■ 16ODD

└───┘
Checksum Value

The split-write of the PG-1500 internal memory data to the two PROMs is completed.

4.1.6 Data transfer from external machine to PG-1500

The procedure for transferring a data file on an external machine to the PG-1500 internal memory using an RS-232-C cable is shown below.

Example	External Machine	PC-9800 Series
	OS	MS-DOS
	Transfer file name	TEST.HEX
	Transfer data format	INTELLEC
	Baud rate	9600
	Parity	None
	XON/XOFF	ON
	Character length	8
	Stop bits	2


<1> Connect the PC-9800 to the PG-1500 using an RS-232-C cable.

<2> Perform PC-9800 internal settings.

PC-9800 Display

```
A>SPEED R0 9600 B8 PN S2 XON ☐
A> ☐
```

<3> Perform PG-1500 internal settings.



<4> Set the PG-1500 to the data input wait state.

FUNCTION

Set FUNCTION mode.

S-IN

Select the S-IN command.

Check that the following is displayed on the LCD:

S-IN FMT: INTELLC

If the data format to be used is not INTELLC, use the ☐ or ☐ key to change the setting.

SET/START

The PG-1500 enters the data input wait state and [*] flashes.

<5> Send the data file from the PC-9800.

```

PC-9800 Display
A>COPY TEST.HEX AUX ☒
    1 file has been copied.

A> ■
  
```

<6> When the transfer ends, the PG-1500 displays the following:

S-IN OK INTELLC

The external machine data has been transferred to the PG-1500.

4.1.7 Data transfer from PG-1500 to external machine


The procedure for transferring PG-1500 internal memory data to an external machine using an RS-232-C cable is shown below.


Example	External Machine	PC-9800 Series
	OS	MS-DOS
	Transfer file name	TEST.HEX
	Transfer range	3000H to 4FFFH
	Transfer data format	INTELLEC
	Baud rate	9600
	Parity	None
	XON/XOFF	ON
	Character length	8
	Stop bits	2

<1> Connect the PC-9800 to the PG-1500 using an RS-232-C cable.

<2> Perform PC-9800 internal settings, then set the input wait state.

PC-9800 Display

```
A>SPEED R0 9600 B8 PN S2 XON 
```

A> 

<3> Perform PG-1500 internal settings.

FUNCTION



Set FUNCTION mode.

MODE

Select the MODE command.

Change the baud rate, parity, XON/XOFF, character length, and stop bit settings as shown in the following display.


```
BR: 9600 P:NON XN:ON
MOVE B:8 SB:2 PC:OF
```

Use  to move the cursor, and  to change the setting.

SET/START

Set when the display is as shown above.

- ★ <4> Set data transfer conditions from PG-1500.



- ★ <5> Set the PC-9800 to input wait.

PC-9800 Display

```
A>COPY AUX TEST.HEX [ ]
```

- ★ <6> Data transfer start from the PG-1500.

SET/START Data transfer is started, and [*] flashes.

```
03000:04FFF 1A
*SOUT FMT: INTELLEC
```

When the transfer ends, the PG-1500 displays the following:

```
03000:04FFF 1A
SOUT OK INTELLEC
```

The PC-9800 displays the following:

PC-9800 Display


```
1 file has been copied.
A> [ ]
```

The PG-1500 data has been transferred to the external machine.

4.2 Remote Control Mode

4.2.1 Outline of operations using NEC in-circuit emulator

This section outlines operations when a PC-9800 series model is used as the host machine, and an NEC IE-75000-R in-circuit emulator is connected. The description given here assumes that the IE-75000-R and PC-9800 are already connected. Please refer to the in-circuit emulator User's Manual for how to connect the host machine and in-circuit emulator.



The procedure for performing operations using the IE-75000-R is as follows:


- (1) Power off each unit.
- (2) Connect the PG-1500 to the IE-75000-R with a cable.
- (3) Set the IE-75000-R's interface with the PG-1500 (channel 2).
- (4) Power on each unit.
- (5) Set the PG-1500's interface with the IE-75000-R.
- (6) Start the IE-75000-R control program.
- (7) Set the PG-1500 to remote control mode.
- (8) Start PG-1500 remote operation (PGM mode).
- (9) Execute a PG-1500 command.
- (10) Terminate PG-1500 remote operation (PGM mode).
- (11) Terminate PG-1500 remote control mode.
- (12) Terminate the IE-75000-R control program.
- (13) Power off each unit.

(1) Power off each unit

The power of each unit should be off before starting the connection procedure. If the PG-1500, IE-75000-R and PC-9800 are powered on, first power them off.

(2) Connect the PG-1500 to the IE-75000-R with a cable

Connect the serial interface connector of the PG-1500 (on the right of the rear panel) to the CH2 serial interface port of the IE-75000-R, using a commercially available RS-232-C interface cable (straight cable).


**(3) Set the IE-75000-R's interface with the PG-1500 (channel 2)**

Channel 2 of the IE-75000-R can be set by setting switches on the main unit with the power off, or by starting the main unit and executing the MOD command. Setting using the switches on the main unit is shown here.

Table 4-1. IE-75000-R Channel 2 Setting

Item	Setting
Mode switchover	Terminal mode
Frame ground	No. 4: OFF
RTS selection	No. 1: ON, Nos. 2 & 3: OFF

Figure 4-1. IE-75000-R Channel 2 Setting



- <1> Open the RS-232-C setting section cover on the side of the IE-75000-R.
- <2> Slide the CH2 modem/terminal mode selection switch to the right, setting terminal mode.
- <3> Turn switch 4 of the CH2 RTS/FG selection switch off (down position), setting FG and SG to the open state.
- <4> Set switches 1 to 3 of the CH2 RTS/FG selection switch as shown below, selecting the RTS setting.

No. 1: ON (UP)

No. 2: OFF (DOWN)

No. 3: OFF (DOWN)

Remark Channel 2 setting using MOD command

Settings for the channel 2 handshaking method, baud rate, and character length are made by means of the MOD command. See the "IE-75000-R User's Manual" for details.

Table 4-2. Channel 2 Settings By MOD Command

Item		Setting	Set By
Handshaking method		1 character	MOD command
Baud rate		9600 bps	
Character specification	Character length	8 bits	
	Parity bits	None	
	Stop bit length	2 bits	

(4) Power on each unit

Follow the procedure below when powering on the equipment.

- <1> Power on the PC-9800.
- <2> Power on the IE-75000-R.
- <3> Power on the PG-1500.

(5) Set the PG-1500's interface with the IE-75000-R

Set the serial interface of the PG-1500. Execute the FUNCTION mode MODE command. The settings are shown below.

Table 4-3. Sample of PG-1500 Serial Interface Settings

Item	Setting	LCD Display
Baud rate	9600 bps	BR : 9600
Parity bit	None	P : NON
XON/XOFF control ^{Note 1}	None	XN : OF
Character length	8 bits	B : 8
Stop bits	2 bits	SB : 2
Precheck ^{Note 2}	None	PC : OF

- Notes**
1. When connecting the unit to the in-circuit emulator, XON/XOFF control should be set to “none” (LCD display: OF).
 2. This function checks whether the device has been inserted correctly. It can only be used with an NEC general-purpose PROM.

<Operation Method>

Key Operation

Display

Description

FUNCTION

```

SIN PIN SOUT MODE REM
FUNCTION
  
```

Set FUNCTION mode.

MODE

```

      Baud Rate      Parity      XON/XOFF
BR: 9600 P:NON XN:ON
MODE B:8 SB:2 PC:OF
      Character      Stop      Precheck
      Length        Bits
  
```

Various setting modes.

Caution Parameter changes cannot be input with numeric keys.

△: Parameter selection

▽: Change of parameter setting

▽

```

BR: 9600 P:NON XN:ON
MODE B:8 SB:2 PC:OF
  
```

Change to the parameter to be set.
Setting example: 9600 bps

Changes as follows, using the ▽ key.

```

→ [19200] → [1200] → [2400] → [4800] → [9600] →
  
```

△

```

BR: 9600 P:NON XN:ON
MODE B:8 SB:2 PC:OF
  
```

Move the cursor.

▽

```

BR: 9600 P:NON XN:ON
MODE B:8 SB:2 PC:OF
  
```

Change to the parameter to be set.
Setting example: NON
[No parity]

Changes as follows, using the ▽ key.

```

→ [NON] → [EVN] → [ODD] →
  
```

△

```

BR: 9600 P:NON XN:ON
MODE B:8 SB:2 PC:OF
  
```

Move the cursor.

▽

```

BR: 9600 P:NON XN:OF
MODE B:8 SB:2 PC:ON
  
```


Change to the parameter to be set.
Setting example: OF

Changes as follows, using the ▽ key.

```

[OF] ↔ [ON]
  
```

<1>



- Cautions**
1. If the **SET/START** key is not pressed, the settings are not changed.
 2. When the **SET/START** key is pressed, a write is performed to the NV-RAM in the PG-1500.

(6) Start the IE-75000-R control program

Start the IE-75000-R control program.

```

A>IE75000 

IE-75000 CONTROLLER (PC-9801 SERIES) V2.16 [18 Nov93]
      Copyright (C) 1989,1993 by NEC Corporation

IE-75000/1-R Monitor V1.5 [1 May 93]
      Copyright (C) 1989,1993 by NEC Corporation

Self check ok

Target CPU       $\mu$ PD75108/108A/108F/P108/P108B/112/112F/116/116F/P116
Program Memory  0-FFFFH
Data Memory     00H-1FFH,F80-FFFFH
Memory Bank     0-1,15
Register Bank   0-3
Power on target system (Y/N) Y 
Do you use high speed down load mode? (Y/N) = N 

brk:0>■

```

“brk:0>” is displayed as a prompt, and the break mode is set.



(7) Set the PG-1500 to remote control mode

Set the PG-1500 remote control mode, using the following procedure.












<Operation Method>

Key Operation	Display	Description
FUNCTION	SIN PIN SOUT MOD REM FUNCTION	Set FUNCTION mode.
REMOTE	REMOTE MODE	Select the REMOTE command.
SET/START	REMOTE MODE OK	If correctly connected with the external machine, [OK] is displayed.

Input the IE-75000-R PROM programmer control command (PGM command). PG-1500 remote operation (PGM mode) is then started.

```
brk:0>PGM   
Beginning of PGM mode  
  
PG> 
```

PG-1500 commands that can be used in remote operation (PGM mode) by the IE-75000-R are shown below.

Command	Input Format	Function
RR	PG> <u>RR ROM_S_ADR, ROM_E_ADR, PG_S_ADR, CONV</u> 	Data read from device.
RS	PG> <u>RS sub</u>  sub = C/R/A	Device selection
RV	PG> <u>RV ROM-S_ADR, ROM_E_ADR, PG_S_ADR, CONV</u> 	Comparison of device data with PG-1500 internal memory data
RW	PG> <u>RW ROM-S_ADR, ROM_E_ADR, PG_S_ADR, CONV</u> 	Write to device
RZ	PG> <u>RZ</u> 	Check of device erased state
MC	PG> <u>MC PG_S_ADR</u> 	Change of PG-1500 internal memory data
MD	PG> <u>MD PG_S_ADR, PG_E_ADR</u> 	Display of PG-1500 internal memory data
MF	PG> <u>MF PG_S_ADR, PG_E_ADR, INT_DATA</u> 	Initialization of PG-1500 internal memory data
LI	PG> <u>LI</u> 	Serial input using Intel HEX
SI	PG> <u>SI PG_S_ADR, PG_E_ADR</u> 	Serial output using Intel HEX
??	PG> <u>??</u> 	Help command

Remark ROM_S_ADR : PROM start address
ROM_E_ADR : PROM end address
PG_S_ADR : PG-1500 internal memory start address
PG_E_ADR : PG-1500 internal memory end address
CONV : Address division mode
INT_DATA : Initialization data

Terminate PG-1500 remote operation (PGM mode)

Input **CTRL** + **Z** to the PC-9800. PG-1500 remote operation will terminate.

```
PG>^Z
Exit PGM mode(Y/N)Y
Termination of PGM mode
brk:0>
```


166

(11) Terminate PG-1500 remote control mode

Press the **RESET** key on the PG-1500 to release the remote control mode.

(12) Terminate the IE-75000-R control program

Input the IE-75000-R control program termination command (EXT). Control is returned to the OS, and the prompt is displayed.

```
brk:0>EXT 
```

```
A> 
```

(13) Power off each unit

Follow the procedure below when powering off the equipment.

- <1> Power off the PG-1500.
- <2> Power off the IE-75000-R.
- <3> Power off the PC-9800.

4.2.2 Data write from in-circuit emulator to blank PROM

This description assumes that the PG-1500 is already connected to the in-circuit emulator and host machine, and is ready for remote operation (in PGM mode) (see Section 4.2.1 Outline of operations using NEC in-circuit emulator).

Example	Host machine	PC-9800 Series
	In-circuit emulator	IE-75001-R
	Blank ROM	μ PD75P308GF
	PROM start address	00000H
	PROM end address	01F7FH
	IE-75000-R memory transfer start address	0000H
	IE-75000-R memory transfer end address	0FFFFH

The following procedure is used to write data from the in-circuit emulator to the blank ROM.

- (1) Transfer the data from the in-circuit emulator to the PG-1500 using the LI command.
- (2) Set the blank ROM in the PG-1500.
- (3) Perform device selection using the RS command.
- (4) Perform a write using the RW command.
- (5) Perform verification using the RV command.

(1) Transfer the data from the in-circuit emulator to the PG-1500 using the LI command

Uses the LI command to transfer the data in the memory space mapped in the IE-75001-R to the PG-1500 internal memory.

Input the transfer start address (0) and transfer end address (0FFF) of the IE-75000-R memory.

If the transfer range specification is omitted, the entire mapped memory space is transferred.

To suspend the transfer, input ESC.

```
PG>LI 0
partition=0,0FFF 0
PG> 
```

(2) Set the blank ROM in the PG-1500

Connect the 04A board to the PG-1500, and connect the PROM programmer adapter (PA-75P308GF) to this board.

Insert the blank ROM (μ PD75P308GF) in the socket on the PROM programmer adapter.

(3) Perform device selection using the RS command


An example in which the READ mode is used is shown here.

```
PG>RS R 0
Your setting ROM is  $\mu$ PD75P308
PG> 
```


(4) Perform a write using the RW command

Input the PROM start address (0), PROM end address (1F7F), PG-1500 internal memory start address (0), and address division mode (N).

If a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified as the address division mode.

```
PG>RW 0,1F7F,0,N 
```

```
Now , data writing !
```

```
Data complete
```


```
Check sum : 2BC8
```

```
PG> 
```

(5) Perform verification using the RV command

The device on which writing is finished is compared with the PG-1500 internal memory data.

Perform this directly after executing the RW command.

```
PG>RV 0,1F7F,0,N 
```

```
Now , data reading !
```

```
Data complete
```

```
Check sum : 2BC8
```

```
PG> 
```

This completes the data write from the in-circuit emulator to the blank ROM.

4.2.3 Data read from master ROM to in-circuit emulator

This description assumes that the PG-1500 is already connected to the in-circuit emulator and host machine, and is ready for remote operation (in PGM mode) (see Section 4.2.1 Outline of operations using NEC in-circuit emulator).

Example	Host machine	PC-9800 Series
	In-circuit emulator	IE-75001-R
	Master ROM	μ PD75P308GF
	PROM start address	00000H
	PROM end address	01F7FH
	PG-1500 internal memory start address	00000H
	PG-1500 internal memory end address	01F7FH
	Address division specification	N
	IE-75000-R- load bias ^{Note}	0

Caution The value obtained by adding the IE-75000-R load bias to the PG-1500 internal memory start address is the IE-75000-R transfer start address.

The following procedure is used to read data from the master ROM to the in-circuit emulator.

- (1) Set the master ROM in the PG-1500.
- (2) Perform device selection using the RS command.
- (3) Perform a read using the RR command.
- (4) Perform verification using the RV command.
- (5) Transfer the data from the PG-1500 to the in-circuit emulator using the SI command.

(1) Set the master ROM in the PG-1500

Connect the 04A board to the PG-1500, and connect the PROM programmer adapter (RA-75P308GF) to this board.

Insert the master ROM (μ PD75P308GF) in the socket on the PROM programmer adapter.

(2) Perform device selection using the RS command

An example in which the READ mode is used is shown here.

```
PG>RS R 
```

```
Your setting ROM is  $\mu$ PD75P308
```

```
PG> 
```

(3) Perform a read using the RR command

Input the PROM start address (0), PROM end address (1F7F), PG-1500 internal memory start address (0), and address division mode (N).

If a device other than a general-purpose PROM is used, NORMAL (no address division) must be specified as the address division mode.

```
PG>RR 0,1F7F,0,N
```

```
Now , data reading !
```

```
Data complete
```

```
Check sum : 2BC8
```

```
PG>
```

(4) Perform verification using the RV command

The device on which reading is finished is compared with the PG-1500 internal memory data.

Perform this directly after executing the RR command.

```
PG>RV 0,1F7F,0,N
```

```
Now , data reading !
```

```
Data complete
```

```
Check sum : 2BC8
```

```
PG>
```

(5) Transfer the data from the PG-1500 to the in-circuit emulator using the SI command

Use the SI command to transfer the contents of the PG-1500 internal memory to the memory space mapped in the IE-75001-R.

Input the PG-1500 internal memory start address (0), PG-1500 internal memory end address (1F7F), and IE-75001-R load bias (0).

The IE-75001-R load bias cannot be omitted.

To suspend the transfer, input **ESC**.

```
PG>SI 0,1F7F
```

```
Bias=0
```

```
complete
```

```
PG>
```

This completes the data read from the master ROM to the in-circuit emulator.

4.2.4 Data transfer from external machine to PG-1500 via parallel interface

Connect the PG-1500 to the in-circuit emulator and host machine via the serial interface and parallel interface. See

4.2.1 Outline of Operations Using NEC In-Circuit Emulator for the serial interface connection. The parallel interface connection is described below.

Connect the parallel interface connector on the PG-1500 to the printer output connector on the host machine, using a parallel interface cable (printer cable). Power off both units before making the connection.

Data in the in-circuit emulator cannot be transferred directly to the PG-1500. The data to be transferred must first be saved to a floppy disk, etc.

The PG-1500 is assumed to be ready for remote operation (in PGM mode).

Example	Host machine	PC-9800 Series
	In-Circuit emulator	IE-75001-R
	Transfer file name	TEST.HEX

The following procedure is used to transfer data from the external machine to the PG-1500 via the parallel interface.

- (1) Set the PG-1500 to the parallel input state with the PI command.
- (2) Terminate PG-1500 remote operation (PGM mode).
- (3) Transfer control to the OS (DOS).
- (4) Perform the data transfer with an OS command.
- (5) Return control to the IE-75001-R control program.
- (6) State PG-1500 remote operation (PGM mode).

(1) Set the PG-1500 to the parallel input state with the PI command

Execute the PI command. The PG-1500 is set to the parallel input state.

```
PG>PI
```

(2) Terminate PG-1500 remote operation (PGM mode)

Input **CTRL** + **Z**. PG-1500 remote operation (PGM mode) terminates and the break mode is set.

```
^Z
Exit PGM mode (Y/N)Y
Termination of PGM mode
brk:0>
```



(3) Transfer control to the OS (DOS)

Execute the in-device emulator DOS command. Control is transferred from the in-device emulator control program to the OS (DOS).

```
brk:0>DOS
Command version ♦♦♦
A>
```



(4) Perform the data transfer with an OS command

Execute the OS COPY command. Data is output from the parallel interface of the host machine.

```
A>COPY TEST_HEX PRN   
      1 file has been copied.  
  
A> 
```



(5) Return control to the IE-75001-R control program

On completion of the data transfer, execute the OS EXIT command to return control to the in-circuit emulator control program.

```
A>EXIT   
  
      Return from Child !  
  
brk:0> 
```

(6) Start PG-1500 remote operation (PGM mode)

When the PGM command is executed in break mode, PG-1500 remote operation (PGM mode) is started.

```
brk:0>PGM   
      Beginning of PGM mode  
  
PG> 
```

This concludes the data transfer from the external machine to the PG-1500 via the parallel interface.

[MEMO]

APPENDIX

[MEMO]

APPENDIX A. ERROR MESSAGE LIST

A.1 Standalone Mode Error List

Error No.	00
Description	Internal circuit power supply +5.00 VDC check error
Occurrence	During initial test
Display	<div>PG-1500 ERR00</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	01
Description	Internal circuit GND check error
Occurrence	During initial test
Display	<div>PG-1500 ERR01</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	02
Description	PG-1500 internal memory check error
Occurrence	During initial test
Display	<div>PG-1500 ERR02</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	03
Description	Internal compare voltage +2.5 V check error
Occurrence	During initial test
Display	<div>PG-1500 ERR03</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	04
Description	Internal compare voltage +2.35 V check error
Occurrence	During initial test
Display	<div>PG-1500 ERR04</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	05
Description	Internal compare voltage +1.5 V check error
Occurrence	During initial test
Display	<div>PG-1500 ERR05</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	06
Description	Internal compare voltage +0.5 V check error
Occurrence	During initial test
Display	<div>PG-1500 ERR06</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	07
Description	VCC (variable) voltage check error
Occurrence	During initial test
Display	<div>PG-1500 ERR07</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	08
Description	VPP (variable) voltage check error
Occurrence	During initial test
Display	<div>PG-1500 ERR08</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	09
Description	Data bus check error
Occurrence	During initial test
Display	<div>PG-1500 ERR09</div>
Countermeasure	Turn off the power supply and turn it on again. If an error still occurs, the PG-1500 may be defective. In such case, consult with an NEC or authorized NEC dealer sales representative.

Error No.	10
Description	Start address > end address
Occurrence	During address check in each command execution
Display	<div> AAAAA:BBBBB CCCCC DDDD ERR10 FFFFFFF </div> <p> A : PROM/internal memory start address B : PROM/internal memory end address C : Internal memory start address/data D : Execute command F : Address divide mode (when DEVICE mode command is used) </p>
Countermeasure	Check the input addresses and reinput the addresses.

Error No.	11
Description	PROM start address > ROM size
Occurrence	During address check in each command execution
Display	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> AAAAA:BBBBB CCCCC DDDD ERR11 FFFFFFF </div> <p> A : PROM/internal memory start address B : PROM/internal memory end address C : Internal memory start address/data D : Execute command F : Address divide mode (when DEVICE mode command is used) </p>
Countermeasure	Check the input addresses and reinput the addresses.

Error No.	12
Description	Internal memory start address > Internal memory size
Occurrence	During address check in each command execution
Display	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> AAAAA:BBBBB CCCCC DDDD ERR12 FFFFFFF </div> <p> A : PROM/internal memory start address B : PROM/internal memory end address C : Internal memory start address/data D : Execute command F : Address divide mode (when DEVICE mode command is used) </p>
Countermeasure	Check the input addresses and reinput the addresses.

Error No.	13
Description	Conversion error
Occurrence	During address check in each command execution
Display	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> AAAAA:BBBBB CCCCC DDDD ERR13 FFFFFFF </div> <p> A : PROM/internal memory start address B : PROM/internal memory end address C : Internal memory start address/data D : Execute command F : Address divide mode (when DEVICE mode command is used) </p>
Countermeasure	The currently selected device does not operate in the specified divide mode. Check the selected device and divide mode and determine the divide mode again.

★

Error No.	20
Description	Verify error (when $V_{CC} = 5\text{ V}$)
Occurrence	During data compare in commands performing a verify operation (COPY, PROGRAM)
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> BB: CC DDDD ERR20 AAAAA </div> <p> A : Address at which error occurred B : Internal memory data C : Device data D : Execute command </p>
Countermeasure	<p>The read device data and the internal memory data contents do not match.</p> <p>If this occurs during write, the write operation has not been carried out normally. In such cases, write once again.</p>

★

Error No.	21
Description	Verify error (when $V_{CC} = 5 + \alpha$) (The value of α depends on the device)
Occurrence	During data compare in commands performing a verify operation (VERIFY, COPY, PROGRAM, CONT)
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> BB: CC DDDD ERR21 AAAAA </div> <p> A : Address at which error occurred B : Internal memory data C : Device data D : Execute command </p>
Countermeasure	<p>The read device data and the internal memory data content do not match.</p> <p>If this occurs during write, the write operation has not been carried out normally. In such cases, write once again.</p>

★

Error No.	22
Description	Verify error (when $V_{CC} = 5 - \alpha$) (The value of α depends on the device)
Occurrence	During data compare in commands performing a verify operation (VERIFY, COPY, PROGRAM, CONT)
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> BB: CC DDDD ERR22 AAAAA </div> <p> A : Address at which error occurred B : Internal memory data C : Device data D : Execute command </p>
Countermeasure	<p>The read device data and the internal memory data content do not match.</p> <p>If this occurs during write, the write operation has not been carried out normally. In such cases, write once again.</p>

Error No.	28
Description	Blank check error
Occurrence	In data compare during blank check command execution
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> BB BLANK ERR28 AAAAA </div> <p style="margin-left: 40px;">A : Address not erased B : Device data</p>
Countermeasure	Data read from the device does not match data which is not written to the device. When writing, use another device.

Error No.	2C
Description	Write error
Occurrence	During data write in write commands (PROG, CONT)
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> CC: BB DDDD ERR2C AAAAA </div> <p style="margin-left: 40px;">A : Address at which error occurred B : Devide data C : Internal memory data D : Execute command</p>
★ Countermeasure	If data cannot be written normally in the device write flow, this error occurs. In such case, check if the used device matches the selected device. If they match, the device may be defective.

Error No.	30
Description	Silicon signature data read error
Occurrence	This error occurs if a read data parity calculation executed in silicon signature data read shows that the read data is not correct
Display	<div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> AAAA ERR30 </div> <p style="margin-left: 40px;">A : Execute command</p>
★ Countermeasure	There may be no silicon signature data in the selected device.

Error No.	31
Description	Silicon signature data read error
Occurrence	When READ mode is used for the device selection method, the target device at ROM control instruction execution differs from the set device.
Display	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;">AAAA ERR31</div> <div>A : Execute command</div> </div>
Countermeasure	<p>When READ mode is used as the device selection method, the read silicon signature data differs from the preset silicon signature data.</p> <p>Check the device inserted in the socket.</p> <p>When carrying operation for the inserted device, start it by reading the silicon signature again.</p>

Error No.	32
Description	Silicon signature undefined error
Occurrence	This error occurs when the device write condition is set using the data read in silicon signature data read.
Display	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;">AAAA ERR32</div> <div>A : Execute command</div> </div>
Countermeasure	Since the data read in system silicon signature data read is not supported by the PG-1500, replace the device with one that supports the data.

Error No.	38
Description	Device incorrect insert error
Occurrence	During NEC general-purpose PROM precheck
Display	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;">AAAA ERR38</div> <div>A : Execute command</div> </div>
Countermeasure	The device is wrongly inserted. Re-insert in the correct direction

Error No.	39
Description	Adapter board and PROM programmer adapter disconnect error
Occurrence	During DEVICE instruction execution
Display	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;">AAAA ERR39</div> <div>A : Execute command</div> </div>
Countermeasure	<p>The adapter board or PROM programmer adapter is not connected.</p> <p>Check adapter board/PROM programmer adapter connection.</p>

Error No.	40
Description	Serial disconnect error
Occurrence	During communication destination check in serial input/output instruction execution
Display	<div> REMOTE MODE ERR40 Not ready </div>
Countermeasure	The RS-232-C cable is not connected correctly. Check the cable, the currently set baud rate and character length.

Error No.	41
Description	File transfer error
Occurrence	During serial/parallel transfer
Display	<div> AAAA ERR41 BBBBBBBB </div> <div> A : Execute command B : Data format </div>
★ Countermeasure	Check the device connection and HEX fail format and carry out transfer again.

A.2 Remote Control Mode Error List

Error No.	10
Description	Start address > end address
Occurrence	During address check in command execution
Display	ERR10 (START_ADR > END_ADR)
Countermeasure	Input the correct addresses.

Error No.	11
Description	PROM start address > ROM size
Occurrence	During address check in each command execution
Display	ERR11 (ROM_S_ADR or ROM_E_ADR > ROM_SIZE)
Countermeasure	Input the correct addresses.

Error No.	12
Description	Internal memory start address > PG-1500 internal memory size
Occurrence	During address check in each command execution
Display	ERR12 (PG_BUFF SIZE over)
Countermeasure	Input the correct addresses.

Error No.	13
Description	Conversion error
Occurrence	During input parameter check in RR, RV and RW command execution
Display	ERR13 (Conversion error)
Countermeasure	The currently selected device does not operate in the specified divide mode. Check the selected device and divide mode.

Error No.	14
Description	Input symbol error
Occurrence	During address check in each command execution
Display	ERR14 (Illegal character)
Countermeasure	A symbol not in hexadecimal notation was used for address input. Check the input characters and reinput the addresses.

Error No.	15
Description	Address divide specify error
Occurrence	During input parameter check in RR, RV and RW command execution
Display	ERR15 (Illegal character)
Countermeasure	An unspecified symbol was input for address divide specification. Reinput using the specified symbol.

Error No.	16
Description	Command syntax error
Occurrence	During input parameter check in each command execution.
Display	ERR16 (Command syntax error)
Countermeasure	The command input format is wrong. Reinput after checking a correct input format.

Error No.	17
Description	Illegal command
Occurrence	During input parameter check in each command execution.
Display	ERR17 (Illegal command)
Countermeasure	An unspecified command has been input. Reinput using the specified command.

Error No.	20
Description	Verify error (generated when $V_{CC} = 5\text{ V}$)
★ Occurrence	Generated when a data comparison is made in a command (RR, RV, or RW) which performs verification.
Display	ERR20 Data not complete!! <div style="display: flex; justify-content: space-around; text-align: center;"> <div>Adr xxxxx</div> <div>ROM data xxxx</div> <div>RAM data xxxx</div> </div> Continue (Y:Yes/N:No)?
Countermeasure	The read device data does not match the internal memory data. If generated in a write, the write has not been performed normally. Perform the write again.

Error No.	21
★ Description	Verify error (generated when $V_{CC} = 5 + \alpha$) (The value of α depends on the device)
Occurrence	Generated when a data comparison is made in a command (RR, RV, or RW) which performs verification.
Display	ERR21 Data not complete!! <div style="display: flex; justify-content: space-around; text-align: center;"> <div>Adr xxxxx</div> <div>ROM data xxxx</div> <div>RAM data xxxx</div> </div> Continue (Y:Yes/N:No)?
Countermeasure	The read device data does not match the internal memory data. If generated in a write, the write has not been performed normally. Perform the write again.

Error No.	22						
Description	Verify error (generated when $V_{cc} = 5 - \alpha$) (The value of α depends on the device)						
Occurrence	Generated when a data comparison is made in a command (RR, RV, or RW) which performs verification.						
Display	<div>ERR22 Data not complete!!</div> <table><tr><td>Adr</td><td>ROM data</td><td>RAM data</td></tr><tr><td>xxxxx</td><td>xxxx</td><td>xxxx</td></tr></table> <div>Continue (Y:Yes/N:No)?</div>	Adr	ROM data	RAM data	xxxxx	xxxx	xxxx
Adr	ROM data	RAM data					
xxxxx	xxxx	xxxx					
Countermeasure	The read device data does not match the internal memory data. If generated in a write, the write has not been performed normally. Perform the write again.						

Error No.	28				
Description	Blank check error				
Occurrence	During blank check command execution				
Display	<p>ERR28 ROM not erased!!</p> <table> <tr> <td>Adr</td><td>ROM data</td></tr> <tr> <td>xxxxx</td><td>FE</td></tr> </table> <p>Continue (Y:Yes/N:No)?</p>	Adr	ROM data	xxxxx	FE
Adr	ROM data				
xxxxx	FE				
Countermeasure	The data read from device does not match the data which is not written to device. When writing, use another device.				

Error No.	2C				
Description	Write error				
Occurrence	During data write in device write commands (PROG, CONT)				
Display	<p>ERR2C Write error!</p> <table> <tr> <td>Adr</td><td>ROM data</td></tr> <tr> <td>xxxxx</td><td>FE</td></tr> </table> <p>Continue (Y:Yes/N:No)?</p>	Adr	ROM data	xxxxx	FE
Adr	ROM data				
xxxxx	FE				
Countermeasure	Data is not written normally, perform rewriting. If the error occurs again, check if the used device matches the selected device. If they match, the data is already written or the device may be defective.				

Error No.	30
Description	Silicon signature data read error
Occurrence	This error occurs if read data parity calculation executed in silicon signature data read shows that the read data is not correct.
Display	ERR30 (Signature read error)
Countermeasure	No silicon signature operation can be performed for the selected device.

Error No.	31
Description	Silicon signature data compare error
★ Occurrence	This error occurs when the R subcommand of the RS command is specified or the target device differs from the set device during RR, RV, RW and RZ command silicon signature data compare.
Display	ERR31 (Unexpected Signature)
Countermeasure	When READ mode is used as the device selection method, the read silicon signature data differs from the preset silicon signature data. Check the device inserted in the socket. When carrying operation for the inserted device, start it by reading the silicon signature data again.

Error No.	32
Description	Silicon signature data undefined error
Occurrence	This error occurs when device write condition is set using the data read in silicon signature data read.
Display	ERR32 (Undefined Signature)
Countermeasure	Since the data read in silicon signature read is not supported by the PG-1500, replace the device with one that supports the data.

Error No.	38
Description	Device incorrect insert error
Occurrence	During NEC general-purpose PROM precheck.
Display	ERR38 (Device insert error)
Countermeasure	A device is not inserted in the socket, or the device is wrongly inserted. Re-insert in the correct direction.

Error No.	39
Description	Adapter board and PROM programmer adapter disconnect error
Occurrence	During DEVICE instruction execution
★ Display	ERR39 (Board not connected)
Countermeasure	The adapter board or PROM programmer adapter is not connected. Check the adapter board/PROM programmer adapter connection.

Error No.	40
Description	Serial disconnect error
Occurrence	During communication destination check
Display	ERR40 (Serial not ready)
Countermeasure	The RS-232-C cable is not connected correctly. Check the cable, the currently set baud rate and character length.

Error No.	41
Description	File transfer error
Occurrence	During serial/parallel transfer
Display	ERR41 (Illegal format data error)
★ Countermeasure	Check the device connection and HEX format and carry out transfer again.

APPENDIX B. OBJECT FORMATS

B.1 INTELLEC HEX

INTELLEC HEX formats are described in (1) and (2) below.

Descriptions <1> to <7> in (1) and (2) are made below.

<1> Start mark

Format recognition is made by start mark [:].

<2> No. of byte counts

a. Extended address record:

No. of bytes of the high segment base address <7>

b. Data record : No. of bytes of data <5>

c. End record : [00]

<3> Address value

a. Extended address record: [0000]

b. Data record : Start address to be input

c. End record : [0000]

<4> Record type

a. Extended address record: [02]

b. Data record : [00]

c. End record : [01]

d. Start address record : [03]

<5> PG-1500 internal memory input or output data (data record only)

The start data address is the value indicated in <3>.

<6> Check sum


The least significant 8-bit data of two's complement obtained by adding data from byte count data to data in the frame just before the check sum.

<7> High-end segment base address (extended address record only)


When the record type [02] is recognized during input/output in extended address record, data is identified as one from bits 4 to 19 at the segment base address. The start data storage address for the subsequent data records is determined by start address and segment base address operations.

(1) Serial input and parallel input PG-1500 ← external device


(a) Extended address record



(b) Data record




(c) End record




(2) Serial output PG-1500 → external device


(a) Extended address record



(b) Data record



(c) End record



B.2 MOTOROLA EXORCISER

The MOTOROLA EXORCISER formats are described in (1) and (2) below.
Items <1> to <6> in (1) and (2) are explained below.

<1> Start mark

Format recognition is made by start mark [S].

<2> Record types

- a. Header record (optional) : [0]
- b. S1 data record : [1]
- c. S2 data record : [2]
- d. S3 data record : [3]
- e. End record (short address) : [9]
- f. End record (standard address) : [8]
- g. End record (long address) : [7]

<3> No. of byte counts

- a. Data record:
No. of bytes from the start address to the checksum value
- b. End record:
No. of bytes of the address value and the checksum value

<4> Address value



- a. Data record : Start address to be input
- b. End record : [0000]

<5> PG-1500 internal memory input or output data (data record only)


The start data address is the value indicated in <4>.

<6> Check sum


The least significant 8-bit data of one's complement obtained by adding data from byte count data to data in the frame just before the checksum.

(1) Serial input and parallel input PG-1500 ← external device**(a) Header record****(b) S1 data record**


(c) S2 data record




(d) S3 data record




(e) End record (short address)



(f) End record (standard address)




(g) End record (long address)




(2) Serial output PG-1500 → external device


(a) S1 data record




(b) S2 data record



(c) End record (short address)



(d) End record (standard address)





Remark In the case of output, the start address has less than 6 bytes. Thus, the [S3 data record] and [end record] following it do not exist.

B.3 EXTENDED TEKHEX

The EXTENDED TEKHEX formats are described in (1) and (2) below.
Items <1> to <7> in (1) and (2) are explained below.


- <1> Start mark
Format recognition is made by start mark [%].
- <2> Block length
Total of blocks excluding the start mark (including the block length)
- <3> Block types
 - a. Data block : [6]
 - b. Terminate block: [8]
 - c. Symbol block : [3]

All other numeric values result in an error.
When terminate block [8] is recognized, data load is stopped.
- <4> Check sum
Sum of hexadecimal numbers excluding the start mark and checksum value.
- <5> No. of address digits
No. of digits of the start data storage address following from the next block.
- <6> Address value
Address with the number of digits set in <5>.
Indicates the data address.
- <7> PG-1500 internal memory input or output data (data block only)
The start data address is the value indicated in <6>.


(1) Serial input and parallel input PG-1500 ← external device**(a) Data block****(b) Terminate block**

(2) Serial output PG-1500 → external device

(a) Data block



(b) Terminate block



Remark For output, the address display unit of the data block becomes 3 bytes (6 digits).

[MEMO]


APPENDIX C. EXTERNAL INTERFACE

This chapter describes the interface on the rear panel.

C.1 Serial Interface

The PG-1500 has an asynchronous serial interface and can be connected to a PC-9800 Series personal computer. The RS-232-C is used as an interface circuit.

Figure C-1. Serial Interface Connector



C.1.1 Pin configuration

The serial interface connector pins are positioned as follows.

Figure C-2. Serial Interface Pin Configuration




Table C-1. Serial Interface Connector Signal Table


Pin No.	Signal Name	Direction (PG-1500) – (External Device)	Function
1	FG	—	Frame ground
2	TXD	←	Data receive
3	RXD	→	Data transmit
4	RTS	←	Transmit enable at high level
5	CTS	→	Receive enable at high level
6	DSR	→	Receive enable at high level
7	SG	—	Signal ground
20	DTR	←	Transmit enable at high level

Caution Be sure to ground the power cable and FG pin of the PG-1500 and external devices. If an external device with FG and SG short-circuited is to be used, remove the FG interface cable.

C.1.2 Interface circuit

Figure C-3 shows the PG-1500 serial interface circuit (RS-232-C).

Figure C-3. RS-232-C Interface Circuit



C.1.3 Resetting

When a serial interface is used, set the following:

- Baud rate
- Parity bit
- XON/XOFF control
- Character length
- Stop bit

Execute resetting by key input.


For details of resetting, refer to Section 2.6.4 Serial Interface Setting (MODE) in Part II.

C.1.4 Handshake method

This section describes the handshake method in the serial interface.

(1) PG-1500 data output**(a) Hardware handshake**

In PG-1500 data transmission, hardware operations are only carried out when XON/XOFF control is set to OFF.

Figure C-4. Hardware Handshake

<1> DSR ON in serial mode

<2> DTR check

<3> Data set

<4> Wait for RTS ON

<5> Data transfer start

<1> DTR ON upon power-ON

<2> DSR check


<3> RTS ON

<4> Wait for data receive completion

<5> Data fetch

(b) Software handshake

In PG-1500 data transmission, software processing is carried out whether XON/XOFF control is ON or OFF.

Figure C-5. Software Handshake


- <1> PG-1500 transmits data.
- <2> External device receives data.
- <3> When the receive buffer becomes full, the external device generates ^S(X-OFF) transmit stop character.
- <4> Upon receipt of the transmit stop character, the PG-1500 stops data transmission.
- <5> When the receive buffer becomes empty, the PG-1500 generates ^Q(X-ON) transmit restart character.
- <6> Upon receipt of the transmit restart character, the PG-1500 restarts data transmission.

(2) PG-1500 data input

(a) Hardware handshake

In PG-1500 data reception, hardware processing is only carried out when XON/XOFF control is set to OFF.

Figure C-6. Hardware Handshake




- <1> DSR ON in serial mode
- <2> DTR check
- <3> CTS ON
- <4> Wait for data receive completion
- <5> Data fetch

- <1> DTR ON upon power-ON
- <2> DSR check
- <3> Data set
- <4> Wait for CTS ON
- <5> Data transfer start upon CTS ON

PG-1500 internal control method in hardware handshake is described below.


Figure C-7. Schematic Circuit Diagram of Serial Input Unit



- <1> PG-1500 has a 256-byte receive buffer in the work RAM.
- <2> Data from an external device is converted into parallel data in the SCU and sent to the receive buffer.
- <3> If the receive buffer receives 100 bytes or more data, $\overline{\text{MRDY}}$ signal in the V40 (CPU) turns OFF and the external device is notified of data receive disable.
- <4> When the receive buffer becomes 10 bytes or less, $\overline{\text{MRDY}}$ signal turns ON and the RBRDY signal of the SCU is connected to the external device, and thus, normal data reception is restarted.

(b) Software handshake

In PG-1500 data transmission, software processing is only carried out when XON/XOFF control is set to ON.

Figure C-8. Software Handshake

- <1> The external device transmits data.
- <2> PG-1500 receives data.
- <3> PG-1500 has a 256-byte receive buffer. If the receive buffer becomes 100 bytes or more, the PG-1500 generates ^S(X-OFF) transmit stop character.
- <4> Upon receipt of the transmit stop character, the external device stops data transmission.
- <5> When the receive buffer becomes 10 bytes or less, the PG-1500 generates ^Q(X-ON) transmit restart character.
- <6> Upon receipt of the transmit restart character, the external device restarts data transmission.

C.1.5 Connection example

This section describes the procedure of connecting a serial interface using NEC personal computer PC-9800 Series as an example.

Use an RS-232-C cable (straight type) for the connection with PC-9800.

The correspondence between the connecting cable signals and pins is shown in Table C-2.

Table C-2. Connection Cable and Signal Relations

PG-1500		PC-9800 Series	
Symbol Name	Pin No.	Pin No.	Symbol Name
FG	1	1	SG
TXD	2	2	TXD
RXD	3	3	RXD
RTS	4	4	RTS
CTS	5	5	CTS
DSR	6	6	DSR
SG	7	7	SG
DTR	20	20	DTR

Note

Note Connect pin No. 1 of PG-1500 to that of PC-9800 series only when the PG-1500 and external device (PC-9800 Series) FG are grounded.


C.2 Parallel Interface

The PG-1500 is equipped with an 8-bit parallel input interface.

The input data and interface control signals are all set to the TTL level.

The interface circuit is compliant with the Centronics.

Figure C-9. Parallel Interface Connector



C.2.1 Pin configuration

The parallel interface connector pins are positioned as follows.

Figure C-10. Parallel Interface Pin Configuration





Table C-3. Parallel Interface Connector Signal Table

Pin No.	Signal Name	Direction (PG-1500) – (External Device)	Function
1	PSTB	←	Data read timing signal
2	PDB0	←	Parallel data 0
3	PDB1	←	Parallel data 1
4	PDB2	←	Parallel data 2
5	PDB3	←	Parallel data 3
6	PDB4	←	Parallel data 4
7	PDB5	←	Parallel data 5
8	PDB6	←	Parallel data 6
9	PDB7	←	Parallel data 7
10	ACK	→	Signal to be output after data read
11	BUSY	→	Status signal indicating whether PG-1500 can acknowledge data or not
19 to 30, 33	GND	—	Signal ground

C.2.2 Interface circuit

Figure C-11 shows the PG-1500 parallel interface circuit.


Figure C-11. Parallel Interface Circuit



C.2.3 Handshake method

This section describes the handshake method in the parallel interface.

Figure C-12. Parallel Interface Timings



- <1> $\overline{\text{PSTB}}$ signal transmitted from the external device becomes active (low level).
- <2> BUSY signal is activated (high level) by the $\overline{\text{PSTB}}$ signal. Until the BUSY signal is canceled, the PG-1500 does not acknowledge the $\overline{\text{PSTB}}$ signal.
- <3> PG-1500 transmits the $\overline{\text{ACK}}$ signal by data read.
- <4> Next, the PG-1500 cancels the BUSY signal at the rising edge of the $\overline{\text{ACK}}$ signal and waits for the next data.

C.2.4 Connection example

This section describes the procedure of connecting a parallel interface using an NEC personal computer of the PC-9800 Series as an example.

Use a parallel interface cable (printer cable) for the connection with the PC-9800 Series personal computer. The correspondence between the connecting cable signals and pins is shown in Table C-4.

Table C-4. Connection Cable and Signal Relations

PG-1500		PC-9800 Series	
Symbol Name	Pin No.	Pin No.	Symbol Name
PSTB	1	1	PSTB
PDB0	2	2	PDB0
PDB1	3	3	PDB1
PDB2	4	4	PDB2
PDB3	5	5	PDB3
PDB4	6	6	PDB4
PDB5	7	7	PDB5
PDB6	8	8	PDB6
PDB7	9	9	PDB7
ACK	10	10	NC
BUSY	11	11	BUSY
GND	19	14	GND

Caution Be sure to ground the power cable and FG pin of the PG-1500 and external devices. If an external device with FG and SG short-circuited is to be used, remove the FG interface cable.

[MEMO]

Facsimile Message

From: _____

Name _____

Company _____

Tel. _____

FAX _____

Address _____

Although NEC has taken all possible steps to ensure that the documentation supplied to our customers is complete, bug free and up-to-date, we readily accept that errors may occur. Despite all the care and precautions we've taken, you may encounter problems in the documentation. Please complete this form whenever you'd like to report errors or suggest improvements to us.

Thank you for your kind support.

North America

NEC Electronics Inc.
Corporate Communications Dept.
Fax: 1-800-729-9288
1-408-588-6130

Hong Kong, Philippines, Oceania

NEC Electronics Hong Kong Ltd.
Fax: +852-2886-9022/9044

Asian Nations except Philippines

NEC Electronics Singapore Pte. Ltd.
Fax: +65-250-3583

Europe

NEC Electronics (Europe) GmbH
Technical Documentation Dept.
Fax: +49-211-6503-274

Korea

NEC Electronics Hong Kong Ltd.
Seoul Branch
Fax: 02-528-4411

Japan

NEC Corporation
Semiconductor Solution Engineering Division
Technical Information Support Dept.
Fax: 044-548-7900

South America

NEC do Brasil S.A.
Fax: +55-11-889-1689

Taiwan

NEC Electronics Taiwan Ltd.
Fax: 02-719-5951

I would like to report the following error/make the following suggestion:

Document title: _____

Document number: _____

Page number: _____

If possible, please fax the referenced page or drawing.

Document Rating	Excellent	Good	Acceptable	Poor
Clarity	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Technical Accuracy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Phase-out/Discontinued

Phase-out/Discontinued