


# MPP-80S / EPP-80 FAQ & Repair

v.2020/07

## BIOS:

Socket Numbering of Bios Eeproms is [wrong in User Manual](#)

Extraction from User Manual:



→ According to Schematics:



M4 = ----- = 2716 = Optional

L4 = "800" = 2716

K4 = "1000" = 2716

J4 = "1800 or 2000" = 2716

## Correct Layout is :



### Clean the following Semiconductor Pin's and IC Sockets:

