

SOP44	DIP40	ADP-29F800-PS DIP40	Pinout.txt SOP44
15	1	40	35
17	2	39	36
19	3	38	37
21	4	37	38
24	5	36	39
26	6	35	40
28	7	34	41
30	8	33-	-
16	9	32	42
18	10	31	5
20	11	30	6
22	12	29 (DIP18)	3
-	13-	28	8
27	14	27	9
29	15	26	10
31	16	25	11
34	17	24 (J3)	23 (J3)
3	18 (DIP29)	23	14
2	19	22-	-
32 (J1)*	20 (J1)*	21	12

Not.

SOP 1, 44, 23 connected to (J3) and DIP24
SOP 13* connected to (J1)
SOP 33 connected to (J2)

- (Not connected, unused)

J1, J2, J3 (Jumper)

J1 - Connected to SOP13
J2 - Connected to SOP33
J3 - Connected to DIP24 and SOP23

JP3 - Jumper function
Short 1 to 2: word
Short 2 to 3: Byte