

LOGIC ANALYZER EXTENDER


- - 10 MHz
- - 5 MHz
- - 2 MHz
- - 1 MHz
- - 500 kHz
- - 200 kHz
- - 100 kHz
- - 50 kHz
- - 20 kHz
- - 10 kHz
- - 5 kHz
- - 2 kHz
- - 1 kHz
- - 500 Hz
- - 200 Hz
- - 100 Hz

PRE-SAMPLE

CLOCK

4 / 8

EXT / INT



SAMPLE FREQUENCY

UP

DOWN

