Aymara → Français

English

RepairAllTV

Search here..

Home» MENU login or Register»

Forgot Password Administrator contact

RepairAlltv Subscriptions 1 to 10

Subscription, for download

Chat with us

Username or email address *

Password *

ERREUR pour le propriétaire du site :
Domaine non valide pour la

reCAPTCHA
Confidentialité - Conditions

Login

Remember me

Lost your password?

Not a member yet? Register now.

my channel youtube RepairAllTV

Recent Comments

oui on FUEGO 32EL610ANDT TP.MT5510S.PB803 EMMC Firmware Download

Jbadaoui sat on SHARP LC-48CFE4042E 25Q64 BIN T.MS3463S.711 Download

EEPROM MASCA Eprom / eeprom

November 11, 2021



Share post with Friends

Eprom / eeprom

The following are examples of chips

EEPROM

- 24c02= b58258
- 24c02= b58293
- 24c02= b58383
- 93c46= b58323
- 93c46= b58097
- 93CS46 = 58221

EPROM

- b57696= 27c256
- b57519= 27c256
- b57604= 27c256
- b57701= 27c256
- b57995= 27c256
- b58214= 27c256
- b58014= 27c256
- b57477= 27c256
- b58539= 27c256
- b57781= 27c256
- b58038= 27c256
- b58717= 27c256
- b58185= 87c257
- b58539= 87c257

abdodiag on TOSHIBA 50L7363D software Download

kami on SAMSUNG UE32D5700 BN41-01660 K9GAG08U0E BIN Download

dini792 on Vestel 17MB95S-1 Software Download

Recent Posts

FIAT MP3 312 SB05 RADIO BLOCKED/WAIT 95320 EEPROM

Xbox One S All Digital Edition 1681 EMMC FIRMWARE

LG 32LB550B-ZA EAX65361505 NAND DUMP DOWNLOAD

GRUNDIG 40VLE4324BF VTT190R-2 SOFTWARE DOWNLOAD

THOMSON REF-512330 25QH64 DUMP DOWNLOAD

TOSHIBA 40L1343DG 17MB95-2.1 SOFTWARE DOWNLOAD

- b57922= 87c257
- b58235= 87c257
- b58545= 87c257
- b58293= 27c512
- b58157= 27c512
- b58127= 27c512
- b58542= 27c512
- b58543= 27c512
- b58234= 27c512
- b58541= 27c512
- b58550= 27c512
- b58444= 27c010 32 pin dil
- b58549= 27c010 32 pin dil
- b58544= 27c010 32 pin dil
- b58399= 29f010 plcc
- b58547= 27c010 plcc eprom
- b58517= 27c010 plcc
- b58530= 27c010 plcc
- b58911= 27c010 plcc
- b58547= 28f010 plcc eprom
- b58293= 27c512 plcc
- b58550= 27c512 plcc
- b58381= 28f512 plcc
- b58275= 27c1024 plcc
- b58548= 27c1024 plcc
- b58400 ti 87510
- b5840 ti 87c510
- b58546 ti 87c510
- b58335=28c64
- b57856=28c64

RepairAllTV YOUTUBE

- b58334=28c64
- b57325= 27c32
- b58126= 27c010
- b58768= 29f200 o 29f400
- b57120= 27c64
- b57347= 27c64
- b57423= 27c256
- b57477= 27c64
- b57519= 27c64
- b57604= 27c256
- b57605= 27c256
- b57607= 27c128
- b57610= 27c128
- b57618= 87c257
- b57654= 27c256
- b57696= 27c256 plcc32
- b57701= 27c256
- b57764= 87c257
- b57808= 27c256
- b57922= 87c257
- b57995= 27c256
- b57995= 27c256
- b58014= 27c256
- b58038= 27c256
- b58094= 27c510
- b58126= 27c010 plcc32
- b58127= 27c512
- b58150= 87c257
- b58157= 27c512
- b58185= 87c257
- b58234= 27c256
- b58235= 87c257
- b58239= 27c512

- b58275= 27c1024 plcc44
- b58293= 27c512 plcc32
- b58331= 28f010 plcc32
- b58381= 28f512 plcc32
- b58399= 28f010 plcc32
- b58424= 27c512
- b58517= 28f020 plcc32
- b58530= am29f010 plcc32
- b58533= 27c4096 plcc44
- b58539= 27c256
- b58541= 27c512
- b58542= 27c512
- b58544= 27c1001
- b58545= 87c257
- b58546= 87c510
- b58547= 27c1001 plcc32
- b58548= tms27pc210 plcc44
- b58550= 27c512 plcc32
- b58639= 87pc110 plcc32
- b58755= am29f200 psop44
- b58768= am29f400ab psop44
- b58791= amf200ab pso44

30001 A/D CONVERTER ADC0809

30039 ????? ???????? ??????

30061 A/D CONVERTER ADC0809

30117 30424

30221 6-CHANNEL POWER DRIVE 30313

B22AN EEPROM 93C06

B34AB EEPROM 24C02

B42AB EEPROM 93C06 ??

B43AB EEPROM 24C02

B46AJ EEPROM 24C02

B49AJ EEPROM 24C02

B52AP EEPROM 24C02

B54AH EEPROM 24C02

B81AB EEPROM 93S66

B56022 EPROM 27C128

B56240 LM2902

B57120 A/D CONVERTER ADC0809

B57306 80C52

B57324 EPROM 2732A

B57325 EPROM 27C32

B57345 ULN2003

B57347 EPROM 27C64

B57383 CA139EX

B57402 LM2904

B57416 80C49

B57422 74HC74

B57423 EPROM 27C256

B57425 CD40106

B57427 A/D CONVERTER ADC0809

B57440 TWO TIMERS B556

B57449 74HC74

B57477 EPROM 27C64

B57487 74HCT573

B57515 80C52

B57519 EPROM 27C64

B57528 SAE81C52

B57545 LM2903

B57546 EPROM 27C010

B57549 74HC365

B57554 LM2903

B57574 74HCT573

B57558 74HCT00

B57560 74HCT02

B57574 74HCT373 ??

B57581 74HC573

B57582 LM2903N

B57604 EPROM 27C256

B57605 EPROM 27256

B57607 EPROM 27C128

B57610 EPROM 27C128

B57618 EPROM 87C257

B57618 EPROM 87C64

B57622 80C52

B57625 EPROM 2764A

B57647 8253, ??580??53

B57648 80C52

B57654 EPROM 27C256

B57656 MCU 80C535

B57677 BD206M

B57684 EPROM 27C256

B57696 EPROM 27C256

B57701 EPROM 27C256

B57725 TA13255A

B57733 4 x LOW-SIDE SWITCH TLE4211, TLE6220

B57764 EPROM 87C257

B57764 EPROM 87C64

B57769 MC68HC05SR3

B57771 EPROM 27C256

B57808 EPROM 27C256

B57820 TI948B

B57826 RAM HM6264

B57828 80C515

B57886 8051 ??

B57922 EPROM 87C257

B57945 87C52

B57960 EPROM 27C256

B57965 74HC14

B57995 EPROM TMS27C256

B58007 SAB80C517

B58010 RAM HM6264

B58014 EPROM 27C256

B58024 80C515

B58029 CA3272

B58038 EPROM 27C256

B58081 74HCT573 ??

B58085 ????? ?????? (6 ?? + ? 6 ?? -)

B58090 74HCT573 ??

B58094 EPROM 27C510

B58098 EPROM 27C512

B58108 6 x LOW-SIDE SWITCH TLE4216, TLE4226

B58115 RAM HM6264

B58126 EPROM 27C010

B58127 EPROM 27C512

B58150 EPROM 87C257

B58157 EPROM 27C512

B58185 EPROM 87C257

B58196 EEPROM NS93C46

B58213 EEPROM 93C06 ??

B58214 EPROM 27C256

B58234 EPROM 27C256

B58235 EPROM 87C257

B58239 EPROM 27C512

B58240 6 x LOW-SIDE SWITCH TLE4216G, TLE4226G

B58241 4 x LOW-SIDE SWITCH TLE4214G, TLE6225

B58243 EPROM CJ87BC6QG

B58244 I87M12

B58252 EEPROM 24C02

B58253 EEPROM 24C02

B58256 EEPROM 24C01

B58258 EEPROM 24C02

B58265 CONTROLLER CANController ??

B58275 EPROM 27C1024

B58275 EPROM 27C1024

B58286 CONTROLLER SAB80C166

B58290 6 x LOW-SIDE SWITCH TLE4226G

B58291 TLE5205-2

B58293 EPROM 27C512

B58298 80C515 ??

B58323 EPROM 93C46

B58331 EPROM 28F010

B58334 EEPROM 28C64

B58335 EEPROM AT28C64B

B58339 28F512

B58380 EEPROM 24C02

B58381 EPROM AM28F512

B58399 EPROM AM29F010

B58400 EPROM 87C510

B58424 EPROM 27C512

B58444 27C010

B58468 SAB80C517

B58470 80C535

B58474 SAB80C517

B58484 SAB80C517

B58502 ABS, ASR SYSTEM IC TLE5200G, TLE6210G

B58504 ABS, ASR SYSTEM IC TLE5201G, TLE6211G

B58505 2 x LOW-SIDE SWITCH TLE5225G, TLE6215G

B58517 EPROM 27C020, 27C2001

B58530 EPROM 27C010, 28F010, 29F010

B58533 EPROM 27C4096

B58539 EPROM 27C256

B58541 EPROM 27C512

B58542 EPROM 27C512

B58543 EPROM 27C512

B58544 EPROM 27C1001

B58545 EPROM 87C257

B58546 EPROM 87C510

B58547 EPROM 27C1001 , 27C010

B58547 EPROM 27C1001, 27C010

B58548 EPROM TMS27PC210, 27C1024

B58550 EPROM 27C512

B58553 SCL4410

B58590 AS87C196EN

B58601 EPROM AM29F200B

B58608 93C66

B58637 4 x LOW-SIDE SWITCH TLE5226G, TLE6216G

B58639 EPROM 87C510 (87PC110 ??)

B58647 87C257

B58718 27C512

B58732 4 x LOW-SIDE SWITCH TLE5216G, TLE6220

B58748 SAB83C166

B58755 EPROM AM29F200

B58768 EPROM AM29F400AB

B58791 EPROM AM29F200AB

B58813 EEPROM 93C56

B58838 EPROM 27C256

B58911 EPROM TMS27C010A

B58944 uPD43256BGU-70

B9411 EPROM AM27C256

DELCO

8393 POWER AMPLIFIER TDA7372A

96405 POWER AMPLIFIER TDA7376B

6263665 EEPROM ?? 93C ??

9355092 EEPROM 24C04

9355093 EEPROM 24C08

9999099 EEPROM 24C08

16045153 8-CHANNEL MULTIPLEXER 4051

16124342 POWER AMPLIFIER TDA7360

16127475 MC68HC11F1

16163762 MC68HC11E9

16175974 RDS DEMODULATOR SAA6579

16202476 MC68HC11F1

16219796 POWER AMPLIFIER TDA7454 or TDA7385

16233541 EPROM M27C256B

PIONEER

PA2024A REGULATOR TA8244H

PA3002 POWER AMPLIFIER HA1397

PA3005 POWER AMPLIFIER HA1384

PA3027A POWER AMPLIFIER HA13150A

PA3029A POWER AMPLIFIER HA13151

PA3029B POWER AMPLIFIER HA13151

PAL001A POWER AMPLIFIER TDA7394

PAL002A POWER AMPLIFIER TDA7394

PAL003A POWER AMPLIFIER TDA7384A

PAL005A POWER AMPLIFIER TDA7385

PAL006A POWER AMPLIFIER TDA7560

PAL007A POWER AMPLIFIER TDA7560

PAU001A POWER AMPLIFIER HA13151

VISTEON

0022FBCAC REGULATOR TL751M10

0040FBCAC REGULATOR TL751M10

77002 I2C EEPROM 24C16

7008FB REGULATOR 78L05

70001AB POWER AMPLIFIER TDA2005

70001BB RDS DEMODULATOR TDA7330

70001SE RDS DEMODULATOR TDA7330

70001RR RDS DEMODULATOR TDA7330 ??

70002FE AUDIO PROCESSOR TDA7311

70003AB POWER AMPLIFIER TDA2003

70003SC FREQ. SYNTH.

70003SE RDS DEMODULATOR TDA7330

70005EB PLL STEREO DECODER TDA1591

70005EH AUDIO PROCESSOR TDA7340P

70006SE AUDIO PROCESSOR TDA7340

70008AB POWER AMPLIFIER TDA7360

70009AB POWER AMPLIFIER

70010AB POWER AMPLIFIER TDA7350

70010BB DUAL PREAMPLIFIER TDA3420

70010FB REGULATOR TL751M10

70011AB POWER AMPLIFIER TDA7360 100%

70011FB

70011SB AUDIO PROCESSOR TDA1524

70014BB OPERATIONAL AMPLIFIER LM837

70016SE AUDIO PROCESSOR TDA7460N

70017AB LINE DRIVER TDA7237

70017FB REGULATOR TA14832

70019SB AUDIO PROCESSOR

70020FB

70023AB POWER AMPLIFIER TDA7391

70024AB POWER AMPLIFIER TDA7375

70024SB DOLBY CIRCUIT TEA0655

70025SB AMS LA2010

70026SB FRONT END

70027SB

70028SB IF/DET

70029SB AUDIO PROCESSOR TDA7306

70032AB PREAMPLIFIER TDA1523 ??

70033BB OPERATIONAL AMPLIFIER LM837

70034AB POWER AMPLIFIER TDA1519B

70039AB POWER AMPLIFIER TDA8566Q

70042FB REGULATOR L084, L4953G

70043AB POWER AMPLIFIER TDA8586Q

70045SB DOLBY CIRCUIT TEA0675

70047SB DOLBY CIRCUIT TEA0675T

70052AB POWER AMPLIFIER TDA8586Q

70082FB REGULATOR

70530FB REGULATOR

70670FS PREAMPLIFIER TEA0676T

71005DC LCD DISPLAY DRIVER PCF8577

71005TB MULTIPOINT TRANSCEIVER DS36277

N7100130 PCF8576T

N700700CFFB000 REGULATOR

N760005WFKC632 MCU MC68HC11E9

F2DF-14A652-EA REGULATOR TL751M10

SONY

159-00 POWER AMPLIFIER HA13151

160-00 POWER AMPLIFIER HA13151

180-00 POWER AMPLIFIER HA13152

260-41 POWER AMPLIFIER HA13151

260-77 POWER AMPLIFIER HA13150A

279-82 POWER AMPLIFIER HA13151

279-87 POWER AMPLIFIER HA13151

279-89 POWER AMPLIFIER HA13152

360-47 POWER AMPLIFIER HA13153

365-41 POWER AMPLIFIER HA13155

368-11 ELECTRONIC VOLUME LC75372E

369-41 POWER AMPLIFIER HA13155

369-42 POWER AMPLIFIER HA13153

426-49 POWER AMPLIFIER HA13155

448-48 POWER AMPLIFIER HA13157

448-61 POWER AMPLIFIER HA13156

490-48 POWER AMPLIFIER HA13158

PICKUPS

OPTIMA-150S JVC OPTIMA-6S

KSP-1H KENWOOD KSS-213F

RAE0142Z MATSUSHITA RAE0144

1121 SONY KSS-210A

KSS-168A SONY KSS-320B

KSS-412A SONY KSS-401A

KSS-401A SONY KSS-412A

KSS-313A SONY KSS-313C

KSS-240 SONY KSS-390

KSS-314A SONY KSS-313A ? ??????????

??????

SOH-AAU SAMSUNG KSS-213

KSS-540A SONY KSS-541A

KSS-520A SONY KSS-521A

MOTOROLA

MC13304T3 POWER AMPLIFIER TA8215

MC13306T3S POWER AMPLIFIER TA8205

MC13309T3 POWER AMPLIFIER TA8215

MC13320T3 POWER AMPLIFIER

CHRYSLER

4234547 POWER AMPLIFIER TDA1516

4632512 AUDIO PROCESSOR TDA7314S

4632512 AUDIO PROCESSOR TDA7314S

4651311 POWER AMPLIFIER TDA1553Q

4391943 74HC00

4392073 27C256

4392075 74HC14

4517571 74HC373

4517572 74HC74 ??

4632511 TDA1591T

4632858 TDA3601AQ

4632990 M28F102

4651350 L9222A

OTHERS

M851G OKI , EEPROM 93C46

16811G OKI , EEPROM 93C46

16911 OKI , EEPROM 59C11

A21SC EEPROM 24C02

A51SC EEPROM 24C16

ADxxxx YAZAKI, EEPROM 93C46 8-bit

ABxxxx YAZAKI, EEPROM ER59C11 8-bit

SN76396 TBA396

80HF ROHM, EEPROM BR9080

SL394 SEIKO, EEPROM S-29L394

V2485I-Z2006 OKI 80C52

repairalltv.com

0

Article Rating

Subscribe

Connect with | login

300

Be the First to Comment!

Name

Email

Post Comment

0 COMMENTS