



Programming Systems

EPP-1F & EPP-2

Installation Manual



Dear User

Thank you for buying an ART EPP programmer.

What Do You Need To Get Started?

To connect the EPP programmer to a PC you need a standard 1:1 RS232 Male Female serial cable. To power the programmer just plug in a power cable. After using the programmer, it is recommended to remove the power cable.

Installation

The installation of both the Windows and DOS software should be easy.

Windows 3.1x:

Copy the files of both disks to a temporary directory on your harddisk. Now run 'SETUP.EXE' from this directory. The setup procedure will install the program for you. Online help is available.

Windows 95/98:

Insert disk 1/2 in your drive and run 'SETUP.EXE' on the disk. The setup procedure will install the program for you. Online help is available.

DOS:

Copy the files in the directory DOS on disk 1/2 to a subdirectory on your harddisk. You are now ready to use the programs. See the 'README' file for further information.

Starting The Program

Follow the instructions carefully.

Windows 3.1x:

Double click on the PromProg for Windows icon. The first time you start the program you need to change the communication and programmer settings. Press the HELP button from the welcome screen to get started.



Windows 95/98:

Double click on the PromProg for Windows icon, or select PromProg for Windows from the start menu. The first time you start the program you need to change the communication and programmer settings. Press the HELP button from the welcome screen to get started.

Please turn the used serial port's FIFO buffers off in the Control Panel (System, Device Manager, Ports, COM X, Port Settings, Advanced). More about this subject in the 'Trouble Shooting' section of the help file.

DOS:

Change to the directory you copied the files to. Type 'PROMPROG.EXE' and press ENTER. It is not recommended starting PromProg directly from disk.

Trouble Shooting (Windows)

When PromProg for Windows does not run, open the help file ('PPW_US.HLP') from the file manager (explorer in Windows 95). This file is in the 'LIBRARY' subdirectory of the PromProg directory (usually 'C:\ART\PPW\LIBRARY'). This file contains part of the FAQ (Frequently Asked Questions), which could help you.

The FAQ list is also available on our WebSite.

How To Get More Information?

The WebSite (<http://www.artbv.nl>) contains a wide variety of information, links, software and tools that are useful for every user.

If you still have questions or problems, e-mail Programming Systems at: artbv@iae.nl

We hope you enjoy working with your EPP programmer.

International copyright laws protect this manual and software described in it. This manual or the software may not be copied, in whole or in part, without written consent of Programming Systems B.V., except in the normal use of the software or to make a backup copy.

Programming Systems B.V. is not responsible for any damage while using programmer hardware, software or manual.

Programming Systems B.V.:

Telephone: +31- 40 - 248 26 35

Fax: +31- 40 - 248 02 95

WebSite: www.artbv.nl

E-mail: artbv@iae.nl