


Thermal panel printer FT190 24/40 User's manual



Printer components

- 1- Print mechanism
- 2- Case
- 3- Paper outfeed
- 4- Paper loading label
- 5- Front panel
- 6- Paper roll compartment
- 7- Keypad
- 8- Feed connector
- 9- Paper winder connector
- 10- Interface connector
- 11- Outside "Print" key connector



All rights reserved. The reproduction of this manual, either totally or partially, in any form whatsoever, whether it be on paper or through computer processes, is strictly prohibited. Custom Engineering s.r.l. and the resource teams employed in the making of this manual will not be held responsible for any problems arising as a result of improper use of this manual, as they guarantee that the information contained in it has been subjected to careful inspection.

Any suggestions regarding errors in its contents or possible improvements will, nonetheless, be greatly appreciated. The products are continuously checked and improved. For this reason Custom Engineering s.r.l. reserves the right to modify the information contained in this manual without prior notice.

COD. DOME-FT190

Revision 1.20

Copyright © 1998 Custom Engineering s.r.l. – Italy

Custom Engineering

Str. Berettine 2 - 43010 Fontevivo (PARMA) - Italy

Tel. : +39 0521-680111 - Fax : +39 0521-610701

[http: www.custom.it](http://www.custom.it) Email : support@custom.it

"CE" Declaration of Conformity

In accordance with standards ISO/IEC Guide 22 and EN 45014

N°:
DC0302698

Manufacturer's name: Custom Engineering s.r.l.

Manufacturer's
address: Strada Berettine 2
Fontevivo (Parma)
Italy

Declares that the product:

Product name: Panel printer with thermal print mechanism

Type name: FT190

Model: FT190 TTL

is in conformity with the following directives:

Electromagnetic compatibility directives EEC/89/336; EEC/92/31; EEC/93/68

In accordance with the following standards:

EN 55022 Class B	Limits and methods of measurement of radio disturbance characteristics of information technology equipment	1995
EN 50082-1	Electromagnetic compatibility - General immunity standard. Part 2: Industrial environments.	1992
EN 61000-4-2	Electrostatic discharge requirements 4KV contact discharge, 8KV air discharge	1995
EN 61000-4-4	Fast electrical transient/burst requirements. DC mains 0.5KV	1995
ENV 50140	Radiated radio-frequency electromagnetic fields. Immunity tests. 3V/m, 80MHz-1000MHz, 80% 1KHz AM	1993

June 1998

INTRODUCTION

CONTENTS OF THE MANUAL	1
CONVENTIONS USED IN THE MANUAL	1
GENERAL INFORMATION REGARDING SAFETY	1
UNPACKING THE PRINTER	3
GENERAL FEATURES	3
DESCRIPTION OF THE PRINTER	4

1. INSTALLATION AND USE

1.1 CONNECTIONS	1-1
1.1.1 Power supply	1-1
1.1.2 Logic circuitry	1-2
1.2 CONFIGURATION	1-5
1.3 AUTOTEST	1-6
1.4 HEXADECIMAL DUMP	1-6
1.5 MAINTENANCE	1-7
1.5.1 Changing the paper roll	1-7

2. INTERFACES

2.1 TTL SERIAL	2-1
2.2 TTL PARALLEL	2-2
2.3 CALENDAR CLOCK (OPTIONAL)	2-3
2.3.1 Adjusting the clock through the keypad	2-3

3. PRINTER FUNCTIONS

3.1 PRINT DIRECTION	3-1
3.2 CONTROL CHARACTERS	3-2

4. TECHNICAL SPECIFICATIONS

4.1 TECHNICAL SPECIFICATIONS	4-1
4.2 DIMENSIONS	4-2

5. CHARACTER SETS

5.1 CHARACTER SETS	5-1
--------------------------	-----

ATTACHMENT A - ACCESSORIES AND SPARE PARTS

A.1 ACCESSORIES.....	A-1
A.1.1 PSM05 Power supply	A-1
A.1.2 AV03 Rewinder	A-2
A.2 SPARE PARTS	A-3

CONTENTS OF THE MANUAL

In addition to the introduction which lists: the conventions used in the manual, general information relative to safety, unpacking of the printer and a brief description of the printer itself, highlighting its main features, the manual is split up into the following chapters:

Chapter 1: Containing the information required for installing and using the printer correctly

Chapter 2: Containing the specifications of the interfaces

Chapter 3: Containing the description of the printer command set

Chapter 4: Containing the technical specifications of the printer

Chapter 5: Containing the character sets (fonts) used by the printer

CONVENTIONS USED IN THE MANUAL

N.B.



Gives important information or suggestions relative to the use of the printer

WARNING



The information marked with this symbol must be carefully heeded to safeguard against damaging the printer

DANGER



The information marked with this symbol must be carefully heeded to safeguard against injury to the operator

GENERAL INFORMATION REGARDING SAFETY

- Read and keep the following instructions.
- Observe all warnings and follow all instructions attached to the printer.
- Before cleaning the printer, disconnect the feed cable.
- Clean the printer with a damp cloth. Do not use liquid or spray products.
- Do not operate the printer near to water.

- Do not place the printer on unsteady surfaces. It could fall and get seriously damaged.
- Use the type of electricity supply marked on the printer label. In the event of uncertainty, contact the seller.
- Position the printer in such a way as to ensure that the cables connected to it will not be damaged.
- Ensure that the maximum absorbed current of the printer does not exceed the maximum acceptable current for the type of feed cable used.
- Do not put objects of any kind inside the printer as they could cause a short circuit or damage parts which could affect its performance.
- Do not spill liquids on the printer.
- Do not carry out technical operations on the printer with the exception of the scheduled maintenance operations specifically indicated in the user's manual.
- Disconnect the printer from the electricity supply and have it repaired by a specialized technician should any of the following conditions occur:
 - A. The feed connector has been damaged.
 - B. Liquid has penetrated to the inside of the printer;
 - C. The printer has been exposed to rain or water;
 - D. The printer is not operating normally despite the instructions in the user's manual having been followed.
 - E. The printer has been dropped and its case damaged.
 - F. The performance of the printer is poor.
 - G. The printer does not work.

UNPACKING THE PRINTER

Remove the printer from the box, taking care not to damage the packing material, as it could be needed for future transportation of the machine.


Ensure that all the components illustrated are in fact present and that they are in perfect condition. If this is not the case, contact the after-sales assistance department immediately.

Printer

Manual (or Cdrom)

Paper roll (inside the printer)

Long screws



GENERAL FEATURES

The FT190 is a printer which, in addition to having an innovative design, guarantees high performance and is reliable and user-friendly.

For these reasons, it is the ideal solution for applications which require the immediate printing of data on a ticket, whether they be of an industrial, professional or laboratory nature. Typical fields of application are: weighing systems, receipts (not for tax purposes) as well as for security, controlling and diagnostics purposes.


It has a 200 dpi thermal print mechanism and uses 57.5mm paper rolls. It can print 24 or 40 characters per line according to the selection made at the setup stage through the software command.

The FT190 printer is so compact and lightweight that it can be installed extremely easily on any type of equipment. It is supplied with TTL serial and parallel interfaces and has a 1Kbyte reception buffer. It can also be equipped with a Real Time Clock.

DESCRIPTION OF THE PRINTER

The FT190 printer has an ABS casing (1) with a front cover (2) which opens to allow access to the paper roll and print head.


The control panel is located on the front (3) and has a PRINT key, a FEED key and two LEDs: Power and Status.



(Figure 2)

- **PRINT key.** When enabled it outputs, in parallel, the logic state “0” on pin 4 of J1, while in serial it brings about the transmission of the control character “\$0D”, if this has been enabled at the printer setup stage. In parallel on PRINT key there is a connector J6 used for the connection to outside key (figure 1.1).
- **FEED key.** When this is pressed, the paper feeds forward manually. If this key is pressed briefly, when the RTCK option is installed, the date and time of day is printed.
- **The POWER LED** indicates that the the printer is receiving a digital power supply.
- **The STATUS LED**, when flashing, signals that the paper is finished. When lit steadily, it signals the presence of an error (head power supply too high or too low or head temperature too high).

1.1 CONNECTIONS



1.1.1 Power supply

The FT190 printer is equipped with a standard 4-pin male AMPMODU1-type connector (J7). The signals on the connector pins are as follows:

PIN	SIGNAL	NOTES
1	GND	
2	GND	
3	+VT: from 4.5 Vdc to 7 Vdc	(head power supply)
4	+VDC: 5 Vdc \pm 7%	(logic card power supply)

(Table 1.1)



WARNING

Respect the polarity of the power supply.

It is possible to avoid connection with the feed connector (J7) by using the logic circuitry's flat 26-pin connector (J1) on request at the time of ordering, thus connecting the printer's power supply and signals with a single cable. In this case, however, the flat cable must not exceed 30 cm in length because, when electrical current runs inside small diameter wires, voltage failures can occur, thus interfering with the correct operation of the printer.

For the pin pattern relative to feeding through the logic's flat connector, please refer to the following paragraph.

1.1.2 Logic circuitry

In the 20-pin connector J1, the signals are arranged as follows:

PIN	SIGNAL	PIN	SIGNAL
1	+VT	2	+VT
3	+VDC	4	+VDC
5	GND	6	GND
7	TD	8	D6
9	D5	10	D4
11	D3	12	D2
13	D1	14	D0
15	D7*	16	RESET
17	PSE	18	READY/RTS
19	FEED	20	STB/RD

(Table 1.2)

In the 26-pin connector J1, the signals are arranged as follows:

PIN	SIGNAL	PIN	SIGNAL
1	GND	2	GND
3	GND	4	TP
5	+VT	6	+VT
7	+VT	8	+VT
9	+VDC	10	+VDC
11	GND	12	GND
13	TD	14	D6
15	D5	16	D4
17	D3	18	D2
19	D1	20	D0

1. INSTALLATION AND USE

PIN	SIGNAL
21	D7 *
23	PSE
25	FEED

PIN	SIGNAL
22	RESET
24	READY/RTS
26	STB/RD

(Table 1.3)

*The D7 signal is not taken into consideration in the event of 7-bit programming of the parallel port. In order to configure the FT190 with the extended character set, the parallel interface must be 8-bit programmed.

The signals indicated have the following functions:

GND: signal and power supply ground;

+VT: head power supply;

+VDC: logic card power supply;

PSE (input): serial/parallel interface selection. If shortcircuited to ground (0) it enables serial communication; if free (1) it enables parallel reception;

D0, ..., D7 (inputs): data buses. In the parallel configuration, these correspond to the printer input data bus (the high level indicates binary digit 1). In serial communication, if the serial parameter selection has been chosen through the connector, these are used to determine communication speed and reception protocol. Normally, the data bus is on logical level 1: to obtain logical level 0, shortcircuit to ground (GND).

The serial baud rate is settable as shown in the table below:

	D0	D1	D2	BAUD
	0	0	1	300
	1	0	1	600
	1	1	1	1200
	0	1	1	2400
	0	0	0	4800
(Table 1.4)	1	0	0	9600

All other combinations select the speed at 1200 baud.

D3 = 1: flag type transmission protocol. When the print buffer is full, the printer sends a low level on the RTS signal, which interrupts transmission; when the buffer is able to receive more data, the level of the RTS signal changes to 1.

D3 = 0: XON/XOFF type transmission protocol. When the print buffer is full, the printer sends a XOFF \$13 (DC3) command, which interrupts transmission; when the buffer is able to receive more data, the command XON \$11 (DC1) signal is transmitted.

D5, D6, D7: the selection of these bits causes the configuration of the serial with the transmission format listed in the table below:

	D7	D6	D5	Format
	1	1	1	8 parity none bits and 1 stop bit
	0	1	1	8 parity EVEN bits and 1 stop bit
	0	1	0	8 parity ODD bits and 1 stop bit
	1	1	0	7 parity none bits and 1 stop bit
	1	0	1	7 parity EVEN bits and 1 stop bit
(Table 1.5)	1	0	0	7 parity ODD bits and 1 stop bit

Remember that in order to configure the printer in serial mode, the signal PSE must be shortcircuited to ground on connector J1.

RESET (input): reset card controller, active at low level. The reset initializes the printer parameters, with the following effects:

- the line buffer and print buffer are erased;
- the print format is selected according to programming;

- the PSE pin of J1 is read for serial or parallel configuration;
- the autotest is printed, on pressing the FEED key;
- the functioning of any optional cards installed is checked.

READY/RTS (output): in the parallel configuration the high level indicates that the printer is ready to receive data. A low level indicates that the printer is busy. In serial communication, the high logic state (1) indicates that the printer is ready to receive data; the low logic state (0) indicates that the print buffer is full and cannot accept data.

FEED (input and output): paper feed key, active at low level. This signal is in parallel to the contacts of the FEED key on the front of the printer.

STB/RD (input): in the parallel configuration, a low level indicates to the printer that there is valid data on the data buses (D0, ..., D7). In the serial configuration, it corresponds to the data reception pin.

TP (input and output): PRINT key, active at low level. This signal is in parallel to the contacts of the PRINT key on the front of the printer.

1.1.3 Outside Print key

To the connector J6 (figure 1.1) can be related an outside Print key. The polarity and the signal's function are as follows (table no. 1.6):

(Table 1.6)

Pin	Signal
1	PRINT
2	GND

1.1.4 Rewinder

The connector J4 (1.1) is used to feed the outside rewinder. The position and the signal's function are as follows (table no. 1.7):

(Table 1.7)

Pin	Signal
1	MOTOR+
2	MOTOR -

1.2 CONFIGURATION

The FT190 enables the configuration of the printer default parameters. This procedure is enabled by holding down the PRINT and FEED keys while switching on, with the jumper JP2 present on the printer card open. After this, each time the PRINT key is pressed, the parameter is modified and its current value is printed. Once the required value has been obtained, press the FEED key to proceed to the next parameter, and so on. Once all the parameters have been run through, the printing of a message signals the end of the setting procedure.

The parameters affected during configuration are:

- Selection of the number of columns (24 or 40)
- Print direction (normal or reverse)
- Selection of the character dimensions (normal, double width, double height, expanded)
- Selection of the font (font 1 or font 2)
- Enabling or disabling of the CR command
- AUTOFEED enabling or disabling : if the function is enabled when the printer receives a characters number equal to the line buffer the next character will place on the left margin in a new line
- Selection of the print speed in function of the absorption
- Selection of the red intensity : using two-colour thermal paper is possible to set different red tonality
- Selection of the parameters for serial and parallel communication
- Enabling or disabling of the 1Kbyte buffer
- Enabling setting of the real time clock
- Enabling of seconds printing in the real time clock function.

The settings made are saved on the EEPROM (non volatile memory).

1.3 AUTOTEST

To run the autotest, hold down the FEED key, while switching on the printer. The autotest causes the printing of the printer's current setting data and the printing of the complete ASCII character set.

1.4 HEXADECIMAL DUMP


If the PRINT key is held down during switching on, the printer enters Hexadecimal Dump mode. This function is used for the diagnostics of characters received in serial or parallel. In fact, these are printed in hexadecimal code together with the corresponding Ascii code.

1.5 MAINTENANCE

1.5.1 Changing the paper roll

To change the paper roll, proceed as follows:

- 1) Open the printer cover and press down the swinging support of the print mechanism at the point marked PUSH;
- 2) Insert the end of the paper roll in the slit of the print mechanism and position the paper roll so that it rotates in the right direction, as shown in the figure;
- 3) The paper is automatically pulled by the roller for 3 or 4 centimetres;
- 4) Tear off the paper and re-close the cover.



(Figure 1.2)



WARNING


Before inserting the paper, ensure that it is cut evenly

2. INTERFACES

The selection of the standard interface, TTL serial and parallel, is given by the status of the PSE pin of J1.

2.1 TTL SERIAL

In the serial protocol, the signals which distinguish the communication are TD, RD, and RTS if the RTS/CTS protocol has been selected while, if the XON/XOFF protocol has been selected, the signals are TD and RD.




(Figure 2.1)

2.2 TTL PARALLEL


In the parallel communication the signals which can be used are:

- 1) 7 or 8 bit data buses;
- 2) STROBE signal indicating the validity of the data;
- 3) READY signal indicating that the printer is ready to receive data.

Transmission format



Flow diagram



(Figure 2.2)

2.3 CALENDAR CLOCK (optional)

The Real Time Clock is available as an option. Printing and adjustment of the clock are managed by a series of control characters, described as follows.



N.B.

For the real time clock control characters, please refer to description of the printer command sets in chapter 3

2.3.1 Adjusting the clock through the keypad


The time and date can be adjusted using the PRINT and FEED keys on the printer's front panel. To set, proceed as follows:

- While holding down the FEED key, press the PRINT key. The printer will print the time and date with an arrow indicating the digit to be modified;
- Each time the PRINT key is pressed, the digit marked by the arrow will increase and an updated version will be printed;
- To proceed to modify another digit, press the FEED key again. Each time the printer will print the updated time and date, highlighting with an arrow the currently selected digit;
- To terminate the setting procedure, press PRINT and FEED at the same time.

3. PRINTER FUNCTIONS

3.1 PRINT DIRECTION

The FT190 printer has two printing directions which can be selected by means of the control characters: normal and reverse.



(Figure 3.1)

3.2 CONTROL CHARACTERS

The command table lists all the commands for the management of the FT190 printer functions. These commands can be transmitted to the printer with both the serial and parallel interfaces; if, however, the parallel interface is being used, the user will not be able to receive any kind of response, as this interface is mono-directional.

The commands can be transmitted to the printer at any moment, but they will only be carried out when the characters previously transmitted have been printed or the commands previously transmitted have been carried out.

There are no commands with priority status; all the commands are carried out when the circular buffer is free to do so.

(Table 3.1) **COMMAND TABLE**

ASCII Com.	HEX Com.	Description
	\$00	Prints in small characters
	\$01	Prints in double width
	\$02	Prints in double height
	\$03	Expanded printing
	\$04	Restores small character printing
	\$0A	Forward feeds one line
	(n) \$0B	Forward feeds (n) line
	\$0D	Prints line buffer
	\$0F	Sets CRLF mode
	\$11	Graphic mode
	\$12	Prints time and date
	\$13	Sets time and date
	\$14	Transmits time and date in serial
	\$17	Prints 1st programmable character
	\$18	Prints 2nd programmable character
	\$19	Prints 3rd programmable character
	\$1A	Prints 4th programmable character
	\$1C	Prints 5th programmable character
	\$1D	Prints 6th programmable character

3. PRINTER FUNCTIONS

ASCII Com.	HEX Com.	Description
	\$1E	Prints 7th programmable character
	\$1F	Prints 8th programmable character
ESC A	\$1B \$41	Executes [n] dots line feed
ESC R	\$1B \$52	Sets reverse mode printing
ESC N	\$1B \$4E	Sets normal mode printing
ESC @	\$1B \$40	Resets the printer
ESC D	\$1B \$44	Enters date in print buffer
ESC T	\$1B \$54	Enters time in print buffer
ESC U	\$1B \$55	Enters date (mm:dd:yy) in print buffer
ESC S	\$1B \$53	Enables printing of seconds
ESC X	\$1B \$58	Prints in red
ESC x	\$1B \$78	Prints in black
ESC B	\$1B \$42	Sets character font 1
ESC b	\$1B \$62	Sets character font 2
ESC I	\$1B \$49	Selects 24 columns
ESC i	\$1B \$69	Selects 40 columns
(aa) ESC r	(aa) \$1B \$72	Reads data at an address (aa)
(aadd) ESC w	(aadd) \$1B \$77	Writes data (dd) in an address (aa)
(dd) ESC G	(dd) \$1B \$47	Writes value (dd) in option register
(dd) ESC K	(dd) \$1B \$4B	Writes value (dd) in option register 1
(dd) ESC M	(dd) \$1B \$4D	Writes value (dd) in print mode
ESC p	\$1B \$70	Transmits option register in serial
ESC k	\$1B \$6B	Transmits option register 1 in serial
ESC m	\$1B \$6D	Transmits print mode in serial
ESC s	\$1B \$73	Transmits next character in serial
(dd) ESC a	\$1B \$61	Selects number of dot spaces
ESC J (n)	\$1B \$4A	Loads programmable character
ESC W	\$1B \$57	Prints graphic line of 200 dpi
ESC c	\$1B \$63	Management of bar code printing
ESC Q	\$1B \$51	Enables underlining
ESC q	\$1B \$71	Disables underlining

A more detailed description of the single commands can be found below.

00H

[Name]	Small character printing
[Format]	ASCII - Hex 00 Decimal 0
[Description]	The printer prints in small characters (normal)
[Notes]	<ul style="list-style-type: none">• The commands 00H - 09H do not cancel the print buffer• The commands which modify the direction of the characters are only active at the beginning of the line
[Default]	Setting in option register by means of front keys
[Reference]	01H, 02H, 03H, 04H
[Example]	

01H

[Name]	Double width printing
[Format]	ASCII - Hex 01 Decimal 1
[Description]	The printer prints in double width format
[Notes]	<ul style="list-style-type: none">• The commands 00H - 09H do not cancel the print buffer• The commands which modify the direction of the characters are only active at the beginning of the line
[Default]	Setting in option register by means of front keys
[Reference]	00H, 02H, 03H, 04H
[Example]	

02H

[Name]	Double height printing
[Format]	ASCII - Hex 02 Decimal 2
[Description]	The printer prints in double height format
[Notes]	<ul style="list-style-type: none">• The commands 00H - 09H do not cancel the print buffer• The commands which modify the direction of the characters are only active at the beginning of the line

3. PRINTER FUNCTIONS

[Default]	Setting in option register by means of front keys
[Reference]	00H, 01H, 03H, 04H
[Example]	

03H

[Name]	Expanded printing
[Format]	ASCII - Hex 03 Decimal 3
[Description]	The printer prints in expanded character mode
[Notes]	<ul style="list-style-type: none">• commands 00H-09H do not cancel the print buffer• the commands which modify the dimensions of the characters are only active at the beginning of the line
[Default]	Setting in the option register by means of the front keys
[Reference]	00H, 01H, 02H, 04H
[Example]	

04H

[Name]	Restore small character printing
[Format]	ASCII - Hex 04 Decimal 4
[Description]	The printer resumes printing with small characters
[Notes]	<ul style="list-style-type: none">• commands 00H-09H do not cancel the print buffer• the commands which modify the dimensions of the characters are only active at the beginning of the line
[Default]	Setting in the option register by means of the front keys
[Reference]	00H, 01H, 02H, 03H
[Example]	

0AH

[Name]	Forward feeds one line
[Format]	ASCII - Hex 0A Decimal 10
[Description]	Forward feeds one line equivalent to a line of print
[Notes]	<ul style="list-style-type: none">• This command brings about the printing of the contents of the line buffer

3. PRINTER FUNCTIONS

[Default]
[Reference] **0BH**
[Example]

(n) 0BH

[Name] **Forward feeds (n) lines**
[Format] ASCII -
 Hex 0B
 Decimal 11
[Description] Carries out the number of line feeds specified in (n)
[Notes] • The number must be ASCII and between 0 and 9 (when n=0
 the command is ignored)
 • This command clears the line buffer
[Default]
[Reference] **0AH**
[Example] To forward feed fast, 5 lines at a time:
 \$35 \$0B (or 5 and the command \$0B)

0DH

[Name] **Print the line buffer**
[Format] ASCII -
 Hex 0D
 Decimal 13
[Description] This command prints the line buffer
[Notes] • If the line buffer is empty, the command is ignored
 • If the CRLF option is set, this command is ignored and
 printing can only be ordered through the command \$0A
[Default]
[Reference] **0FH**
[Example]

0FH

[Name] **Set CRLF mode**
[Format] ASCII -
 Hex 0F
 Decimal 15
[Description] Inhibits the command \$0D maintaining enabled only the
 command \$0A for printing

3. PRINTER FUNCTIONS

[Notes]	<ul style="list-style-type: none"> • To disable this option, reset the printer • This command clears the line buffer • On switching on the default value is in the Option Register
[Default]	Setting in the option register by means of the front keys
[Reference]	0DH
[Example]	

11H

[Name]	Graphic mode																													
[Format]	ASCII -																													
	Hex 11																													
	Decimal 17																													
[Description]	Enables graphic mode: a line in 24 column mode corresponds to 144 horizontal dots divided into 24 blocks of 6 dots each; a line in 40 column mode corresponds to 240 horizontal dots divided into 40 blocks of 6 dots each.																													
[Notes]	To obtain graphic printing, enter the command \$11 at the beginning of each line. The format of the byte in graphic configuration is: <table><tr><td>X</td><td>R</td><td>P6</td><td>P5</td><td>P4</td><td>P3</td><td>P2</td><td>P1</td></tr><tr><td>D7</td><td>D6</td><td>D5</td><td>D4</td><td>D3</td><td>D2</td><td>D1</td><td>D0</td></tr></table> where: X is not used (0 is recommended); R must be fixed at level 1; P1, P6 are the graphic dot data (1 prints, 0 does not print). The P6 bit of the string of dots transmitted is printed on the left and the others follow from left to right (P5, P4, P3, P2, P1) as shown: <table><tr><td>1st byte à</td><td>2nd byte à</td><td>3rd byte à</td></tr><tr><td>P6 P5 P4 P3 P2 P1</td><td>P6 P5 P4 P3 P2 P1</td><td>P6 P5 P4 P3 P2 P1</td></tr></table>								X	R	P6	P5	P4	P3	P2	P1	D7	D6	D5	D4	D3	D2	D1	D0	1st byte à	2nd byte à	3rd byte à	P6 P5 P4 P3 P2 P1	P6 P5 P4 P3 P2 P1	P6 P5 P4 P3 P2 P1
X	R	P6	P5	P4	P3	P2	P1																							
D7	D6	D5	D4	D3	D2	D1	D0																							
1st byte à	2nd byte à	3rd byte à																												
P6 P5 P4 P3 P2 P1	P6 P5 P4 P3 P2 P1	P6 P5 P4 P3 P2 P1																												
[Default]																														
[Reference]																														
[Example]	To print a line of dots, transmit: \$11, n x \$7F (where n is the number of characters per line), \$0D. To print an empty line, transmit: \$11, \$40, \$0D.																													

12H

[Name]	Print time and date
[Format]	ASCII - Hex 12 Decimal 18
[Description]	Prints the time and date in the following format: hh : mm dd - mm -yy If seconds printing is enabled, the format will be: hh : mm : ss dd - mm -yy
[Notes]	<ul style="list-style-type: none"> • The command resets the line
[Default]	
[Reference]	13H, 14H
[Example]	

13H

[Name]	Set time and date
[Format]	ASCII - Hex 13 Decimal 19
[Description]	This command sets the time and date in two possible ways: the first uses the 24-hour clock and the second the 12-hour am/pm clock. In the first case, transmit the 10 ASCII characters representing the time and the date followed by \$13 and in the second case transmit the 10 ASCII characters representing the time and the date preceded by "A" or "P" and followed by \$13.
[Notes]	<ul style="list-style-type: none"> • It is advisable to transmit the command \$0D first, in order to empty the print buffer
[Default]	
[Reference]	12H, 14H
[Example]	To set the time 12:45 on 19-01-93, transmit: 1 2 4 5 1 9 0 1 9 3 \$13 \$31 \$32 \$34 \$35 \$31 \$39 \$30 \$31 \$39 \$33 \$13 To set the time A12:45 on 19-01-93, transmit: A 1 2 4 5 1 9 0 1 9 3 \$13 \$41 \$31 \$32 \$34 \$35 \$31 \$39 \$30 \$31 \$39 \$33 \$13

3. PRINTER FUNCTIONS

14H

[Name]	Transmit the time and date in serial		
[Format]	ASCII	-	
	Hex	14	
	Decimal	20	
[Description]	Transmit the time and date on the serial port in 11 ASCII: character format: hours/minutes/day/month/year + (CR) \$0D		
[Notes]			
[Default]			
[Reference]	12H, 13H		
[Example]			

17H,...1FH

[Name]	Print 1st (...8th) programmable character		
[Format]	ASCII	-	
	Hex	17, ...1F	
	Decimal	23, ...31	
[Description]	This command prints the corresponding programmable character.		
[Note]			
[Default]	BIT MAP contained in flash		
[Reference]	17H, 18H, 19H, 1AH, 1CH, 1DH, 1EH, 1FH		
[Example]			

ESC A [nH] [nL]

[Name]	Executes [n] dot lines feed				
[Format]	ASCII	ESC	A	nH	nL
	Hex	1B	65	nH	nL
	Decimal	27	41	nH	nL
[Description]	Executes [n] dot lines feed				

ESC R

[Name]	Set reverse mode printing		
[Format]	ASCII	ESC	R
	Hex	1B	52
	Decimal	27	82
[Description]	Selects printing in reverse mode: the receipt feeds out of the printer with the printing in normal mode running from left to right		

3. PRINTER FUNCTIONS

[Notes]

[Default] Setting in option register by means of front keys

[Reference] **ESC N**

[Example]

ESC N

[Name] **Set normal mode printing**

[Format]	ASCII	ESC	N
	Hex	1B	4E
	Decimal	27	78

[Description] Select normal mode printing: the receipt feeds out of the printer with the printing upside down running from right to left

[Notes]

[Default] Setting in option register by means of front keys

[Reference] **ESC R**

[Example]

ESC @

[Name] **Resets the printer**

[Format]	ASCII	ESC	@
	Hex	1B	40
	Decimal	27	64

[Description] Cancels all the data in the print buffer and resets the printer mode, restoring the mode which was enabled at the moment of switching on

[Notes]

- Same as hardware reset
- After the command has been transmitted, 1.5 seconds elapse before the printer is enabled

[Default]

[Reference]

[Example] This can be useful during switching on in order to avoid the sending of false characters during initialization by the master device

ESC D

[Name] **Enters the date in the print buffer**

[Format]	ASCII	ESC	D
	Hex	1B	44
	Decimal	27	68

[Description] Enters in the buffer the date of the calendar clock installed inside the printer, in the following format: dd - mm -yy.

3. PRINTER FUNCTIONS

- [Notes] • The date is printed in 8 characters: if there is not enough space in the buffer, it will not be printed
• It does not zero-set the line buffer

[Default]

[Reference] **ESC T, ESC U**

[Example] If you wish to write:

	DATE: 11-09-93 TEST OK
transmit	DATE: \$1b \$44 TEST OK \$0D
to print just the date	\$1B \$44 \$0D

ESC T

[Name] **Enters the time in the print buffer**

[Format]	ASCII	ESC	T
	Hex	1B	54
	Decimal	27	84

[Description] Enters in the buffer the time on the calendar clock installed inside the printer, in the following format: hh:mm

- [Notes] • The time is printed in 5 characters and, if the seconds option is enabled, in 8 characters: if there is not enough space in the buffer, it will not be printed.
• It does not zero-set the line buffer

[Default]

[Reference] **ESC D, ESC U, ESC S**

[Example] If you wish to write:

	HOUR: 16:45 TEST OK
transmit	HOUR \$1b \$54 TEST OK \$0D
to print just the date	\$1B \$54 \$0D

ESC U

[Name] **Enter the date (mm - dd - yy) in the print buffer**

[Format]	ASCII	ESC	U
	Hex	1B	55
	Decimal	27	85

[Description] Enter in the buffer the date on the calendar clock installed inside the printer, American style: mm-dd-yy

- [Notes] • The date is printed in 8 characters: if there is not enough space in the buffer, it will not be printed
• It does not zero-set the line buffer

[Default]

[Reference] **ESC D, ESC T**

[Example] If you wish to write:

	DATE: 09-11-93 TEST OK
transmit	DATE: \$1b \$55 TEST OK \$0D
to print just the date	\$1B \$55 \$0D

3. PRINTER FUNCTIONS

ESC S

[Name]	Enables printing of seconds		
[Format]	ASCII	ESC	S
	Hex	1B	53
	Decimal	27	83
[Description]	Enables the printing of the seconds when the time of day is requested through command ESC T		
[Notes]			
[Default]	Setting in option register by means of front keys		
[Reference]	ESC T		
[Example]			

ESC X

[Name]	Prints in red		
[Format]	ASCII	ESC	X
	Hex	1B	58
	Decimal	27	78
[Description]	After receiving this command the printer prepares itself to print in red		
[Notes]			

ESC x

[Name]	Prints in black		
[Format]	ASCII	ESC	x
	Hex	1B	78
	Decimal	27	120
[Description]	After receiving this command the printer prepares itself to print in black		
[Notes]			

3. PRINTER FUNCTIONS

ESC B

[Name]	Sets font 1		
[Format]	ASCII	ESC	B
	Hex	1B	42
	Decimal	27	66
[Description]	Selects the first character font		
[Notes]	<ul style="list-style-type: none">• The complete font is printed during the autotest. Some codes are not standard: \$60, \$7B, \$7C, \$7D, \$7E, \$7F, \$8D, \$ED, \$FA, \$FF		
[Default]	Setting in the option register by means of the front keys		
[Reference]	ESC b		
[Example]			

ESC b

[Name]	Sets font 2		
[Format]	ASCII	ESC	b
	Hex	1B	62
	Decimal	27	98
[Description]	Selects the second character font		
[Note]	<ul style="list-style-type: none">•The complete font is printed during the autotest. The font contains cyrillic characters		
[Default]	Setting in the option register by means of the front keys		
[Reference]	ESC B		
[Example]			

ESC I

[Name]	Select 24 columns		
[Format]	ASCII	ESC	I
	Hex	1B	49
	Decimal	27	73
[Description]	On receiving this command, the printer enters 24-column per line printing mode		
[Notes]			
[Default]			
[Reference]	ESC i		
[Example]			

ESC i

[Name]	Select 40 columns		
[Format]	ASCII	ESC	i
	Hex	1B	69
	Decimal	27	105
[Description]	On receiving this command, the printer enters 40-column per line printing mode		
[Notes]			
[Default]			
[Reference]	ESC I		
[Example]			

(aa) ESC r

[Name]	Read data at an address (aa)				
[Format]	ASCII	aH	aL	ESC	r
	Hex	aH	aL	1B	72
	Decimal	aH	aL	27	114
[Description]	Read a memory location (EEPROM) at address <i>a</i> aH is the most significant nibble of <i>a</i> expressed in ASCII aL is the least significant nibble of <i>a</i> expressed in ASCII				
[Notes]	<ul style="list-style-type: none"> • There are 256 legible locations (from \$00 to \$FF) 				
[Default]	The whole memory bank contains the value \$20 by default				
[Reference]	ESC w				
[Example]	To read address \$01, transmit in ASCII:				

\$30 \$31 \$1B \$72

If address \$01 contains \$A5, we will receive:

\$41 \$35

3. PRINTER FUNCTIONS

(aadd) ESC w

[Name]	Write data (dd) in address (aa)						
[Format]	ASCII	aH	aL	dH	dL	ESC	w
	Hex	aH	aL	dH	dL	1B	77
	Decimal	aH	aL	dH	dL	27	119
[Description]	Save data <i>a</i> in address <i>a</i> in the memory (EEPROM): aH is the most significant nibble of <i>a</i> expressed in ASCII aL is the least significant nibble of <i>a</i> expressed in ASCII dH is the most significant nibble of <i>d</i> expressed in ASCII dL is the least significant nibble of <i>d</i> expressed in ASCII						
[Notes]	<ul style="list-style-type: none"> There are 256 writable locations (from \$00 to \$FF). The data maximum is \$FF (255) and both the addresses and the data must be expressed in ASCII on two bytes 						
[Default]	The whole memory bank contains the value \$20 by default						
[Reference]	ESC r						
[Example]	To save the data \$A5 in the address \$01, transmit: \$30 \$31 \$41 \$35 \$1B \$77						

(dd) ESC G

[Name]	Write the value (dd) in the option register				
[Format]	ASCII	dH	dL	ESC	G
	Hex	dH	dL	1B	47
	Decimal	dH	dL	27	71
[Description]	Modify the configuration register. (dd) are two ascii characters which represent the hexadecimal code for the programming of the register.				
	(dd)	bit=0		bit=1	
	bit0: setting of real time clock	disabled		enabled	
	bit1: print direction	normal		reverse	
	bit2: number bits in parallel reception	8		7	
	bit3: printing of seconds	disabled		enabled	
	bit4: CR (\$0D)	enabled		disabled	
	bit5: reception parameter selection	hardware (dipswitch)		software	
	bit6: font selection	font 1		font 2	
	bit7: reception buffer	1Kbyte		N° columns	

3. PRINTER FUNCTIONS

[Notes] • The setting is memorized in the EEPROM and assumed as the default value the next time the printer is switched on

[Default]

[Reference] **ESC K**

[Example] To send setting byte 00001001 (\$09):
\$30 \$39 \$1B \$47

(dd) ESC K

[Name] **Write the value (dd) in the option register 1**

[Format]	ASCII	dH	dL	ESC	K
	Hex	dH	dL	1B	4B
	Decimal	dH	dL	27	75

[Description] Modifies the configuration register. (dd) are two ASCII characters representing the hexadecimal code for the programming of the register.

(dd)	bit=0	bit=1
------	-------	-------

bit0: number of columns	24 columns	40 columns
-------------------------	------------	------------

[Notes] • The setting is memorized in the EEPROM and assumed as default value the next time the printer is switched on

[Default]

[Reference] **ESC G**

[Example] To send setting byte 00001001 (\$09):
\$30 \$39 \$1B \$47

(dd) ESC M

[Name] **Writes the value (dd) in the print mode**

[Format]	ASCII	dH	dL	ESC	M
	Hex	dH	dL	1B	4D
	Decimal	dH	dL	27	77

[Description] Sets the print mode default parameters:
\$00 small character printing
\$01 double width printing
\$02 double height printing
\$03 expanded printing

3. PRINTER FUNCTIONS

[Notes]	• The setting is stored in the EEPROM
[Default]	Setting by means of the front keys
[Reference]	ESC m
[Example]	For double height printing, transmit: \$30 \$32 \$1B \$4D

ESC p

[Name]	Transmit the configuration register in serial		
[Format]	ASCII	ESC	p
	Hex	1B	70
	Decimal	27	112
[Description]	Transmit the option register byte on the serial port		
[Notes]	• If the printer is using the parallel protocol, nothing will be transmitted		
[Default]			
[Reference]	ESC G, ESC K, ESC k		
[Example]	The response is on two bytes. E.g., if you receive: \$30 \$39 it means that the default configuration is 00001001		

ESC k

[Name]	Transmits the second configuration register in serial		
[Format]	ASCII	ESC	k
	Hex	1B	6B
	Decimal	27	107
[Description]	Transmits in serial the value of the second configuration register in ASCII format on two characters which represent the hexadecimal value		
[Notes]	• If the printer is using the parallel protocol, nothing will be transmitted		
[Default]			
[Reference]	ESC K		
[Example]	The response is on two bytes. E.g. if you receive: \$30 \$39 it means that the default register is 00001001		

ESC m

[Name]	Transmits the print mode in serial		
[Format]	ASCII	ESC	m
	Hex	1B	6D
	Decimal	27	109
[Description]	Transmits the print mode configuration on the serial port		
[Notes]	<ul style="list-style-type: none"> • If the printer is using the parallel protocol, nothing will be transmitted 		
[Default]	Setting in the option register by means of the front keys		
[Reference]	ESC B		
[Example]	The response is on two bytes. E.g. if you receive:		
	\$30, \$32		
	it means that printing is in double height mode		

ESC s

[Name]	Transmits the next character in serial		
[Format]	ASCII	ESC	s
	Hex	1B	73
	Decimal	27	115
[Description]	Transmits the next character it receives on the serial port		
[Notes]			
[Default]			
[Reference]			
[Example]	If you transmit: ESC s A		
	the last character, A, will not be printed but immediately transmitted on the serial line		

(dd) ESC a

[Name]	Selects the number of dot spaces			
[Format]	ASCII	(dd)	ESC	a
	Hex	(dd)	1B	61
	Decimal	(dd)	27	97
[Description]	(dd) are two ASCII characters which identify a hexadecimal byte and correspond to the number of dot lines between one print line and another			

3. PRINTER FUNCTIONS

[Notes]

[Default] = 0

[Reference]

[Example]

ESC J (n) 10*(d)

[Name] **Load the programmable character**

[Format] ASCII ESC J (n)

Hex 1B 4A (n)

Decimal 27 74 (n)

[Description] (n) corresponds to the character number, i.e. between 1 and 8. The bit map that represents the character is contained in the next 10 bytes expressed in binary code. The formatting of these bytes is as follows:

bit	7	6	5	4	3	2	1	0
	0	1	d	d	d	d	d	d

[Notes]

[Default] The 8 characters available on switching on are loaded with a bit map contained in the printer's flash. To modify these bit maps, a firmware upgrade is required.

[Reference]

[Example] If you wish the symbol of the code \$1F to be #, transmit ESC J 2 followed by the 10 bytes making up the character:
\$1B \$4A \$32 \$52 \$52 \$52 \$7F \$52 \$52 \$7F \$52 \$52 \$52

ESC W

[Name] **Print a graphic line at 200 dpi**

[Format] ASCII ESC W

HEX 1B 57

Decimal 27 87

[Description] After receiving this command, the printer waits for 48 bytes which correspond to an entire graphic line. In fact, 48 bytes of 8 bits each correspond to 384 dots per line.

[Notes]

[Default]

[Reference]

[Example]

ESC c

[Name]	Management of bar code printing
--------	--

[Format]	ASCII	ESC c	[code] [height] [position] [options]
			[length] [data]

Hex 1B 63

Decimal 27 99

[Description]	[ASCII code]	Type of bar code
---------------	--------------	------------------

Interleaved 2/5

C Code 39

B CodaBar

e EAN8

E EAN13

[height]

Number of dot lines in 1/8 mm. units.

[position]

Left hand margin, expressed in 1/8 mm. units

[options]

bit

bit 0

bit 1

bit0: check digit	is not printed	is printed
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0
31	0	0
32	0	0
33	0	0
34	0	0
35	0	0
36	0	0
37	0	0
38	0	0
39	0	0
40	0	0
41	0	0
42	0	0
43	0	0
44	0	0
45	0	0
46	0	0
47	0	0
48	0	0
49	0	0
50	0	0
51	0	0
52	0	0
53	0	0
54	0	0
55	0	0
56	0	0
57	0	0
58	0	0
59	0	0
60	0	0
61	0	0
62	0	0
63	0	0
64	0	0
65	0	0
66	0	0
67	0	0
68	0	0
69	0	0
70	0	0
71	0	0
72	0	0
73	0	0
74	0	0
75	0	0
76	0	0
77	0	0
78	0	0
79	0	0
80	0	0
81	0	0
82	0	0
83	0	0
84	0	0
85	0	0
86	0	0
87	0	0
88	0	0
89	0	0
90	0	0
91	0	0
92	0	0
93	0	0
94	0	0
95	0	0
96	0	0
97	0	0
98	0	0
99	0	0
100	0	0
101	0	0
102	0	0
103	0	0
104	0	0
105	0	0
106	0	0
107	0	0
108	0	0
109	0	0
110	0	0
111	0	0
112	0	0
113	0	0
114	0	0
115	0	0
116	0	0
117	0	0
118	0	0
119	0	0
120	0	0
121	0	0
122	0	0
123	0	0
124	0	0
125	0	0
126	0	0
127	0	0
128	0	0
129	0	0
130	0	0
131	0	0
132	0	0
133	0	0
134	0	0
135	0	0
136	0	0
137	0	0
138	0	

bit3,2: HRI 0=no 1=above 2=below 3=above & below

bit5,4: size 0=normal 1=double 2=triple 3=quadruple

[maximum length]

Interleaved 2/5 = 12 characters

Code 39 = 10 characters

CodaBar = 10 characters

EAN8 = 8 characters

EAN13 = 13 characters

[data]

Expressed in ASCII

[Notes]

3. PRINTER FUNCTIONS

[Default]

[Reference]

[Example]

ESC Q

[Name] **Enable underlined printing**

[Format]	ASCII	ESC	Q
	Hex	1B	51
	Decimal	27	81

[Description] After this command has been received, the characters are printed underlined

[Note]

[Default]

[Reference] **ESC q**

[Example]

ESC q

[Name] **Disables underlined printing**

[Format]	ASCII	ESC	q
	Hex	1B	71
	Decimal	27	113

[Description] Annuls underlined printing

[Notes]

[Default]

[Reference] **ESC Q**

[Example]

4. TECHNICAL SPECIFICATIONS

4.1 TECHNICAL SPECIFICATIONS

The main technical features of the printer are listed in Table 4.1.

Table 4.1


Columns	24	40
Character (L x H mm)		
Normal	2x3	1x3
Double height	2x6	1x6
Double width	4x3	2x3
Expanded	4x6	2x6
Graphic dot	0,125 x 0,125	0,125 x 0,125
Custom emulation dots per line	144	240
Print speed (speed/current = normal)		
Lines/sec	30	30
Characters/sec	220	320
Feed (lines/sec)	53	53
Line buffer	24 byte	40 byte
Print buffer	1Kbyte	
Print method	Thermal dot matrix	
Character matrix	16 x 24	8x24
Print direction	Normal or reverse	
Character set	Normal and extended	
Paper roll dimensions	58 +/- 1mm x Ø50 mm max	
Standard interfaces	TTL Serial and parallel TTL	
Power supply	Double or single 5 Vdc. ± 10%	
Absorption (with 5 Volt power supply)		
Selection "Speed/current = LOW"		
Printing	3 A	
Stand by	100 mA	
In feed	750 mA	

4. TECHNICAL SPECIFICATIONS

Selection "Speed/current = NORMAL"	
Printing	4,5 A
Stand by	100 mA
In feed	750 mA
Selection "Speed/current = HIGH"	
Printing	6 A
Stand by	100 mA
In feed	750 mA
Environmentals conditions	
Operating temperature	0°C - 50°C
Operating humidity	20% - 85% (no condensing)
Storage temperature / humidity	-25°C - +70°C / 10% - 90%
Options	Real time clock

4.2 DIMENSIONS

The dimensions of the FT190 panel printer are shown in the figure below. With the screws fitted in the printer, the maximum thickness of the panel is 5 mm; using the two additional screws provided, the printer can be mounted on panels with a maximum thickness of 15 mm. For even thicker panels, use longer M3 screws.



(Figure 4.1)

5. CHARACTER SETS

5.1 CHARACTER SETS

The FT190 printer has two characters sets, each containing 224 characters (font 1 and font 2), which can be called up through the programming (paragraph 1.2) or through the control characters (paragraph 3.2).

FONT 1

123456789ABCDEF

0	0	@	P	φ	p	Ç	É	ä	⌘	α	≡		
1	!	1	A	Q	a	q	Ü	æ	i	⌘	β	±	
2	"	2	B	R	b	r	ë	Æ	ó	⌘	γ	≥	
3	#	3	C	S	c	s	ä	ö	ü	⌘	π	≤	
4	\$	4	D	T	d	t	ä	ö	ñ	-	ε	Σ	
5	%	5	E	U	e	u	ä	ö	ñ	+	F	∫	
6	&	6	F	V	f	v	ä	ö	ñ	⌘	μ	÷	
7	⌘	7	G	W	g	w	ç	ü	ñ	⌘	τ	≈	
8	⌘	8	H	X	h	x	ë	ü	ç	⌘	ø	°	
9	⌘	9	I	Y	i	y	ë	ü	ç	⌘	θ	·	
A	⌘	*	J	Z	j	z	è	ü	ç	⌘	Ω	λ	
B	⌘	+	;	K	[k	°	ï	φ	½	⌘	δ	√
C	⌘	,	<	L	\	l	±	î	£	¼	⌘	∞	h
D	⌘	-	=	M]	m	μ	ï	§	ı	⌘	∅	z
E	⌘	.	>	N	^	n	Ω	Ä	ß	«	⌘	€	Δ
F	⌘	/	?	O	_	o	≠	À	ƒ	»	⌘	Π	†

(Figure 5.1)

FONT 2

123456789ABCDEF


0	0	@	P	'	p	À	P	a	⌘	⌘	P	∅
1	!	1	A	Q	a	q	ß	ó	⌘	⌘	C	±
2	"	2	B	R	b	r	B	T	B	⌘	T	≥
3	#	3	C	S	c	s	Γ	Υ	Γ	⌘	Υ	≤
4	\$	4	D	T	d	t	∏	Φ	∏	-	ε	∫
5	%	5	E	U	e	u	E	x	e	+	F	X
6	&	6	F	V	f	v	⌘	U	⌘	⌘	U	÷
7	⌘	7	G	W	g	w	3	4	3	⌘	4	≈
8	⌘	8	H	X	h	x	W	W	⌘	⌘	W	°
9	⌘	9	I	Y	i	y	W	W	⌘	⌘	W	·
A	⌘	*	J	Z	j	z	K	b	K	⌘	b	-
B	⌘	+	;	K	[k	Π	Π	⌘	⌘	Π	√
C	⌘	,	<	L	\	l	M	b	M	⌘	b	h
D	⌘	-	=	M]	m	H	3	H	⌘	3	z
E	⌘	.	>	N	^	n	∅	∅	⌘	⌘	∅	Δ
F	⌘	/	?	O	_	o	∏	∏	⌘	⌘	∏	†

(Figure 5.2)

A.1 ACCESSORIES

A.1.1 PSM05 power supply

The following figure shows the PSM05 power supply which feeds the FT190 printer with a voltage of 5 VDC.




(Table A.1)

Output specifications		
Output voltage		5 V
Output current	Minimum	0 A
	Maximum	3,6 A
	Peak	5 A(1)
	Short Circuit	6 A(2)
Ripple P-P		100 mV(3)
Input specifications		
Input voltage		100 Vac to 240 Vac
Input frequency		50 Hz to 60 Hz

A.1.2 AV03 Rewinder

To the printer FT190 can be related in the connector J4 the rewinder model AV03.



(Figure A.2)


Technical specifications:

Range of application	Universal
Paper width (max)	60 mm
Roll diameter (max)	70 mm
Power supply	5 - 12Vdc \pm 10%
Electrical input (max)	450 mA

(Table A.2)

A.2 SPARE PARTS**(Table A.3)**

RCT57X50		Thermal paper roll		
	Quantity recommended per n° machines purchased			
N° machines	<10	<50	<100	>100
Quantities recommended	5	30	60	90

**(Figure A.3)**