


receipt printer

TM-T88II Series

Operator's Manual

Printer Parts and Labels



Caution Lables



CAUTION:

Thermal head is hot.



ATTENTION:

La tête thermique est chaude.



VORSICHT:

Der Thermalkopf ist heiß.

Labels



Label inside
printer cover



Label inside
cutter section



Caution label above drawer kick-out connector.

Quick Reference

This Quick Reference will direct you to key areas of this Operator's Manual. For a complete listing of topics, see the Contents.

Printer Parts and Labels *inside front cover*

Ordering Paper *page ix*

Where to order paper

Setting Up the Printer *page 1-1*

How to set up the printer.

Installing and Replacing Paper *page 1-7*

How to load or change the paper roll.

Solving Problems *page 3-1*

How to correct problems.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, Seiko Epson Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

EPSON is a registered trademark of Seiko Epson Corporation.
ESC/POS is a registered trademark of Seiko Epson Corporation.

NOTICE: The contents of this manual are subject to change without notice.

Copyright © 1997 by Seiko Epson Corporation, Nagano, Japan.

FCC CLASS A

FCC Compliance Statement

For American Users

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

WARNING

The connection of a non-shielded printer interface cable to this printer will invalidate the FCC Verification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FOR CANADIAN USERS

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

GEREÄUSCHPEGEL

Gemäß der Dritten Verordnung zum Gerätesicherheitsgesetz (Maschinenlärminformations- Verordnung-3. GSGV) ist der arbeitsplatzbezogene Geräusch-Emissionswert kleiner als 70 dB(A) (basierend auf ISO 7779).

DECLARATION OF CONFORMITY

Product Name: Printer

Model Name: M129B

The printer conforms to the following Directives and Norms

Directive 89/336/EEC

EN 55022 (1987 and 1994 2nd/1995) Class B

EN 50082-1 (1992)

IEC 801-2 (1991)

IEC 801-3 (1984)

IEC 801-4 (1988)

Directive 90/384/EEC

EN45501: (1992)

EMI and Safety Standards Applied

The following standards are applied only to the printers that are so labeled. (EMC is tested using the EPSON PS-170 power supply)

Europe: CE marking
EN55022
EN50082-1
EN45501

Safety Standard: TÜV (EN 60950)

North America: EMI: FCC Class A
Safety standards: UL 1950-2TH-D3
C-UL

Japan: EMI: VCCI Class 1

Oceania: EMI: AS/NZS 3548 Class B

About This Manual

Setting Up and Using

- ❑ **Chapter 1** contains information on unpacking the printer and setting it up.
- ❑ **Chapter 2** contains information on using the printer.
- ❑ **Chapter 3** contains troubleshooting information.

Reference

- ❑ **Chapter 4** contains specifications.
- ❑ **Appendix A** tells how to change the DIP switch and paper near end settings, and **Appendix B** lists the EPSON Sales Subsidiaries and their addresses.

Warnings, Cautions, and Notes



WARNING:

Warnings must be followed carefully to avoid serious bodily injury.



CAUTION:

Cautions must be observed to avoid minor injury to yourself or damage to your equipment.



Note:

Notes have important information and useful tips on the operation of your printer.

Introduction

Features

The TM-T88 II Series are high-quality POS printers that can print on a paper roll. The printers have the following features:

Printing

- ❑ High speed printing: 28.4 lines/second (1/6 inch feed) maximum.
- ❑ Low-noise thermal printing.
- ❑ High reliability due to a stable mechanism.

Application Software

- ❑ Command protocol is based on the ESC/POS™ standard.
- ❑ Various layouts are possible by using page mode.
- ❑ Characters can be scaled up to 64 times as large as the standard size. Smoothing is also possible.
- ❑ Bar code printing is possible by using a bar code command. Bar codes can be printed both in the vertical direction (fence bar code) and in the horizontal direction (ladder bar code).
- ❑ Repeated operation and copy printing are possible by using macro definitions.
- ❑ Character font size (12 x 24 font or 9 x 17 font) can be selected using a command.

Printer Handling

- ❑ Easy paper roll loading.
- ❑ An auto-cutter is standard.
- ❑ The printer allows easy maintenance for tasks such as head cleaning.
- ❑ Four different print densities can be selected by DIP switches.
- ❑ The built-in interface provides control capability for two drawers.

- ❑ Available non-volatile bit image buffer (256K bytes)

Options and Accessories

- ❑ EPSON power supply unit, PS-170.
- ❑ Affixing tapes (model : DF-10).
- ❑ RS-485 interface board can be equipped as a dealer option.
- ❑ Wall hanging bracket set (WH-10)

Ordering Paper and Supplies

Thermal roll paper can be ordered from the supplier in your area.

Specified Thermal Roll Paper: NTP080-80

In Japan:

Nakagawa Seisakujo
2-5-21 Nishiki-Cho Warabi-Shi
Saitama-Ken 335 Japan

Tel: (048) 444-8211

Fax: (048) 443-6652

In U.S.A.:

Nakagawa Mfg (USA) Inc.
2305 Lincoln Avenue
Hayward, CA 94545 USA

Tel: (510) 782-0197

Fax: (510) 782-7124

In Europe:

Nakagawa Mfg (Europe) GmbH.
Krützpoot 16, 47804
Krefeld, Germany

Tel: 02151-711051

Fax: 02151-713293

In Southeast Asia:

N.A.K. Mfg (Malaysia) SDN BHD
Lot 19-11, Bersatu Industrial Complex,
Jalan Satu, Kaw Per. Cheras Jaya.,
Balakong Industrial Area, 43200 Cheras.
Selangor Darul Ehsan, Malaysia

Tel: 03-9047896, 9047900, 9047691

Fax: 03-9047889

Other Qualified Suppliers for Thermal Paper

The following suppliers sell thermal paper that may be used if desired. Contact each company for information.

- Original paper: TF50KS-E
Nippon Paper Industry Co., Ltd.
1-12-1, Yuraku-Cho, Chiyoda-Ku
Tokyo 100 Japan
- Tel: 03-3218-8000
Fax: 03-3216-1375
- Original paper: PD 160R
New Oji Paper Mfg. Co., Ltd.
7-5 Ginza 4-Chome Chuo-Ku
Tokyo 104 Japan
- Tel: 03-3563-4800
Fax: 03-3563-1136
- Original paper: AF50KS-E
Jujo Thermal Oy (Finland)
P.O. Box 92 FIN27501 Kauttua Finland
- Tel: 38-3932900
Fax: 38-3932419
- Original paper: P350(F380)
P310
Kanzaki Specialty Papers, Inc.
1500 Main Street
Springfield, MA 01115 U.S.A.
- Tel: (413)736-3216
Fax: (413)734-5101

Contents

Quick Reference..... i
Introduction vii

Chapter 1 Setting Up the Printer

Unpacking 1-1
Connecting the Cables and Grounding the Printer 1-2
Installing or Replacing the Paper Roll 1-7
Using the Power Switch Cover 1-10
Self Test 1-10
 Running the self test 1-10
Adjustments and Settings 1-12

Chapter 2 Using the Printer

Operating the Control Panels 2-1
 Control Panel 2-1
 Panel Lights 2-2

Chapter 3 Troubleshooting

Troubleshooting 3-1
 General problems 3-1
 Printing problems 3-1
 Cleaning the print head 3-3
 Paper handling problems 3-3
 Auto cutter problems 3-5
Hexadecimal Dump 3-7

Chapter 4 Reference Information

Printing Specifications	4-1
Paper Specifications	4-3
Electrical Characteristics	4-4
Reliability	4-5
Environmental Conditions	4-5

Appendix A DIP Switch and Paper Near End Settings

Setting the DIP Switches	A-1
Adjusting the Paper Near End Sensor	A-8


Appendix B EPSON Sales Subsidiaries

Chapter 1

Setting Up the Printer

Unpacking


Your printer box should include these items. If any items are damaged or missing, please contact your dealer for assistance.



See the note on page 1-3 for information about the hexagonal lock screws.

Connecting the Cables and Grounding the Printer

You can connect up to four cables to the printer. They all connect to the connector panel on the back of the printer, which is shown below:



Notes:

There is a caution label above the drawer kick-out connector. Depending on the interface installed, the interface connector on your printer may look different from the one illustrated.


Before connecting any of the cables, make sure that both the printer and the computer are turned off.

Connecting the computer

You need an appropriate interface cable.


1. Plug the cable connector securely into the printer's interface connector.

2. If the printer has a serial interface, tighten the screws on both sides of the cable connector.




Note:

Your printer has inch-type hexagonal lock screws installed. If your interface cable requires millimeter-type screws, replace the inch-type screws with the enclosed millimeter-type screws using a hex screwdriver (5 mm).



Inch screw



Millimeter screw

If the printer has a parallel interface, squeeze the wire clip on the printer together until they lock in place on both sides of the connector.

3. Attach the other end of the cable to the computer.

Connecting the Drawer



WARNING:


Use a drawer that matches the printer specification. Using an improper drawer may damage the drawer as well as the printer.



CAUTION:

Do not connect a telephone line to the drawer kick-out connector; otherwise the printer and the telephone line may be damaged.

Plug the drawer cable into the drawer kick-out connector on the back of the printer next to the power supply connector.



Anschließen der Lade


! WARNUNG:

Eine für den Drucker geeignete Lade verwenden. Bei Verwendung einer falschen Lade kann diese oder der Drucker beschädigt werden.

! ACHTUNG:

Kein Telefonkabel an die Schnappsteckerbuchse anschließen, da sonst der Drucker und die Telefonkabel beschädigt werden können.


Das Kabel der Lade an die Schnappsteckerbuchse hinten am Drucker neben dem Netßzanschluß anschließen.



Grounding the Printer

You need a ground wire to ground your printer. Make sure that the wire is AWG 18 or equivalent.

1. Make sure that the printer is turned off.
2. Connect the ground wire to the printer using one of the the FG screws on the back of the printer, as shown.



Connecting the Power Supply

Use the optional EPSON PS-170 or equivalent power supply for your printer.

WARNING:


Make sure that you use the EPSON PS-170 power supply or equivalent. Using an incorrect power supply may cause fire or electrical shock.

CAUTIONS:

When connecting or disconnecting the power supply from the printer, make sure that the power supply is not plugged into an electrical outlet. Otherwise you may damage the power supply or the printer.

If the power supply's rated voltage and your outlet's voltage do not match, contact your dealer for assistance. Do not plug in the power cord. Otherwise, you may damage the power supply or the printer.

1. Make sure that the printer's power switch is turned off, and the power supply's power cord is unplugged from the electrical outlet.
2. Check the label on the power supply to make sure that the voltage required by the power supply matches that of your electrical outlet.
3. Plug in the power supply's cable as shown below. Notice that the flat side of the plug faces down.



Note:

To remove the DC cable connector, make sure that the power supply's power cord is unplugged; then grasp the connector at the arrow and pull it straight out.


Installing or Replacing the Paper Roll



Note:


Be sure to use paper rolls that meet the specifications. Do not use paper rolls that have the paper glued to the core because the printer cannot detect the paper end correctly.

1. Make sure that the printer is not receiving data; otherwise, data may be lost.
2. Open the paper roll cover by pressing the cover-open button. If the cover-open button will not open the cover, see page 3-4 or 3-6 in Troubleshooting.




3. Remove the used paper roll core if there is one.


4. Insert the paper roll as shown.




5. Be sure to note the correct direction that the paper comes off the roll.



6. Pull out a small amount of paper, as shown. Then close the cover.



7. Tear off the paper as shown.




Using the Power Switch Cover

WARNING:

If an accident occurs when the power switch cover is attached, unplug the power supply cord from the outlet immediately. Continued usage may lead to fire or shock.

You can use the enclosed power switch cover to make sure that the power switch is not accidentally pressed. If you want to use this cover, install it as shown in the illustration below.



Self Test

The self test lets you know if your printer is operating properly. It checks the control circuits, printer mechanisms, print quality, ROM version, and DIP switch settings.

This test is independent of any other equipment or software.

Running the self test

1. Make sure the printer is turned off and the printer covers are closed properly.

2. While holding down the FEED button, turn on the printer using the switch on the front of the printer to begin the self test. The self test prints the printer settings and then prints the following, cuts the paper, and pauses. (The PAPER OUT light blinks.)

Self test printing.
Please press the PAPER FEED button.

3. Press the FEED button to continue printing. The printer prints a pattern using the built-in character set.
4. The self test automatically ends and cuts the paper after printing the following:

*** completed ***

The printer is ready to receive data as soon as it completes the self test.



Note:

If you want to pause the self test manually, press the FEED button. Press the FEED button again to continue the self test.

Adjustments and Settings

The TM-T88II Series are set up at the factory to be appropriate for almost all users. It does, however, offer some settings for users with special requirements.

It has DIP switches that allow you to change communication settings, such as handshaking and parity check, as well as print density.

The TM-T88II Series also have a near-end sensor for the paper. This can give you a warning when the paper is almost out. If you find that there is not enough paper remaining on the roll when the near-end detector is triggered, you can change the near-end sensor setting.

See Appendix A if you need to make any of these changes.


Chapter 2

Using the Printer

Operating the Control Panels

You can control the basic paper feeding operations of the printer with the button on the control panel. The indicator lights help you monitor the printer's status.

Control Panel



Button

The button can be disabled by the **ESC c 5** command.

Press the FEED button once to advance paper one line. You can also hold down the FEED button to feed paper continuously.

Panel lights

POWER

The POWER light is on whenever the printer is on.

ERROR

This indicates an error. See Chapter 3 for information on what to do when this light comes on.

PAPER OUT

This light indicates the near end of the paper roll. Install a new paper roll and the printer will continue printing.

When the light blinks, it indicates the self-test printing standby state or macro execution standby state when the macro execution command is used.

Chapter 3

Troubleshooting

Troubleshooting

This chapter gives solutions to some printer problems you may have.

General problems

The lights on the control panel do not come on.

Make sure that the power supply cables are correctly plugged into the printer, the power unit, and to the power outlet.

Make sure that power is supplied to the power outlet. If the outlet is controlled by a switch or timer, use another outlet.

Printing problems

The ERROR light is on (not blinking) and nothing is printed.

If the PAPER OUT light is **on**, the paper roll is not installed or is at or near the end. Install a new paper roll. See Chapter 1 for instructions.

If the PAPER OUT light is **off**, make sure that the printer cover is properly closed. Press the printer cover until the cover audibly clicks into place.

The ERROR light is blinking and the printer does not print.

First, turn off the printer and check for a paper jam. (See the paper jam description on page 3-3.)

If there is no paper jam and the printer has been printing for quite a while, the print head may be overheated. If the print head is overheated, the printer will resume printing when the head has cooled (usually within two or three minutes).

If there is no paper jam and the print head is not overheated, turn off the printer and turn it back on after about 10 seconds. If the ERROR light is still flashing, contact a qualified service person.

The ERROR light is off, but nothing is printed.

Try to run the self test to check that the printer works properly. See the self test instructions in Chapter 1 to run the self test. If the self test does not work, contact your dealer or a qualified service person.

If the self test works properly, check the following:

1. Check the connection at both ends of the interface cable between the printer and the computer. Also make sure that this cable meets the specifications for both the printer and the computer.
2. The data transmission settings may be different between the printer and computer. Make sure that the printer's DIP switch settings for data transmission are the same as the computer's. You can print the printer's interface settings using the self test.

If the printer still does not print, contact your dealer or a qualified service person.

Printing is poor.

Paper dust on the heating element of the thermal print head can lower the print quality. Try cleaning the print head as described below:


Cleaning the print head

CAUTIONS:

After printing, the print head can be very hot. Be careful not to touch it. Also let it cool before you clean it.

Do not damage the print head by touching it with your fingers or any hard object.

1. Open the printer cover.
2. Clean the thermal element of the print head with a cotton swab moistened with an alcohol solvent (ethanol, methanol, or IPA).



Paper handling problems


Paper is jammed inside the printer.

CAUTIONS:


Do not touch the print head because it can be very hot after printing continuously for a long time.

To clear a paper jam, follow the steps below:

1. Turn the printer off and press the cover open button to open the cover.
2. Remove the jammed paper and put the roll back in the printer and close the cover.
3. If paper is caught in the automatic cutter and the printer cover cannot be opened, open the cutter cover as shown below.



4. Then turn the knob until you see ▽ in the opening, as shown in the illustration below. This returns the cutter blade to the normal position. Also notice that there is a label near the cutter to assist you.



5. Close the cutter cover.
6. Open the printer cover.
7. Remove the jammed paper.

Auto cutter problems


The auto cutter is jammed.


If a foreign object such as a push pin or paper clip drops in the auto cutter and causes the auto cutter to lock up, the printer enters an error state and begins the recovery operation automatically.


If the problem is not serious, the auto cutter returns to its normal position without any intervention by the user.

If the auto cutter does not return to its normal position by itself, follow the steps below to correct the problem:

1. Pull the cutter cover toward you so that you can rotate the cutter motor knob.



2. Following the instructions on the label, rotate the knob until the  appears in the hole.



3. Close the cutter cover.

Hexadecimal Dump

This feature allows experienced users to see exactly what data is coming to the printer. This can be useful in finding software problems. When you turn on the hex dump function, the printer prints all commands and other data in hexadecimal format along with a guide section to help you find specific commands.

To use the hex dump feature, follow these steps:

1. After you make sure that the printer is off, open the cover.
2. Hold down the FEED button while you turn on the printer.
3. Close the cover.
4. Run any software program that sends data to the printer. The printer prints “Hexadecimal Dump” and then all the codes it receives in a two-column format. The first column contains the hexadecimal codes and the second column gives the ASCII characters that correspond to the codes.

Hexadecimal Dump

```
1B 21 00 1B 26 02 40 40 . ! . . & . @ @  
1B 25 01 1B 63 34 00 1B . % . . c4 . .  
41 42 43 44 45 46 47 48 ABCDEFGH
```

- ☐ A period (.) is printed for each code that has no ASCII equivalent.
 - ☐ During the hex dump all commands except **DLE EOT** and **DLE ENQ** are disabled.
5. Open the cover to set the printer off line so that it will print the last line.
 6. Close the cover and turn off the printer or reset it to turn off the hex dump mode.

Printing Specifications

Printing method:	Thermal line printing
Dot density:	180 dpi × 180 dpi [the number of dots per 25.4 mm (1")]
Printing direction:	Unidirectional with friction feed
Printing width:	72 mm (2.83"), 512 dot positions
Characters per line (default):	42 (Font A) 56 (Font B)
Character spacing (default):	0.28 mm (.01") (2 dots) (Font A) 0.28 mm (.01") (2 dots) (Font B) Programmable by control command.
Printing speed - High speed mode:	28.4 lines/second maximum (1/6" feed, at 24V, 20° C, density level 2) Approximately 120 mm/second maximum (approximately 4.72"/second maximum) Speed is adjusted deepening on the applied voltage to the printer and head temperature conditions automatically.
Printing speed - Low power consumption mode:	Approximately 16.5 lines/second (1/6" feed) Approximately 70 mm/second (approximately 2.76"/second)
Printing speed - when a ladder bar code is printed:	Approximately 42 mm/ second (approximately 1.7"/ second)

**Notes:**

Printing speed may be slower, depending on the data transmission speed and the combination of control commands.

There may be variations in printing after switching the mode of the printing speed. To prevent this for logo printing, using a downloaded bit image is recommended. (Change in printing speed does not occur during downloaded bit image printing).

Paper feeding speed: Approximately 120 mm/second
(approximately 4.72" /second) continuous
paper feeding

Line spacing (default): 4.23 mm (1/6")
Programmable by control command.

Number of characters: Alphanumeric characters: 95
International characters: 32

Extended graphics: 128 × 7 pages
(including one space page)
kanji chareacters: JIS-Level 1, Level 2
(JIS X0208-1990)

Character structure: Font A: 12 × 24 (including 2-dot spacing
in horizontal)

Font B: 9 × 17 (including 2-dot spacing in
horizontal)

Kanji: 24 × 24

Font A is the default

	Standard		Double-height		Double-width		Double-width/ Double-height	
	W x H (mm)	CPL	W x H (mm)	CPL	W x H (mm)	CPL	W x H (mm)	CPL
Font A 12 x 24	1.41 x 3.39 (.06" x .13")	42	1.41 x 6.77 (.06" x .27")	42	2.82 x 3.39 (.11" x .13")	21	2.82 x 6.77 (.11" x .27")	21
Font B 9 x 17	0.99 x 2.40 (.04" x .09")	56	0.99 x 4.80 (.04" x .19")	56	1.98 x 2.40 (.08" x .09")	28	1.98 x 4.80 (.08" x .19")	28
Kanji 24 x 24	3.39 x 3.39 (.13" x .13")	21	3.39 x 6.77 (.13" x .27")	21	6.77 x 3.39 (.27" x .13")	10	6.77 x 6.77 (.27" x .27")	10

* CPL = Characters Per Line

* Space between characters is not included

* Characters can be scaled up to 64 times as large as the standard sizes.

Paper Specifications

Paper roll (single-ply): Size: Width: 79.5 mm \pm 0.5 mm
(3.13" \pm 0.02")

Maximum
outside
diameter: 83 mm (3.27")

Paper roll
spool
diameter: Inside: 12 mm (0.47")
Outside: 18 mm (0.71")
Paper must not be pasted
to the paper roll spool.

Take up
paper roll
width: $80 \pm_{1.0}^{0.5}$ mm 3.15" $\pm_{0.04}^{0.02}$ "

Electrical Characteristics

Supply voltage: +24 VDC \pm 7% (optional power supply: EPSON PS-170)

Current consumption: (at 24V)	High speed mode:	Mean: Approximately 1.7A (character font A α -N all columns printing) Peak: Approximately 7.7A
--------------------------------------	------------------	---

	Low power consumption mode:	Mean: Approximately 1.2A (Character font A α -N all columns printing) Peak: Approximately 6.6A
--	-----------------------------	---

	Standby:	Mean: Approximately 0.2A
--	----------	--------------------------



Note:
Maximum 1A for drawer kick-out driving

Reliability

Life:	Mechanism:	15,000,000 lines
	Thermal head:	100 million pulses, 100 km
	Auto cutter:	1,500,000 cuts
	(End of Life is defined as the point at which the printer reaches the beginning of the Wearout Period.)	
MTBF:	180,000 hours (Failure is defined as Random Failure occurring at the time of the Random Failure Period.)	
MCBF:	37,000,000 lines (This is an average failure interval based on failures relating to wearout and random failures up to the life of 15 million lines.)	

Environmental Conditions

Temperature:	Operating:	5° to 45°C (41° to 113°F)
	Storage:	-10° to 50°C (14° to 122°F) (except for paper)
Humidity:	Operating:	10 to 90% RH
	Storage:	10 to 90% RH (except for paper)

Appendix A

Dip Switch and Paper Near End Settings

Although the factory settings are best for almost all uses, if you have special requirements, you can change the DIP switch or paper near end settings.

Setting the DIP Switches

DIP switch functions

Your printer has two sets of DIP switches. The functions of the switches are shown in the following tables.

Serial interface specification

Set 1

SW	Function	ON	OFF
1-1	Data receive error	Ignored	Prints “?”
1-2	Receive buffer capacity	45 bytes	4K bytes
1-3	Handshaking	XON/XOFF	DTR/DSR
1-4	Data word length	7 bits	8 bits
1-5	Parity check	Enabled	Disabled
1-6	Parity selection	Even	Odd
1-7	Transmission speed (See the table below)		
1-8			

Transmission Speed

Transmission Speed (BPS)-bits per second	1-7	1-8
2400	ON	ON
4800	OFF	ON
9600	ON	OFF
19200	OFF	OFF

Set 2

SW	Function	ON	OFF
2-1	Handshaking (BUSY condition)	Receive buffer full	Off line or receive buffer full
2-2	Reserved: do not change settings	Fixed to OFF	
2-3	Selects print density	Refer to table below	
2-4			
2-5	Reserved: do not change settings	Fixed to OFF	
2-6	Reserved: do not change settings	Fixed to OFF	
2-7	I/F pin 6 reset signal	Enabled	Disabled
2-8	I/F pin 25 reset signal	Enabled	Disabled

Print Density Selection

Print Density	SW 2-3	SW 2-4
1 Low power consumption mode	ON	ON
2(Normal)	OFF	OFF
3	ON	OFF
4 (Dark)	OFF	ON

Notes:

- With the optional RS-485 interface, DIP switches 2-7 and 2-8 are disabled.
- Changes in DIP switch settings (excluding switches 2-7 and 2-8 interface reset signals) are recognized only when the printer power is turned on or when the printer is reset by using the interface. If the DIP switch setting is changed after the printer power is turned on, the change does not take effect until the printer is turned on again or is reset.
- If you turn on DIP switch 2-7 or 2-8 while the printer is turned on, the printer may be reset, depending on the signal state. DIP switches should not be changed while the printer power is on.
- If the print density is set to level 3 or 4, the printing will be at the low speed.
- In a low power consumption, printing speed is fixed to 70 mm/sec.

Parallel interface specification

Set 1

SW	Function	ON	OFF
1-1	Auto line feed	Always enabled	Always disabled
1-2	Receive buffer capacity	45 bytes	4K bytes
1-3~ 1-8	Undefined	–	–

Set 2

SW	Function	ON	OFF
2-1	Handshaking (BUSY condition)	<ul style="list-style-type: none">• Receive buffer full• Reading data	<ul style="list-style-type: none">• Off-line• Receive buffer full• Reading data
2-2	Reserved (Do not change settings)	Fixed to Off	
2-3	Selects print density	Refer to table below	
2-4			
2-5~ 2-7	Reserved (Do not change settings)	Fixed to Off	
2-8	I/F pin 31 reset signal (Do not change settins)	Fixed to On	

Print Density Selection

Print Density	SW 2-3	SW 2-4
1 Low power consumption mode	ON	ON
2 (Normal)	OFF	ON
3	ON	OFF
4 (Dark)	OFF	OFF

Notes:

- Changes in DIP switch settings (excluding switch 2-8 interface reset signal) are recognized only when the printer power is turned on or when the printer is reset by using the interface. If the DIP switch setting is changed after the printer power is turned on, the change does not take effect until the printer is turned on again or is reset.
- If you turn on DIP switch 2-8 while the printer is turned on, the printer may be reset, depending on the signal state. DIP switches should not be changed while the printer power is on.
- If the print density is set to level 3 or 4, the printing will be at the low speed.
- In a low power consumption, printing is fixed to 70mm/sec.


Changing the DIP switch settings

If you need to change settings, follow the steps below to make your changes:

CAUTION:

Turn off the printer while removing the DIP switch cover to prevent an electric short, which can damage the printer.

1. Make sure the printer is turned off.
2. Remove the screw from the DIP switch cover. Then take off the DIP switch cover, as shown in the illustration below.



3. Set the switches using a pointed tool, such as tweezers or a small screwdriver.
4. Replace the DIP switch cover. Then secure it with the screw.

The new settings take effect when you turn on the printer.

Adjusting the Paper Near End Detector

The paper near end detector detects when paper is almost gone by measuring the diameter of the paper roll. The detector has two settings.


Because of variations in paper roll cores, it is not possible for the detector to measure exactly the length of paper left on the roll when the detector is triggered. Of the two settings, the factory setting (lower) leaves the least amount of paper on the roll when the sensor is triggered. If you want more paper left, change the setting as described below.



Note:

The factory setting is based on a paper roll core with an outside diameter of 18mm and an inside diameter of 12mm. If you use a paper roll with a core with an outside diameter of more than 18mm, it is better to change to the upper setting, as described below.

1. Open the printer cover, and remove the paper roll.
2. Loosen the adjusting screw and move the tab up to the upper setting.



3. Tighten the adjusting screw, and check to be sure that the detecting lever moves freely.
4. Replace the paper roll.

Appendix B

EPSON Sales Subsidiaries

EPSON AMERICA INC./OEM DIV.	20770 Madrona Ave. Torrance, CA 90559-2842 U.S.A. Tel : 1-310-787-6300 Fax : 1-310-782-5350
EPSON EUROPE B.V.	Prof. J.H. Bavincklaan 5 1183 AT Amstelveen The Netherlands Tel : 31-(0)20-5475-251 Fax : 31-(0)20-6454-315
EPSON Deutschland GmbH	Zülpicher Strasse 6, 40549 Düsseldorf 11, Germany Tel : 49-(0)211-5603152 Fax : 49-(0)211-5603319
EPSON U.K. LIMITED	Campus 100 Maylands Ave. Hemel Hempstead Herts. HP2 7TJ United Kingdom Tel : 44-1(0)442-61144 Fax : 44-1-(0)442-227-244
EPSON FRANCE S.A.	68 Bis Rue Marjolin B.P. 320 92305 Levallois Perret Cedex, France Tel : 33-(0)1-40-87-38-62 Fax : 33-(0)1-47-37-15-10
EPSON IBERICA, S.A.	Avda. de Roma, 18-26 08290 Cerdanyola del Vallès (Barcelona), Spain Tel : 34-(9)3-582-2500 Fax : 34-(9)(3-582-1555
EPSON ITALIA S.P.A.	V.le F Ili Casiraghi, 427 20099 Sesto Si Giovanni (Milan), Italy Tel : (39)226-2331 Fax (39)2244-0750
EPSON SINGAPORE PTE. LTD.	No. 1 Raffles Place #26-00 OUB Centre Singapore, 0104 Tel : 5-530477 Fax : 5-5338119

EPSON HONG KONG LIMITED	25/F., Harbor Centre, 25, Harbor Road, Wanchai, Hong Kong Tel : 852-2-585-4663 Fax : 852-2-827-4346
EPSON TAIWAN TECHNOLOGY & TRADING LTD.	10f, No. 287, Nanking E. Road, Sec. 3 Taipei, Taiwan R.O.C. Tel : 886-(0)2-717-7360 Fax : 886-(0)2-718-9366
SEIKO EPSON CORP. KOREA OFFICE	10F, KIL 63 Building 60, Yoido Dong, Youngedungpo-Ku, Seoul, Korea Tel : 82-(0)2-784-6027 Fax : 82-(0)2-769-1049
EPSON AUSTRALIA PTY. LTD.	70 Gibbes Street, Chatswood NSW 2067 Australia Tel : 61-(0)2-415-9000 Fax : 61-(0)2-417-0077
EPSON HANBAI CO., LTD. TOKYO OFFICE:	3F Building Kawaguchi Fuda Chofu-Shi Tokyo 182 Japan Tel : 0424-99-7829 Fax : 0424-99-7834
OSAKA OFFICE:	13F Shin-Osaka Daiichi-Seimei Bldg. 5-24 3-Chome Miyahara Yodogawa-ku Osaka 532 Japan Tel : 06-350-4964 Fax : 06-350-4968